


Service Manual



PDP-5010FD

ORDER NO.
ARP3455

PLASMA DISPLAY SYSTEM

PDP-5010FD

THIS MANUAL IS APPLICABLE TO THE FOLLOWING MODEL(S) AND TYPE(S).

Model	Type	Power Requirement	Remarks
PDP-5010FD	KUCXC	AC 120 V	
PDP-5010FD	KUC	AC 120 V	



For details, refer to "Important Check Points for good servicing".

SAFETY INFORMATION



This service manual is intended for qualified service technicians ; it is not meant for the casual do-it-yourselfer. Qualified technicians have the necessary test equipment and tools, and have been trained to properly and safely repair complex products such as those covered by this manual.

Improperly performed repairs can adversely affect the safety and reliability of the product and may void the warranty. If you are not qualified to perform the repair of this product properly and safely, you should not risk trying to do so and refer the repair to a qualified service technician.

WARNING

This product contains lead in solder and certain electrical parts contain chemicals which are known to the state of California to cause cancer, birth defects or other reproductive harm.

Health & Safety Code Section 25249.6 - Proposition 65

NOTICE

(FOR CANADIAN MODEL ONLY)

Fuse symbols (fast operating fuse) and/or (slow operating fuse) on PCB indicate that replacement parts must be of identical designation.

REMARQUE

(POUR MODÈLE CANADIEN SEULEMENT)

Les symboles de fusible (fusible de type rapide) et/ou (fusible de type lent) sur CCI indiquent que les pièces de remplacement doivent avoir la même désignation.

SAFETY PRECAUTIONS

NOTICE : Comply with all cautions and safety related notes located on or inside the cabinet and on the chassis.

The following precautions should be observed :

1. When service is required, even though the PDP UNIT an isolation transformer should be inserted between the power line and the set in safety before any service is performed.
2. When replacing a chassis in the set, all the protective devices must be put back in place, such as barriers, nonmetallic knobs, adjustment and compartment covershields, isolation resistor-capacitor, etc.
3. When service is required, observe the original lead dress. Extra precaution should be taken to assure correct lead dress in the high voltage circuitry area.
4. Always use the manufacture's replacement components. Especially critical components as indicated on the circuit diagram should not be replaced by other manufacture's. Furthermore where a short circuit has occurred, replace those components that indicate evidence of overheating.
5. Before returning a serviced set to the customer, the service technician must thoroughly test the unit to be certain that it is completely safe to operate without danger of electrical shock, and be sure that no protective device built into the set by the manufacture has become defective, or inadvertently defeated during servicing. Therefore, the following checks should be performed for the continued protection of the customer and servicetechnician.

6. Perform the following precautions against unwanted radiation and rise in internal temperature.

- Always return the internal wiring to the original styling.
 - Attach parts (Gasket, Ferrite Core, Ground, Rear Cover, Shield Case etc.) surely after disassembly.
7. Perform the following precautions for the PDP panel.
- When the front case is removed, make sure nothing hits the panel face, panel corner, and panel edge (so that the glass does not break).
 - Make sure that the panel vent does not break. (Check that the cover is attached.)
 - Handle the FPC connected to the panel carefully. Twisting or pulling the FPC when connecting it to the connector will cause it to peel off from the panel.
8. Pay attention to the following.
- Pay extreme caution when the front case and rear panel are removed because this may cause a high risk of disturbance to TVs and radios in the surrounding.

Leakage Current Cold Check

With the AC plug removed from an AC power source, place a jumper across the two plug prongs. Turn the AC power switch on. Using an insulation tester (DC 500V), connect one lead to the jumpered AC plug and touch the other lead to each exposed metal part (input/output terminals, screwheads, metal overlays, control shafts, etc.), particularly any exposed metal part having a return path to the chassis. Exposed metal parts having a return path to the chassis should have a minimum resistor reading of 4 MΩ.


The below 4 MΩ resistor value indicate an abnormality which require corrective action. Exposed metal parts not having a return path to the chassis will indicate an open circuit.

Leakage Current Hot Check

Plug the AC line cord directly into an AC power source (do not use an isolation transformer for this check).

Turn the AC power switch on.

Using a "Leakage Current Tester (Simpson Model 229 equivalent)", measure for current from all exposed metal parts of the cabinet (input/output terminals, screwheads, metal overlays, control shaft, etc.), particularly any exposed metal part having a return path to the chassis, to a known earth ground (water pipe, conduit, etc.). Any current measured must not exceed 1 mA.



AC Leakage Test

ANY MEASUREMENTS NOT WITHIN THE LIMITS OUTLINED ABOVE ARE INDICATIVE OF A POTENTIAL SHOCK HAZARD AND MUST BE CORRECTED BEFORE RETURNING THE SET TO THE CUSTOMER.

PRODUCT SAFETY NOTICE

Many electrical and mechanical parts in PIONEER set have special safety related characteristics. These are often not evident from visual inspection nor the protection afforded by them necessarily can be obtained by using replacement components rated for higher voltage, wattage, etc. Replacement parts which have these special safety characteristics are identified in this Service Manual.

Electrical components having such features are identified by marking with a ⚠ on the schematics and on the parts list in this Service Manual.

The use of a substitute replacement component which does not have the same safety characteristics as the PIONEER recommended replacement one, shown in the parts list in this Service Manual, may create shock, fire or other hazards.

Product Safety is continuously under review and new instructions are issued from time to time. For the latest information, always consult the current PIONEER Service Manual. A subscription to, or additional copies of, PIONEER Service Manual may be obtained at a nominal charge from PIONEER.

[Important Check Points for Good Servicing]

In this manual, procedures that must be performed during repairs are marked with the below symbol.
Please be sure to confirm and follow these procedures.

1. Product safety



Please conform to product regulations (such as safety and radiation regulations), and maintain a safe servicing environment by following the safety instructions described in this manual.

- ① Use specified parts for repair.

Use genuine parts. Be sure to use important parts for safety.

- ② Do not perform modifications without proper instructions.

Please follow the specified safety methods when modification (addition/change of parts) is required due to interferences such as radio/TV interference and foreign noise.

- ③ Make sure the soldering of repaired locations is properly performed.

When you solder while repairing, please be sure that there are no cold solder and other debris.
Soldering should be finished with the proper quantity. (Refer to the example)

- ④ Make sure the screws are tightly fastened.

Please be sure that all screws are fastened, and that there are no loose screws.

- ⑤ Make sure each connectors are correctly inserted.

Please be sure that all connectors are inserted, and that there are no imperfect insertion.

- ⑥ Make sure the wiring cables are set to their original state.

Please replace the wiring and cables to the original state after repairs.
In addition, be sure that there are no pinched wires, etc.

- ⑦ Make sure screws and soldering scraps do not remain inside the product.

Please check that neither solder debris nor screws remain inside the product.

- ⑧ There should be no semi-broken wires, scratches, melting, etc. on the coating of the power cord.

Damaged power cords may lead to fire accidents, so please be sure that there are no damages.
If you find a damaged power cord, please exchange it with a suitable one.

- ⑨ There should be no spark traces or similar marks on the power plug.

When spark traces or similar marks are found on the power supply plug, please check the connection and advise on secure connections and suitable usage. Please exchange the power cord if necessary.

- ⑩ Safe environment should be secured during servicing.

When you perform repairs, please pay attention to static electricity, furniture, household articles, etc. in order to prevent injuries.
Please pay attention to your surroundings and repair safely.

2. Adjustments



To keep the original performance of the products, optimum adjustments and confirmation of characteristics within specification.
Adjustments should be performed in accordance with the procedures/instructions described in this manual.

3. Lubricants, Glues, and Replacement parts



Use grease and adhesives that are equal to the specified substance.
Make sure the proper amount is applied.

4. Cleaning



For parts that require cleaning, such as optical pickups, tape deck heads, lenses and mirrors used in projection monitors, proper cleaning should be performed to restore their performances.

5. Shipping mode and Shipping screws



To protect products from damages or failures during transit, the shipping mode should be set or the shipping screws should be installed before shipment. Please be sure to follow this method especially if it is specified in this manual.

CONTENTS

SAFETY INFORMATION	2
1. SERVICE PRECAUTIONS.....	7
1.1 NOTES ON SOLDERING	7
1.2 CHARGED SECTION AND HIGH VOLTAGE GENERATING POINT	8
2. SPECIFICATIONS.....	9
2.1 ACCESSORIES.....	9
2.2 SPECIFICATIONS	10
2.3 PANEL FACILITIES.....	11
3. BASIC ITEMS FOR SERVICE	14
3.1 CHECK POINTS AFTER SERVICING	14
3.2 QUICK REFERENCE	15
3.3 PCB LOCATION	17
3.4 JIGS LIST	18
3.5 CLEANING	18
4. BLOCK DIAGRAM	20
4.1 OVERALL WIRING DIAGRAM (1/2).....	20
4.2 OVERALL WIRING DIAGRAM (2/2).....	22
4.3 OVERALL BLOCK DIAGRAM (1/2)	24
4.4 OVERALL BLOCK DIAGRAM (2/2)	26
4.5 POWER SUPPLY UNIT	28
4.6 50F X DRIVE ASSY.....	29
4.7 50F Y DRIVE, 50F SCAN A, B, C and D ASSYS	30
4.8 POWER SUPPLY BLOCK of 50F X, Y DRIVE and 50F SCAN A, B, C and D ASSYS	31
4.9 50F ADDRESS L and S ASSYS.....	32
4.10 50F DIGITAL ASSY	33
4.11 MAIN ASSY (DTV BLOCK DIAGRAM).....	34
4.12 POWER SUPPLY BLOCK of MAIN ASSY	36
4.13 TANSHI ASSY	38
4.14 50FHD LED and FHD IR ASSYS	39
4.15 POWER SUPPLY BLOCK of FHD RLS and SIDE KEY ASSYS	40
5. DIAGNOSIS	41
5.1 POWER SUPPLY OPERATION.....	41
5.1.1 LED DISPLAY INFORMATION.....	41
5.1.2 POWER ON SEQUENCE	42
5.1.3 DETAILS OF POWER ON SEQUENCE.....	43
5.2 DIAGNOSIS FLOWCHART OF FAILURE ANALYSIS	45
5.2.1 WHOLE UNIT.....	45
5.2.2 POWER SUPPLY UNIT.....	47
5.2.3 DRIVE ASSY	48
5.2.4 DIGITAL ASSY	52
5.2.5 MAIN ASSY.....	53
5.2.6 VIDEO SYSTEM	54
5.2.7 AUDIO SYSTEM	60
5.3 DIAGNOSIS OF PD (POWER-DOWN)	63
5.3.1 BLOCK DIAGRAM OF THE POWER-DOWN SIGNAL	63
5.3.2 PD (POWER-DOWN) DIAGNOSIS OF FAILURE ANALYSIS	64
5.4 DIAGNOSIS OF SD (SHUTDOWN)	67
5.4.1 BLOCK DIAGRAM OF THE SHUTDOWN SIGNAL	67
5.4.2 SD (SHUTDOWN) DIAGNOSIS	68
5.5 NON-FAILURE INFORMATION.....	70
5.5.1 INFORMATION ON SYMPTOMS THAT DO NOT CONSTITUTE FAILURE	70
5.5.2 FUNCTION OF DECREASING THE BRIGHTNESS LEVEL	73
5.6 OUTLINE OF THE OPERATION	74
5.6.1 PANEL DRIVE-POWER ON / OFF FUNCTION	74
5.6.2 SPECIFICATION OF THE FAN CONTROL.....	75
5.6.3 PROCESSING IN ABNORMALITY	76
5.6.4 TRAP SWITCH.....	79

	6. SERVICE FACTORY MODE	80
	6.1 OUTLINE OF THE SERVICE FACTORY MODE	80
A	6.1.1 SERVICE FACTORY MODE TRANSITION CHART	80
	6.1.2 HOW TO ENTER/EXIT SERVICE FACTORY MODE	80
	6.1.3 FUNCTIONS WHEN ENTERING THE SERVICE FACTORY MODE	81
	6.1.4 REMOTE CONTROL CODE IN SERVICE FACTORY MODE	82
	6.1.5 PDP SERVICE REMOTE CONTROL	83
	6.1.6 FACTORY HIERARCHICAL TABLE	84
	6.1.7 INDICATIONS IN SERVICE FACTORY MODE	86
	6.2 DETAILS OF FACTORY MENU	88
	6.2.1 INFORMATION	88
	6.2.2 PANEL FACTORY (+)	98
	6.2.3 OPTION	108
	6.2.4 INITIALIZE	109
B	7. DISASSEMBLY	112
	7.1 FLOWCHART OF REMOVAL ORDER FOR THE MAIN PARTS AND BOARDS	112
	7.2 DISASSEMBLY	113
	7.3 DISASSEMBLY AND REASSEMBLY PRECAUTIONS FOR SPEAKER SYSTEM	121
	8. EACH SETTING AND ADJUSTMENT	122
	8.1 ADJUSTMENT REQUIRED WHEN THE UNIT IS REPAIRED OR REPLACED	122
	8.2 BACKUP OF THE EEPROM (DIGITAL ASSY)	124
	8.3 HOW TO CLEAR HISTORY DATA	127
	8.4 ADJUSTMENT WHEN THE SERVICE PANEL ASSY IS REPLACED	128
	8.5 ADJUSTMENT WHEN THE DRIVE ASSYS ARE REPLACED	141
	8.6 PRECAUTION ON REPLACEMENT OF THE POWER SUPPLY UNIT	144
C	9. RS-232C	145
	9.1 OUTLINE OF RS-232C COMMAND	145
	9.1.1 PREPARED TOOLS	145
	9.1.2 USING RS-232C COMMANDS	145
	9.2 LIST OF RS-232C COMMANDS	146
	9.3 DETAILS OF EACH COMMANDS	155
	9.3.1 QS1 (PANEL STATUS)	155
	9.3.2 QS2 (PANEL OPERATION DATA)	156
	9.3.3 QS3 (OTHER DATA ON THE PANEL)	157
	9.3.4 QAJ (PANEL ADJUSTMENT DATA)	158
	9.3.5 QPW (VIDEO ADJUSTMENT DATA OF THE PANEL)	159
	9.3.6 QPM (PULSE METER VALUE)	159
D	9.3.7 QPD (PD LOGS)	160
	9.3.8 QSD (SD LOGS)	161
	9.3.9 QSE (DESTINATION PECULIAR INFORMATION)	162
	9.3.10 QMT (TEMPERATURE / FAN ROTATION / ROOM LIGHT SENSOR)	162
	9.3.11 QNG (SHUTDOWN INFORMATION OF MTB)	163
	9.3.12 QSI (INPUT SIGNAL DATA)	165
	9.3.13 DRV (PANEL DRIVE-POWER ON / OFF)	165
	9.3.14 FAY / FAN (ADJ. COMMANDS PERMISSION / PROHIBITION)	166
	9.3.15 FAJ / UAJ / CBU / BCP (BACKUP FUNCTION FOR ADJUSTMENT VALUE)	166
	10. EXPLODED VIEWS AND PARTS LIST	168
	10.1 PACKING SECTION	168
	10.2 REAR SECTION	170
E	10.3 FRONT SECTION	172
	10.4 CHASSIS SECTION (1/2)	174
	10.5 CHASSIS SECTION (2/2)	176
	10.6 PANEL CHASSIS SECTION	178
	10.7 MULTI BASE SECTION	180
	10.8 PDP SERVICE ASSY 508F (AWU1272)	182
	10.9 TABLE TOP STAND	184
	10.10 SPEAKER SYSTEM (PACKING)	185
	10.11 CS ASSY	186

1. SERVICE PRECAUTIONS

1.1 NOTES ON SOLDERING

- For environmental protection, lead-free solder is used on the printed circuit boards mounted in this unit.
Be sure to use lead-free solder and a soldering iron that can meet specifications for use with lead-free solders for repairs accompanied by reworking of soldering.
- Compared with conventional eutectic solders, lead-free solders have higher melting points, by approximately 40 °C.
Therefore, for lead-free soldering, the tip temperature of a soldering iron must be set to around 373 °C in general, although the temperature depends on the heat capacity of the PC board on which reworking is required and the weight of the tip of the soldering iron.

Compared with eutectic solders, lead-free solders have higher bond strengths but slower wetting times and higher melting temperatures (hard to melt/easy to harden).

The following lead-free solders are available as service parts:

- Parts numbers of lead-free solder:
GYP1006 1.0 in dia.
GYP1007 0.6 in dia.
GYP1008 0.3 in dia.

1.2 CHARGED SECTION AND HIGH VOLTAGE GENERATING POINT

Charged Section

The places where the commercial AC power is used without passing through the power supply transformer. If the places are touched, there is a risk of electric shock. In addition, the measuring equipment can be damaged if it is connected to the GND of the charged section and the GND of the non-charged section while connecting the set directly to the commercial AC power supply. Therefore, be sure to connect the set via an insulated transformer and supply the current.

- 1. Power Cord
- 2. AC Inlet
- 3. Power Switch
- 4. Fuse (In the POWER SUPPLY Unit)
- 5. STB Transformer and Converter Transformer (In the POWER SUPPLY Unit)
- 6. Other primary side of the POWER SUPPLY Unit

High Voltage Generating Point

The places where voltage is 100 V or more except for the charged places described above. If the places are touched, there is a risk of electric shock. The VSUS voltage remains for several minutes after the power to the unit is turned off. These places must not be touched until about 10 minutes after the power is turned off, or it is confirmed with a tester that there is no residual VSUS voltage.

If the procedures described in “5.6.1 PANEL DRIVE-POWER ON/OFF FUNCTION” are performed before the power is turned off, the voltage will be discharged in about 30 seconds.

POWER SUPPLY UNIT	(205 V)
50F X DRIVE Assy	(205 V)
50F Y DRIVE Assy	(-270 V to 400 V)
50F SCAN A Assy	(-270 V to 400 V)
50F SCAN B Assy	(-270 V to 400 V)
50F SCAN C Assy	(-270 V to 400 V)
50F SCAN D Assy	(-270 V to 400 V)

- : Part is Charged Section.
- : Part is the High Voltage Generating Points other than the Charged Section.





Fig. High Voltage Generating Point (Rear view)


2. SPECIFICATIONS

2.1 ACCESSORIES

- Remote control unit (AXD1550)




- Alkaline dry cell battery (LR6, AA)



- Binder Assy (AEC1908)

- Speed clamp: ×3
- Bead band: ×3




- Cleaning cloth (AED1285)




- Warranty card



- Operating instructions (PDP-5010FD/KUCXC) (ARE1472)




- Operating instructions (PDP-5010FD/KUC) (ARE1487)




- Band assy (AXY1192)

- Screw: ×2 (M4×10 mm) (for plastic bands)
- Plastic band: ×2




- Power cord (2 m/6.6 feet) (ADG1215)




Speaker accessories

- Speaker cable: ×2 (SDS1202)




- Bracket Assy (S): ×2 (SXC1127)



Brackets for side: ×2

- Bracket Assy (C) (SXC1128)



Brackets for center

- Speaker mounting screw (M5 x 10 mm: Black): ×9 (BMZ50P100FTB)



2.2 SPECIFICATIONS


Item			
Number of pixel			
1920 × 1080 pixels			
Audio Amplifier			
17 W + 17 W (1 kHz, 10 %, 6 Ω)			
Speakers			
Woofer: 4.8 cm x 13 cm cone type Tweeter: 2.5 cm semidome type			
Sound Effect			
SRS FOCUS/SRS/SRS TruBass			
Power Requirement			
120 V AC, 60 Hz, 442 W (26 W Standby)			
Weight			
Main unit: 38.5 kg (84.9 lbs.) Stand: 2.2 kg (4.9 lbs.) (including bolts) Speaker system: 3.3 kg (7.3 lbs.) (including cables, mounting fittings and screws) Total: 44.0 kg (97 lbs.)			
Reception System (Digital)			
ATSC Digital TV system			
Circuit type			
8VSB/64QAM/256QAM/QPSK demodulation			
Tuner			
VHF/UHF			
VHF Ch. 2 to 13 UHF Ch. 14 to 69			
CATV			
Ch. 2 to 135			
Audio format			
Dolby Digital			
Reception System (Analog)			
American TV standard NTSC system			
Circuit type			
Video signal detection PLL full synchronous detection, PLL digital Synthesizer system			
Tuner			
VHF/UHF			
VHF Ch. 2 to 13 UHF Ch. 14 to 69			
CATV			
ANT/CABLE A IN Ch. 1 to 135 ANT B IN Ch. 1 to 125			
Audio multiplex			
BTSC system			
Terminals	Rear	ANT/CABLE A IN	75 Ω UNBAL, F Type for DTV/VHF/UHF/CATV in
		ANT B IN	75 Ω UNBAL, F Type for VHF/UHF/CATV in
		INPUT 1	S-VIDEO in, VIDEO in, AUDIO in
		INPUT 2	COMPONENT VIDEO in, VIDEO in, AUDIO in
		INPUT 4	HDMI in*, AUDIO in
		PC INPUT	Analog RGB in, AUDIO in
		INPUT 5	HDMI in*, AUDIO in
		INPUT 6	HDMI in*
		INPUT 7	HDMI in*
		AUDIO OUT	AUDIO out (Fixed)
		DIGITAL OUT	Optical
		CONTROL OUT	1
		SPEAKERS	6 Ω to 16 Ω
		SUB WOOFER	Variable
	CableCARD	Point of Deployment	
	Side	INPUT 3	COMPONENT VIDEO in, VIDEO in, AUDIO in
		PHONES	16 Ω to 32 Ω recommended
		USB	USB in**
	On-screen display languages		
	English/French/Spanish		

* This conforms to HDMI1.3 and HDCP1.1.
HDMI (High Definition Multimedia Interface) is a digital interface that handles both video and audio using a single cable.
HDCP (High-bandwidth Digital Content Protection) is a technology used to protect copyrighted digital contents that use the Digital Visual Interface (DVI).

** This conforms to USB 1.1 and 2.0 .


• Design and specifications are subject to change without notice.

Dimensions



PDP-5010FD

Front Section



1 button (This button is located on the bottom on the rear panel (see **1** on Rear section). If the button is off, the power will not turn on even when **TV** on the remote control unit or **STANDBY/ON** on the plasma display is pressed. To turn on the power, press .

2 POWER ON indicator

3 STANDBY indicator

4 SLEEP indicator

5 Room Light Sensor

6 Remote control sensor

7 **STANDBY/ON** button

8 **INPUT** button (**ENTER** button*)

9 **VOLUME UP/DOWN** buttons (**UP/DOWN** buttons*)

10 **CHANNEL UP/DOWN** buttons (**LEFT/RIGHT** buttons*)

11 **TV GUIDE** button*

12 USB port

13 PHONES output terminal

14 INPUT 3 terminals (COMPONENT VIDEO: Y, Pb, Pr)

15 INPUT 3 terminal (VIDEO)

16 INPUT 3 terminals (AUDIO)

The buttons with asterisks (*) can operate the TV Guide On Screen™ system.

A

Rear Section


B

C

D

E

F




* For exact terminal positions, refer to the terminal position sheet located near the terminal compartment.

- | | | | |
|----|---|----|--|
| 1 | button | 17 | INPUT 1 terminals (AUDIO) |
| 2 | CableCARD™ slot | 18 | INPUT 2 terminals (AUDIO) |
| 3 | ANT/CABLE A IN terminal | 19 | INPUT 4 terminals (AUDIO) |
| 4 | AC IN terminal | 20 | INPUT 5 terminals (AUDIO) |
| 5 | INPUT 4 terminal (HDMI) | 21 | INPUT 2 terminal (VIDEO) |
| 6 | INPUT 5 terminal (HDMI) | 22 | DIGITAL OUT terminal (OPTICAL) |
| 7 | INPUT 6 terminal (HDMI) | 23 | PC INPUT terminal (AUDIO) |
| 8 | INPUT 7 terminal (HDMI) | 24 | INPUT 2 terminals (COMPONENT VIDEO: Y, Pb, Pr) |
| 9 | PC INPUT terminal (ANALOG RGB) | 25 | SPEAKERS (R/L) terminals |
| 10 | CONTROL OUT terminal | 26 | SPEAKERS (R) terminal (Speaker side) |
| 11 | RS-232C terminal (used for factory setup) | 27 | SPEAKERS (L) terminal (Speaker side) |
| 12 | ANT B IN terminal | | |
| 13 | INPUT 1 terminal (S-VIDEO) | | |
| 14 | INPUT 1 terminal (VIDEO) | | |
| 15 | SUB WOOFER terminal | | |
| 16 | AUDIO OUT terminals (AUDIO) | | |

Remote Control Unit

This section describes the functions of the buttons available when the mode switch has been set to TV.



Mode switch
(with "TV" selected)

- 1 **TV** (⏻): Turns on the power to the plasma display or places it into standby mode.
- 2 **Transmission confirmation LED**
- 3 **INPUT**: Selects an input source of the plasma display. ("INPUT1", "INPUT 2", "INPUT3", "INPUT4", "INPUT5", "INPUT6" and "INPUT 7")
- 4 **SCREEN SIZE**: Selects the screen size.
- 5 **AV SELECTION**: Selects audio and video settings. (AV source: OPTIMUM, STANDARD, DYNAMIC, MOVIE, GAME, USER. PC source: STANDARD, USER.)
- 6 **INFO**: Displays a channel banner when a TV program is being watched. When the TV Guide On Screen™ system is in operation, displays information about the currently highlighted channel (if available).
- 7 **HOME MENU**: Displays the HOME MENU screen. **MENU**: Displays a panel menu when the TV Guide On Screen™ system is in operation.
- 8 **DAY +/-**: Jumps to the next or previous day of program listings in the TV Guide On Screen™ Listing service.
- 9 **⬆/⬇/⬅/➡**: Selects a desired item on the menu screen.
- 10 **HDMI CONTROL**: Displays the HDMI Control menu.
- 11 **FAVORITE CH (A, B, C, D)**: Selects any of the four preset channels. While watching, you can toggle the set channels by pressing A, B, C and D.
- 12 **0 to 9**: Selects the channel.
- 13 **• (dot)**: Enters a dot.
- 14 **CH +/-**: Selects the channel.
- 15 **SPLIT**: Switches the screen mode among 2-screen, picture-in-picture, and single-screen.
- 16 **FREEZE**: Freezes a frame from a moving image. Press again to cancel the function.
- 17 **MTS**: Selects MTS/SAP or language depending on the program being watched.
- 18 **ANT**: Selects the antenna (A, B).
- 19 **PC**: Selects the PC terminal as an input source.
- 20 **DISPLAY**: Displays the channel information.
- 21 **TV GUIDE**: Displays the TV Guide On Screen™ system.
- 22 **ENTER**: Executes a command.
- 23 **PAGE +/-** (for the TV Guide On Screen™ system): Scrolls the program listing screen vertically.
- 24 **RETURN**: Returns to the previous menu screen.
- 25 **CH ENTER**: Executes a channel number.
- 26 **CH RETURN**: Returns to the previous channel. This button is disabled while the TV Guide On Screen™ system is displayed.
- 27 **VOL +/-**: Sets the volume.
- 28 **MUTING**: Mutes the sound.
- 29 **SHIFT**: Moves the location of the small screen when in the picture-in-picture mode.
- 30 **SWAP**: Switches between the two screens when in the 2-screen or picture-in-picture mode.

Luminous remote control buttons

All buttons on the remote control unit are luminous and gather and store light. This enables quick access to the desired function when performing operations in dark places.

Note

- When using the remote control unit, point it at the plasma display.

3. BASIC ITEMS FOR SERVICE

3.1 CHECK POINTS AFTER SERVICING

Items to be checked after repair (PDP)

To ensure the quality of the product after repair, check the recommended items shown below:

No.	Procedures	Item to be checked
1	Check if all the symptoms pointed out by the customer have been addressed.	The symptoms in question must not be reproduced.
2	Connect the peripheral equipment.	Connect all external peripheral equipment as originally connected and check if the connections are correct.
3	Check the video and audio.	Tune in to the stations that the customer would normally receive and check if video and audio are normal.
4	Check the buttons and controls.	Use the buttons and controls on the remote control unit and main unit and check if they operate properly.
5	Check the cabinet.	Check for any scratches or dirt that have been made or attached on the cabinet after receiving the product for repair.

See the table below for the items to be checked regarding video and audio:

Item to be checked regarding video	Item to be checked regarding audio
Block noise	Distortion
Horizontal noise	Noise
Dot noise	Volume too low
Disturbed image (video jumpiness)	Volume too high
Too dark	Volume fluctuating
Too bright	Sound interrupted
Mottled color	

Quick Reference upon Service Visit ①

Notes, PD/SD diagnosis, and methods for various settings

Notes when visiting for service

1. Notes when disassembling/reassembling

① Rear case

When reassembling the rear case, the screws must be tightened in a specific order. Be careful not to tighten them in the wrong order forcibly. For details, see "Rear Case" in "7. DISASSEMBLY".

② Attaching screws for the HDMI connector

When attaching the HDMI connector after replacing the Main Assy, secure the HDMI connector manually with a screwdriver, but not with an electric screwdriver. If you tighten the screws too tightly with an electric screwdriver, the screw heads may be damaged, in which case the screws cannot be untightened/tightened any more.

2. On parts replacement

① How to discharge before replacing the Assys

A charge of significant voltage remains in the Plasma Panel even after the power is turned off. Safely discharge the panel before replacement of parts, in either manner indicated below:

A: Let the panel sit at least for 3 minutes after the power is turned off.
B: Turn the Large Signal System off before the power is turned off then, after 1 minute, turn the power off.

For details, see "5.6.1 PANEL DRIVE-POWER ON/OFF FUNCTION".

② On the settings after replacement of the Assys






Some boards need settings made after replacement of the Assys. For details, see "8. EACH SETTING AND ADJUSTMENT".

3. On various settings

① Setting in Factory mode

After a Mask indication into the panel is performed, be sure to set the Mask setting to "OFF" then exit Factory mode.

PD/SD			
Item		No. of LEDs flashing	
		Red	Blue
Panel section	SQ_LSI		Blue 1
	Communication with the module IIC		Blue 2
	DIGITAL-RST2		Blue 3
	Panel high temperature		Blue 4
MTB section	Audio/ Short-circuit SP terminal		Blue 5
	Communication with the Module UCOM		Blue 6
	Main 3-wire serial communication		Blue 7
	Main IIC communication		Blue 8
	Communication with the Main UCOM		Blue 9
	FAN		Blue 10
	Unit high temperature		Blue 11
	Digital Tuner communication		Blue 12
	MTB-RST2/RST4		Blue 13
	Home Media Gallery		Blue 14
	Main EEPROM		Blue 15
POWER		Red 2	
SCAN		Red 3	
SCN-5V		Red 4	
Y-DRIVE		Red 5	
Y-DCDC		Red 6	
Y-SUS		Red 7	
ADRS		Red 8	
X-DRIVE		Red 9	
X-DCDC		Red 10	
X-SUS		Red 11	
DIG-DCDC		Red 12	
UNKNOWN		Red 15	

LED Display Information	
① TRAP SW	
② Rewriting software	
③ PD (2-15)	
④ SD (1-15)	
⑤ No backup	
This indication does not display all LED patterns. For details, please refer to 5.1.1 LED DISPLAY INFORMATION.	

How to locate several items on the Factory menu

{ } : Item on the Factory menu
[] : Key on the remote control unit
" " : Screen indication

1. Confirmation of accumulated power-on time and power-on count

Select {INFORMATION} then {HOUR METER}.
(After entering Factory mode, press [↓] five times.)

2. Confirmation of the Power-down and Shutdown histories

① Panel system

PD: Select {PANEL FACTORY} then {POWER DOWN}.
(After entering Factory mode, press [MUTING] once, press [ENTER/SET], then press [↓] three times.)

SD: Select {PANEL FACTORY} then {SHUT DOWN}.
(After entering Factory mode, press [MUTING] once, press [ENTER/SET], then press [↓] four times.)

② MTB section

Select {INFORMATION} then {MAIN NG}.
(After entering Factory mode, press [↓] three times.)

3. How to display the Mask indication

① Mask indication in the panel side

- Select {PANEL FACTORY} then {RASTER MASK SETUP}.
(After entering Factory mode, press [MUTING] once, press [ENTER/SET], then press [↓] 8 times.)
- Press [ENTER/SET], then select a Mask indication, using [↑] or [↓].

Adjustments and Settings after replacement of the Assys (Procedures in Factory mode)

1. Digital Video Assy: Transfer of backup data

- Select {PANEL FACTORY}, {ETC}, then {BACKUP DATA}. (After entering Factory mode, press [MUTING] once, press [ENTER/SET], press [↓] seven times, then press [ENTER/SET].)
- Select {TRANSFER}, using [→], then hold [ENTER/SET] pressed for at least 5 seconds.
- After transfer of backup data is completed, {ETC} is automatically selected, and the LED on the front panel returns to normal lighting.

2. MAIN Assy: Execution of FINAL SETUP.

- Select {INITIALIZE} then {FINAL SETUP}, then press [ENTER/SET]. (After entering Factory mode, press [MUTING] three times, then press [↓] four times.)
- Select "YES", using [→]. Then hold [ENTER/SET] pressed for at least 5 seconds.
- After "FINAL SETUP IS COMPLETE" is displayed on the screen, turn the POWER switch of the main unit off.

3. POWER SUPPLY Unit: Clearance of the accumulated power-on count and maximum temperature value

- Select {PANEL FACTORY}, {ETC}, then {P COUNT INFO}. (After entering Factory mode, press [MUTING] once, press [ENTER/SET], press [↓] seven times, press [ENTER/SET], then press [↓] six times.)
- Press [→] to select "CLEAR". Hold [ENTER/SET] pressed for at least 5 seconds. After clearance is completed, "ETC" is automatically selected. Clear the maximum temperature value (MAX TEMP) in the same manner.


4. Other Assys: Clearance of the maximum temperature value

- Select {PANEL FACTORY}, {ETC}, then {MAX TEMP}. (After entering Factory mode, press [MUTING] once, press [ENTER], press [↓] seven times, press [ENTER/SET], then press [↓] seven times.)
- Press [→] to select "CLEAR". Hold [ENTER/SET] pressed for at least 5 seconds. After clearance is completed, "ETC" is automatically selected.

Quick Reference upon Service Visit ②

Mode transition and structure of layers in Service Factory mode

Mode transition in Service Factory mode



Structure of Layers in Service Factory Mode

INFORMATION mode	
1. VERSION (1)	The software versions for each microcomputer
2. VERSION (2)	The Flash memory versions for each device
3. VERSION (3)	The Flash memory versions for each device
4. MAIN NG	The shutdown message ID/event times (Going Clear mode by [ENTER/SET] key)
4-1. CLEAR	Select Yes by [→] key → pushing and hold [ENTER/SET] key
5. TEMPERATURE	The temperature/FAN rotating status/Room Light Sensor
6. HOUR METER	The HOUR METER/P-COUNT information
6-1. CLEAR	Select Yes by [→] key → pushing and hold [ENTER/SET] key
7. HDMI SIGNAL INFO 1	The information of HDMI information files
8. HDMI SIGNAL INFO 2	The information of HDMI information files
9. VDEC SIGNAL INFO 1	The signal information of VDEC
10. VDEC SIGNAL INFO 2	The signal information of VDEC
11. DTV TUNING STATUS 1	Detail information for DTV
12. DTV TUNING STATUS 2	Detail information for DTV
13. DTV TUNING STATUS 3	Detail information for DTV
14. DTV TV-GUIDE BER	For production line use
15. DEBUG INFO	For factory use
PANEL FACTORY mode	Refer to [PANEL FACTORY MODE]
OPTION mode	
1. EDID WRITE MODE	For factory use
2. ANTENNA MODE	For production line use
3. AFT	For production line use
4. SYNC DET	For technical analysis
INITIALIZE mode	
1. SIDE MASK LEVEL	For factory use
1-1. SIDE MASK LEVEL	
2. FINAL SETUP	Set to Factory default settings (it should perform after replacing a MAIN Assy)
2-1. DATA RESET	Information for a USB device is displayed
3. HMG/HG SERVICE MODE	
3-1. MODE SHIFT	
4. Wide XGA AUTO	For technical analysis

Structure of Layers in Panel Factory Mode 1

1. PANEL INFORMATION	Version indication of the panel
2. PANEL WORKS	Indications of the accumulated power-on time, pulse-meter count, and power-on count of the panel
3. POWER DOWN	Indication of the Power-down history
4. SHUT DOWN	Indication of the Shutdown history
5. PANEL-1 ADJ (+)	
1. VOL SUS	Settings required after replacement of the panel
2. VOL OFFSET	
...	
8. VOL YNOFS4	
9. RESET1ST_KSB	Modification not required because these items are basically for factory presetting
10. RESET2ND_KSB	
...	
23. YSTL_FMR_HZ	
24. SUS FREQ	For AM noise prevention (Depending on the mode, brightness of the screen changes.) For confirmation of the result of the setting change, the unit must be turned off then back on again.
6. PANEL-2 ADJ (+)	
1. R-HIGH	Parameters for the WB adjustment of the panel, which are required during adjustment after panel replacement
2. G-HIGH	
3. B-HIGH	
4. R-LOW	
5. G-LOW	
6. B-LOW	
7. ABL	Setting of the power consumption. A setting table is available for each vertical signal.

To "Structure of Layers in Panel Factory Mode 2"

Structure of Layers in Panel Factory Mode 2

7. PANEL FUNCTION (+)	
1. R-LEVEL	Items for use by engineers
2. G-LEVEL	
3. B-LEVEL	
4. ADDRESS L1	
5. ADDRESS L2	
...	
11. ADDRESS U4	
12. STK MODE	
8. ETC (+)	
1. BACKUP DATA	For transferring backup data (after replacement of the DIGITAL Assy)
2. DIGITAL EEPROM	To clear data of the digital video
3. PD INFO.	For clearance of data for the corresponding items. The clearing method is the same: Select "CLEAR", using [→], then hold [ENTER/SET] pressed for at least 5 seconds. After clearance is completed, (ETC) is automatically selected.
4. SD INFO.	
5. HR-MTR INFO.	
6. PM/B1-B5	
7. P COUNT INFO.	
8. MAX TEMP.	
9. RASTER MASK SETUP (+)	
1. MASK OFF	For use while Raster Mask (full mask) is displayed. Use [↑] or [↓] to select the type of mask.
2. RST MASK 01	
...	
26. RST MASK 25	
10. PATTEN MASK SETUP (+)	
1. MASK OFF	For use while Pattern Mask is displayed. Use [↑] or [↓] to select the type of mask.
2. PTN MASK 01	
...	
50. PTN MASK 49	
11. COMBI MASK SETUP (+)	
1. MASK OFF	For use while Combination Mask is displayed. Use [↑] or [↓] to select the type of mask.
2. CMB MASK 01	
...	
18. CMB MASK 17	

A

The wiring shown in the photo is different from the actual wiring, because the product in the photo is a prototype. Upon servicing, be sure to restore the original wiring of the unit after repair work.

E

3.4 JIGS LIST

A

Name	Jig No.	Remarks
Service Cotton Cloth Glove	GYX1002	7.3 DISASSEMBLY AND REASSEMBLY PRECAUTIONS FOR SPEAKER SYSTEM

B

C

3.5 CLEANING



D

Name	Part No.	Remarks
Cleaning liquid	GEM1004	Used to fan cleaning. Refer to “10.4 CHASSIS SECTION (1/2)”.
Cleaning paper	GED-008	

E

F



5



6



7



8



A



B



C



D



E



F



5



6




7




8









- When ordering service parts, be sure to refer to "EXPLODED VIEWS and PARTS LIST" or "PCB PARTS LIST".
- The  mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.

OVERALL DIAGRAM
PDP-5010FD

4.2 OVERALL WIRING DIAGRAM (2/2)





CONNECTOR PIN ASSIGN


1-50. GND	26-25. GND
2-49. TEMP2	27-24. INPUT2_V
3-48. NC	28-23. GND
4-47. V+3_3V_UCOM	29-22. INPUT1_V
5-46. GND	30-21. GND
6-45. GND	31-20. INPUT1_SY
7-44. GND	32-19. GND
8-43. GND	33-18. INPUT1_S2
9-42. GND	34-17. GND
10-41. GND	35-16. INPUT1_SC
11-40. GND	36-15. GND
12-39. GND	37-14. INPUT1_PLUG
13-38. INPUT3_PLUG	38-13. GND
14-37. GND	39-12. INPUT2_PLUG
15-36. INPUT3_V	40-11. GND
16-35. GND	41-10. INPUT2_V
17-34. INPUT3_PB	42-9. GND
18-33. GND	43-8. GND
19-32. INPUT3_PR	44-7. GND
20-31. GND	45-6. INPUT2_PR
21-30. AIR_R	46-5. GND
22-29. GND	47-4. GND
23-28. AIR_L	48-3. GND
24-27. GND	49-2. GND
25-26. INPUT3_V	50-1. GND

1-40. V+5V_A	21-20. I2S_SDATA_HNM
2-39. NC	22-19. I2S_BCLK_HNM
3-38. V+3_3V_STB	23-18. I2S_LRCLK_HNM
4-37. NC	24-17. GND
5-36. GND	25-16. I2S_SDATA_HDMI
6-35. GND	26-15. I2S_BCLK_HDMI
7-34. GND	27-14. I2S_LRCLK_HDMI
8-33. GND	28-13. GND
9-32. I2S_OUT	29-12. I2S_SDATA_DTV
10-31. GND	30-11. I2S_BCLK_DTV
11-30. GND	31-10. I2S_LRCLK_DTV
12-29. AC_AM_MUTE	32-9. GND
13-28. GND	33-8. SDA
14-27. AC_HP_MUTE	34-7. SDA_AV
15-26. HP_PLUG	35-6. AC_A_MUTE
16-25. GND	36-5. RST_MSP
17-24. SPDIF_HNM	37-4. GND
18-23. GND	38-3. A_NG_B
19-22. SPDIF_DTV	39-2. I2S_DET
20-21. GND	40-1. GND

1-40. GND	21-20. WAITA
2-39. POD_VCC	22-19. OOB_EN/MA4
3-38. POD_VCC	23-18. RST_A
4-37. POD_VCC	24-17. TX_1
5-36. MDIA3	25-16. POD_VS2
6-35. MDIA3	26-15. TX_EN
7-34. MDIA2	27-14. MDIA7
8-33. WE	28-13. TX_Q
9-32. MDIA1	29-12. MDIA6
10-31. GND	30-11. MDIA5
11-30. MOCCLKA/MA14	31-10. MDIA5
12-29. GND	32-9. MD6
13-28. MDIA0	33-8. MD0A4
14-27. MDIA3	34-7. MD1A4
15-26. MISTRTA	35-6. MD0A3
16-25. GND	36-5. MD4
17-24. POD_CLK/MA8	37-4. CD1A
18-23. GND	38-3. MD7
19-22. IOWR	39-2. GND
20-21. POD_DATA/MA9	40-1. GND

1-40. GND	21-20. WAITA
2-39. PTXDB	22-19. OOB_EN/MA4
3-38. GND	23-18. RST_A
4-37. PRXDB	24-17. TX_1
5-36. GND	25-16. POD_VS2
6-35. CDIA2	26-15. TX_EN
7-34. MD0A2	27-14. MDIA7
8-33. MD2	28-13. TX_Q
9-32. MD0A1	29-12. MDIA6
10-31. MD1	30-11. MDIA5
11-30. MD0A0	31-10. MDIA5
12-29. MD0	32-9. GND
13-28. M0STRTA	33-8. M1CLKA
14-27. MA0A	34-7. GND
15-26. M0VALA	35-6. MD1A4
16-25. MA1	36-5. M1VALA
17-24. REG	37-4. POD_VPP
18-23. MA2	38-3. POD_VPP
19-22. GND	39-2. GND
20-21. MA3	40-1. GND

※1	PDP-5010FD	AWV2472-
----	------------	----------


The  mark found on some component parts should be replaced with same parts (safety regulation authorized) of identical designation.

OVERALL DIAGRAM
PDP-5010FD


4



4.4 OVERALL BLOCK DIAGRAM (2/2)



- : Analog Audio signal
- : Analog Video signal
- ===== : Component signal
- : Digital Video signal
- : Digital Audio signal
- : Synchronized signal
- ===== : Data signal
- : Control signal
- : RF signal




4

A



4.6 50F X DRIVE ASSY

50F X DRIVE ASSY





4

F

50F SCAN A ASSY (HIGH-SIDE_HIGH)




4.8 POWER SUPPLY BLOCK of 50F X, Y DRIVE and 50F SCAN A, B, C and D ASSYS




Note:
VYPRST, VSNOFS, VYKOF512, VYKOF53, VYKOF54
VXKOF51 and VXKOF52 voltages are electrical volume controls.

4.9 50F ADDRESS L and S ASSYS


50F ADDRESS L ASSY



50F ADDRESS S ASSY



4.10 50F DIGITAL ASSY



4.11 MAIN ASSY (DTV BLOCK DIAGRAM)

A


B

C

D

E

F



■

5

■

6

■

7

■

8

■

A

■

B

■

C

■

D

■

E

■

F

■

5

■

6

■

7

■

8

■

4.12 POWER SUPPLY BLOCK of MAIN ASSY

A


B


C

D

E


F






4.13 TANSHI ASSY

TANSHI ASSY




4.14 50FHD LED and FHD IR ASSYS



1 2 3 4

4.15 POWER SUPPLY BLOCK of FHD RLS and SIDE KEY ASSYS



5. DIAGNOSIS

5.1 POWER SUPPLY OPERATION


5.1.1 LED DISPLAY INFORMATION

LED Pattern



State	LED	LED Pattern / Remarks				
AC OFF or Main power switch OFF	Blue	Lightins out				
	Red	Lightins out				
	Orange	Lightins out				
Standby power management	Blue	Lightins out				
	Red	Always lighting				
	Orange	Lightins out				
Power ON	Blue	Always lighting				
	Red	Lightins out				
	Orange	Lightins out				
Power-down	Blue	Once	Twice	n times	Once	
	Red	500 mS			2.5 S	
	Orange	Lightins out				
Shutdown	Blue	500 mS			2.5 S	
	Red	Once	Twice	n times	Once	
	Orange	Lightins out				
No digital adjustment data copied for backup	Blue	200 mS				
	Red	Always lighting				
	Orange	Lightins out				
In the process of rewriting the program of the microcomputer	Blue	100 mS				
	Red	100 mS				
	Orange	Lightins out				
During factory operation	Blue					
	Red					
	Orange					
During DTV Module software downloading	Blue	100 mS				
	Red	100 mS				
	Orange					
Downloading of DTV Module software is finished normally.	Blue					
	Red	500 mS	500 mS	500 mS	500 mS	500 mS
	Orange					
Downloading of DTV Module software is abnormally finished.	Blue					
	Red					
	Orange	500 mS	500 mS	500 mS	500 mS	500 mS
Trap switch	Blue	Always lighting				
	Red	Always lighting				
	Orange	Lightins out				


5.1.2 POWER ON SEQUENCE



- ① : The remote control (or KEY) signal is input to the IF microcomputer.
- ② : The IF microcomputer sends the operation data of the remote control unit (or KEY) to the main microcomputer.
- ③ : The main microcomputer issues a startup command (PON) to the MOD microcomputer.
- ④ : The relay is controlled with logical OR interpretation of control signals by the main microcomputer and module (MOD) microcomputer.



Power supply status - Main switch off




F

4

5.2 DIAGNOSIS FLOWCHART OF FAILURE ANALYSIS

5.2.1 WHOLE UNIT

Flowchart of Failure Analysis for The Whole Unit




A


A

In the subsequent diagnostic steps, it is most likely that the multi base section is in failure.

Problems concerning video display




B



Problems concerning the audio output

C




D

E

F


5.2.2 POWER SUPPLY UNIT

Flowchart of Failure Analysis for The POWER SUPPLY Unit



A


Flowchart of Failure Analysis for The Drive Assy



D

E

F



A


B

C


D



E

F




Ⓒ ADDRESS Assy






A

Flowchart of Failure Analysis for The DIGITAL Assy




Flowchart of Failure Analysis for The MAIN Assy




5.2.6 VIDEO SYSTEM

Flowchart of Failure Analysis for The Video System




Flowchart of Failure Analysis for The Video System

No video from Composite or S-VIDEO




● Waveforms

Input signal: Color-bar



A

No video from TV signal


D


● Waveforms

Input signal: Color-bar

E


F






• Waveforms

Input signal: Color-bar




A




D

● Waveforms


Input signal: Color-bar



F





No video from USB input



5.2.7 AUDIO SYSTEM


Flowchart of Failure Analysis for The Audio System






• Waveforms


Input signal: L/R 1 kHz, 0.5 Vrms (VOL 30)




A




B




C



D




E



Waveforms

Input signal: L/R 1 kHz, 0.5 Vrms (VOL 30)




F

5.3 DIAGNOSIS OF PD (POWER-DOWN)

5.3.1 BLOCK DIAGRAM OF THE POWER-DOWN SIGNAL

■ Block Diagram of the Power-Down Signal



5.3.2 PD (POWER-DOWN) DIAGNOSIS OF FAILURE ANALYSIS

Prediction of failure symptoms when a PD (power-down) is generated


Red LED Flashing Count	Operating PD	Defective Assy	PD Outline	Checkpoint	Possible Defective Part	Remarks
2	POWER	POWER SUPPLY Unit	Failure in the POWER SUPPLY Unit			
		X DRIVE Assy	VSUS UVP	X SUS BLOCK	Q1219 to Q1224	VSUS-SUSOUT and SUSOUT-SUSGND are short-circuited.
		Y DRIVE Assy		Y SUS BLOCK	Q2217 to Q2224	VSUS-SUSOUT and SUSOUT-SUSGND are short-circuited.
3	SCAN	SCAN Assy	VH UVP	SCAN IC	SCAN IC	
		X DRIVE Assy		X SUS BLOCK	Q1218 to Q1224,Q1226	VSUS-SUSOUT and SUSOUT-SUSGND are short-circuited.
		Y DRIVE Assy		Y SUS BLOCK	Q2217 to Q2224	VSUS-SUSOUT and SUSOUT-SUSGND are short-circuited.
				VH DC/DC converter	IC2601,IC2603,D2604	
		DIGITAL Assy	Connectors disconnection detection	CN2001,CN2301		
4	SCN-5V	SCAN Assy	Connectors disconnection detection	CN2801,CN2901,CN2902,CN3001,CN3002,CN3101		
		Y DRIVE Assy	IC5V UVP	SCAN IC	SCAN IC	
			IC5V DC/DC	Q2764,D2768,R2764		
6	Y-DCDC	Y DRIVE Assy	VNOFS UVP	Y MSK BLOCK	Q2320 to Q2325,Q2330,Q2332,Q2334	LMSK is short-circuited.
				VNOFS DC/DC	D2606,Q2709,Q2710	
			Vprst UVP	YPRST Regulator	Q2604,Q2605,IC2602	
			15VDD UVP	15VDC/DC	Q2662,R2669	
			VKOFS1_2 UVP	Y MSK BLOCK	Q2320 to Q2325,Q2330,Q2332,Q2334	LMSK is short-circuited.
				VKOFS1_2 Regulator	Q2705,Q2702	
			VKOFS3 UVP	Y MSK BLOCK	Q2320 to Q2325,Q2330,Q2332,Q2334	LMSK is short-circuited.
				VKOFS3 Regulator	Q2706,Q2703	
			VKOFS4 UVP	Y MSK BLOCK	Q2320 to Q2325,Q2330,Q2332,Q2334	LMSK is short-circuited.
				VKOFS4 Regulator	Q2707,Q2704	
7	Y-SUS	Y DRIVE Assy	Center electric potential detection PD	Y RESONANCE BLOCK	Q2106 to Q2109,Q2111,Q2113,D2104 to D2107	
8	ADRS	ADDRESS Assy	VADR UVP	ADDRESS RESONACE BLOCK		
			VADR UVP	TCP		
		DIGITAL Assy	Connectors disconnection detection	CN1601,CN1602,CN1801,CN1802		
		X DRIVE Assy		CN3501 to CN3508		
		Y DRIVE Assy		CN1202 to CN1206		
9	XDRIVE	X DRIVE Assy	Connectors disconnection detection	CN1001		
		DIGITAL Assy		CN3510		
10	X-DCDC	X DRIVE Assy	Connectors disconnection detection	CN1201		
			15VDD UVP	X SUS BLOCK	L1201,R1217	
				15VDC/DC	Q1402	
			VXKOFS1 UVP	VXKOFS1 Regulator	Q1405,Q1406	
				X OFFSET BLOCK	Q1302,Q1304	
			VXKOFS2 UVP	VXKOFS2 Regulator	Q1403,Q1404	
				X OFFSET BLOCK	Q1301,Q1303	
11	X-SUS	X DRIVE Assy	Center electric potential detection PD	X RESONANCE BLOCK	Q1108,Q1116,Q1112,Q1119	
12	DIG-DCDC	DIGITAL Assy	3.3V, 2.5V, 1.1V UVP, OVP, OCP	Abnormality in the DC-DC converter control IC	IC3801	
				Periphery of the DC-DC converter	Q3841, Q3861, Q3881 L3841, L3861, L3881 R3820, R3848, R3868, R3888	
			5.1V OCP	Abnormality in 5.1V input (include abnormality in the protection fuse)	FU3801	
15	UNKNOWN	POWER SUPPLY Unit	Connectors disconnection detection	P4		EXT_PD line: Open
		DIGITAL Assy	Connectors disconnection detection	CN3801		EXT_PD line: Open
			ModuleUcom can not detection	Each PD line of ModuleUcom		It becomes "UNKNOWN" except above-mentioned PD detection condition.

UVP: Under Voltage Protect , OVP: Over Voltage Protect


How to distinguish which connector is disconnected

Assy	Connector	To which Assy the Connector is Connected	LED Flashing Count	Screen Display
X DRIVE Assy	CN1001	DIGITAL Assy	5 (XDRIVE)	
	CN1201	POWER SUPPLY Unit (drive system power)		Black screen
	CN1202	POWER SUPPLY Unit (ADR system power)	8 (ADRS)	
	CN1203	ADDRESS Assy	8 (ADRS)	
Y DRIVE Assy	CN2001	DIGITAL Assy	3 (SCAN)	
	CN2301	POWER SUPPLY Unit (drive system power)	3 (SCAN)	
	CN2302	POWER SUPPLY Unit (ADR system power)	8 (ADR)	
	CN2303 to CN2306	ADDRESS Assy	8 (ADR)	
	CN2501, CN2502	SCAN A, B, C, D Assy	4 (SCN-5V)	
SCAN A, B, C, D Assy	CN2901, CN3001	Y DRIVE Assy	4 (SCN-5V)	
	CN2801, CN2902 CN3002, CN3101	SCAN A, B, C, D Assy		
ADDRESS Assy	CN1602, CN1802	DIGITAL Assy	8 (ADRS)	
	CN1601, CN1801	X DRIVE Assy, Y DRIVE Assy	8 (ADRS)	


A

X Drive PD system

B




C


Y Drive PD system

D

E




F



5.4 DIAGNOSIS OF SD (SHUTDOWN)

5.4.1 BLOCK DIAGRAM OF THE SHUTDOWN SIGNAL

■ Block Diagram of the Shutdown Signal



5.4.2 SD (SHUTDOWN) DIAGNOSIS

Frequency of LED Flashing	Major Type	Detailed Type	Log Indication in Factory Mode		Checkpoint	Possible Defective Part	Remarks
			MAIN	SUB			
Blue 1	Abnormality in the Sequence LSI	Communication error		RTRY	CLK_SQ/TXD_SQ, etc.	IC3301, IC3601	SQ_IC communication not established. IC3301 may not have properly started up.
		Drive stop		SONO	Check if the video sync signal is input to IC3301.	CN3201, IC3202, IC3301	A shutdown occurs if IC3301 has not properly started up (a communication failure between IC3301 and IC3302 [FASH]).
		Busy		BUSY	BUSY_SQ	IC3301, IC3601	If BUSY_SQ remains high, a shutdown is generated.
		Incoherent version (hardware, software)		VER-HS	Check the model number of the DIGITAL Assy and the destination of the sequence LSI.	IC3302, IC3601	The written SEQ_PROG is incoherent with data on the DIGITAL Assy.
Blue 2	Failure in IIC communication with the module microcomputer	Incoherent version (memory, software)		VER-MS	Check the model number of the DIGITAL Assy and the destination of the sequence LSI.	IC3302, IC3601, IC3602	A shutdown occurs if the SEQ_PROG that has been stored in backup memory does not coincide with the actual SEQ_PROG.
		DIGITAL Assy EEPROM		EEPROM	IIC communication line of IC3602	IC3602, IC3601	Check the pull-up resistor of the IIC control line and the power to the corresponding IC.
		PANEL SENSOR Assy EEPROM		BACKUP	IIC communication line of IC3902	PANEL SENSOR Assy (IC3902), IC3901	Check the pull-up resistor of the IIC control line and the power to the corresponding IC.
		DAC1		DAC1	IIC communication line of IC3605	IC3605, IC3601	Check the pull-up resistor of the IIC control line and the power to the corresponding IC.
Blue 3	Abnormality in RST2 power decrease			DAC2	IIC communication line of IC3606	IC3606, IC3601	Check the pull-up resistor of the IIC control line and the power to the corresponding IC.
					Is the output voltage (3.3 V) of the DC-DC converter low?	TP3881, TP3882	If RST2 does not become high after the unit is turned on, a shutdown will be generated in several seconds.
Blue 4	Abnormality in panel temperature				The 5.1 V power is not output.	POWER SUPPLY Unit (IC3801)	If TEMP1 that is read by the module microcomputer is 85 °C or higher, a shutdown will be generated.
					High temperature abnormality in the panel temperature sensor	PANEL SENSOR Assy (IC3901)	A shutdown occurs if the reading of TEMP1 detected by the module microcomputer is -20 °C or less. Also check the connection with the PANEL SENSOR Assy.
Blue 5	Short-circuiting of the speakers / D-AMP temperature abnormality				Low temperature abnormality in the panel temperature sensor	PANEL SENSOR Assy (IC3901)	Check if any speaker cable is in contact with the chassis.
					Speaker terminals	JA9301	Check if the AMP output is short-circuited.
Blue 6	Failure in communication with the module microcomputer				AUDIO_AMP	IC9201, IC9101	Check if cables are firmly connected.
					Periphery of the cable between IO3 and M8, and IO6 and P5	CN8803, CN4001, CN8806, P5	Check if the communication lines (TXD_MOD/RXD_MOD/REQ_MOD).
Blue 7	Failure in main microcomputer 3-wire serial communication				Communication line between MAIN and MOD	IC3151, IC8401	Check if cables are firmly connected.
					Periphery of the cable between D11 and M1	CN3001, CN4101	Check the communication lines (TXD_IF/RXD_IF/CLK_IF/BUSY_F/CE_IF/REQ_IF).
Blue 8	Failure in IIC communication with the main microcomputer				Communication line between IF and MAIN	IC8301, IC8401	Check the communication lines (TXD_C3/RXD_IC3).
					Communication line between MULTI and MAIN	IC8001, IC8401	Check the communication lines (SCL_TU/SDA_TU or SCL_AV5/SDA_AV5).
					IIC communication line between Tuner (ANT-F) and MAIN	U6101, IC8401	Check the communication lines (SCL_AV/SDA_AV).
					IIC communication line between MSP/MAP and MAIN	IC9101, IC8401	Check the communication lines (SCL_AV5/SDA_AV5).
					IIC communication line between AV-SW and MAIN	IC4601, IC8401	Check the communication lines (SCL_AV5/SDA_AV5).
					IIC communication line between RGB-SW and MAIN	IC4701, IC8401	Check the communication lines (SCL_MB/SDA_MB).
					IIC communication line between V-DEC and MAIN	IC4801, IC8401	Check the communication lines (SDRAM).
					IIC communication line between VDEC and SDRAM	IC4801, IC8402	Check the communication lines (SCL_MB/SDA_MB).
					IIC communication line between ADC and MAIN	IC5001, IC8401	Check the communication lines (SCL_AV/SDA_AV).
					IIC communication line between HDMI_RX and MAIN	IC5201, IC8401	Check the communication lines (SCL_AV5/SDA_AV5).
Blue 9	Failure in communication with the main microcomputer				IIC communication line between Tuner (ANT-B) and MAIN	U6001, IC8401	Check the communication lines (SCL_AV5/SDA_AV5).
					IIC communication line between US_MSP and MAIN	IC6001, IC8401	Check the communication lines (TXD_IF/RXD_IF/CLK_IF/BUSY_F/CE_IF/REQ_IF).
Blue 10	FAN NG				Communication line between IF and MAIN	IC8301, IC8401	Check the fan. (SD10 does not detect it at the temperature that a fan does not turn.)
					Dirt attached to the fan motor	-	Check if cables are firmly connected.
					Periphery of the cable between FAN and M4	CN4103	Check that the voltage outputs it.
					Periphery of the fan control regulator	IC4310	Check the fan. (SD10 does not detect it at the temperature that fans do not turn.)
Blue 10	FAN NG				Dirt attached to the fan motor	-	FAN NG
					Periphery of the FHD FAN CONNECT	FHD FAN CONNECT Assy	Check if cables are firmly connected.
					Periphery of the cable between FA1 and M5, FAN and M4, and P42 and P45	CN9551 to CN9555, CN4108	Check that the voltage outputs it.
					Periphery of the fan control regulator	IC4303	

Frequency of LED Flashing	Major Type	Detailed Type	Log Indication in Factory Mode		Checkpoint	Possible Defective Part	Remarks
			MAIN	SUB			
Blue 11	High temperature of the unit	—	TEMP2	—	Temperature sensor or its periphery Periphery of the temperature sensor	TH9091 —	TEMP2 A shutdown occurs because of high temperature. TEMP2
		DTV startup error DTV communication error BCM7038 is abnormal Tuner1 or Tuner2 Card I/F IC		PS/RST RETRY DE-BCM DE-FE DE-CAS	Periphery of the cable between IO4 and M6 Startup of BCM7038 Communication line between BCM7038 and MAIN Periphery of BCM7038 Front-end block (ANT-A)	— CN8804, CN4004 IC8401 IC6401 IC6401, U6101 IC7302, IC6401, POD Assy	Check if cables are firmly connected. Check the startup of the BCM7038 and the communication line with MAIN. Check the startup of the BCM7038 and the communication line with MAIN. Check the BCM7038 and its periphery device Check the BCM7038 and its periphery device
Blue 12	Digital Tuner	VBI Slicer EEPROM	DTUNER	DE-VBI DE-EP1	Periphery of VBI slicer	IC7001 IC6903, IC6401	Check the BCM7038 and its periphery device Check the BCM7038 and its periphery device
		TV Guide		TV-G	TV-GUIDE function (Data from broadcast wave)	—	Check the BCM7038 and its periphery device
		Home Gallery Middleware		HOME-G DTV MID	HNM circuit DTV middleware	IC6401, ANW2497 —	Check the BCM7038 and its periphery device
		Application		DTV APP	DTV application	—	Check the BCM7038 and its periphery device
		DC-DC Converter power decrease		M-DCDC	DC-DC converter or its periphery, RST2 EMG_USB	IC4403, Q4404 IC4309, Q4304	Check if V + 3.3 V_D4 is started. Check if the voltage at a waveform check point is 5 V.
Blue 13	Failure in the power supply	POWER SUPPLY	RST-MA	RELAY	The 12 V power is not output, RST4	POWER SUPPLY Unit	Check if V + 12 V is started.
					The 6.5 V power is not output	POWER SUPPLY Unit	Check if V + 6.5 V is started.
					The 5.1 V power is not output	POWER SUPPLY Unit	Check if V + 5.1 V is started.
Blue 14	Home Media Gallery	HMG startup error	HMG	START	EMG_DDC	DC-DC converter CN4105	Check if the DC-DC converter is overloaded. Check if cables are firmly connected.
					Periphery of the cable between P8 and M3 Periphery of connector	CN4111	Check if cables are firmly connected.
Blue 15	Main EEPROM	Main EEPROM communication error	MA-EEP	—	HNM power supply	IC4309, Q4304	Check if the voltage at a waveform check point is 5 V.
					IIC communication line between EEPROM and MAIN	IC8404, IC8401	Check the communication lines (SCL_EP/SDA_EP).

1234

5.5 NON-FAILURE INFORMATION

5.5.1 INFORMATION ON SYMPTOMS THAT DO NOT CONSTITUTE FAILURE

A

Information on symptoms that do not constitute failure

Symptom	Cause, item to check, information
HDMI: Symptoms concerning the input format and settings	
The picture color for an INPUT 4 to 7 signal is not correct.	The color setting for INPUT 4 to 7 is not compatible with that of the output equipment. Check whether the color setting is YPbPr or RGB.
The video signal to INPUT 4 to 7 is not displayed, and a message is displayed.	A unsupported video signal is input.
The audio signal input to the INPUT 4 to 5 is not output. No HDMI signal is input.	The audio setting for INPUT 4 to 5 is any setting and a video signal is not input. If the audio setting is any setting to output an analog audio signal, the HDMI signal must be input. (If a DVI device is to be connected, use a DVI-HDMI conversion cable.) If the HDMI video signal is not input, the analog audio signal is not output.
No sound of signals to INPUT 4 to 7 is output.	The setting on the side of the HDMI output equipment is wrong. Example: Dolby Digital
The 1080p input signal is not displayed properly or at all, although the 1080i input signal is displayed properly.	Check that the connected cable supports HDMI Category 2. (As the clock frequency for the 1080p signal is triple that for the 1080i signal, signal degradation caused by a cable must not be neglected. A cable supporting HDMI Category 2 can be used for the 1080p signal. Although some conventional cables can support the 1080p signal, some others cannot.)
DIGITAL OUT	
Playback of the signal from the DIGITAL audio output connector is possible, but recording is not possible.	The video signal output from the DIGITAL connector is copy-protected.
Miscellaneous	
The no-signal off function is not activated.	The no-signal off and no-operation off functions are effective only if video (composite, S video, component, HDMI [excluding PC]) input or TV input is selected.
The no-operation off function is not activated.	
Power management does not function.	Power Management is effective only while an analog PC signal is being input. It is not effective with HDMI-PC signal input.
The AUTO SETUP function is not activated.	The Auto Setup function is effective only while an analog PC signal is being input. This function does not work if an analog PC signal is not input, even if the INPUT PC is selected.
Control via the SR connector is not possible.	Wrong connection of the cable to the PC INPUT (AUDIO) connector is suspected.
The audio signal from the PC is not output.	Wrong connection of the cable to the SR connector is suspected.
The picture-quality setting (AV Selection) is not stored.	The picture-quality setting is stored for each input. As the setting is changed when another input is selected, the user may have a false idea that the setting is not stored.
The picture size changes arbitrary.	The Auto Size setting is set to ON.
The display position of the screen changes slightly while the screen is on.	The orbiter function for minimizing the effects of phosphor burn is activated. Although the setting for this function can be changed on the Home menu, retaining the factory setting is strongly recommended.
The video signal to the S video connector is not displayed.	The component video cable is connected to the same input function as for the S video (even if no signal is input to the component video connector, merely having something plugged in to the connector will result in judgment that a signal is being fed in and the component video connector takes priority). (Priority of connectors: component video > S video > composite video)
The video signal to the composite video connector is not displayed.	The S Video or component video cable is connected to the same input function as for the composite video. (Priority of connectors: component video > S video > composite video)

E

SUPPLEMENT: On the video setting for HDMI

There are three types of HDMI output formats: color difference 4:4:4, color difference 4:2:2, and RGB4:4:4. (The proportions, such as 4:4:4 and 4:2:2, represent those of the amount of data for video signal components. For example, as for color difference 4:4:4, the proportion of the amount of data as for Y, Cb, and Cr is 4:4:4.)

It is required to make the settings of the PDP according to the settings of the output equipment. For usual operation, however, set them to AUTO. If the color is inappropriate, make the settings manually.

In the HDMI system, video signals are coded at 24 bits per pixel and transmitted as a series of 24-bit pixels. In a case of color difference 4:4:4, Y, Cb, and Cr use 8 bits each. In a case of color difference 4:2:2, Y, Cb, and Cr use 12 bits each, but Cb and Cr are transmitted at a half sampling rate of Y. This unit is capable of processing the upper 10 bits out of 12 bits of video data. Recent high-end DVD players, such as Pioneer DV-79AVi, are capable of outputting 10-bit color-difference signals. In general, it is said that picture quality for color difference 4:2:2 format is assumed to be higher, because human eyes are more sensitive to luminance than to colors. In the case of RGB4:4:4, R, G, and B use 8 bits each.

5.5.1.1 CONFIRMATION ON THE HDMI CONTROL FUNCTION

When you use the HDMI Control (HDMI-CEC) function, if the unit does not function properly, such as not being able to control or recognize connected equipment, check the following:


- **Confirmation of the manufacturer of the connected equipment**

Check if the connected equipment was manufactured by Pioneer and if it supports the HDMI Control function. If its manufacturer is not Pioneer, proper operations are not guaranteed.

- **Confirmation of connections**

Check if the unit is connected properly, as shown in the figures below:

(For details, refer to "Making the HDMI Control connections" in the Operating instructions.)



Example 1: When an AV amplifier that supports HDMI Control is connected

Example 2: When an AV amplifier that does not support HDMI Control is connected

Example 3: When an AV amplifier is not connected

Check that the following conditions are met:

- The connected equipment must support the HDMI Control function.
- The equipment must be connected to the INPUT connector that has been selected in "Input Setting" on the HDMI Control Setting menu.
- The connections must be made properly, as shown in the above figures (in a case where an AV device, such as an AV amplifier, and a DVD recorder/BD player are connected, in a case where only a DVD recorder/BD player is connected, and in a case where an AV device, such as an AV amplifier, which does not support HDMI-CEC, is connected).
- When an AV device that supports the HDMI Control function is connected, it must be connected between the PDP and a DVD recorder/BD player.
- The HDMI Control function must be activated on the connected equipment (DVD recorder, BD player, AV device [AV amplifier, etc.]). (Refer to the Operating instructions of the connected equipment.)

A

• Confirmation of the number of connected devices

Check that the number of connected devices does not exceed the maximum number for guaranteed operations.

Equipment	Maximum Number
DVD recorder	2
BD player	2
AV System	1

B

• Confirmation of settings

Check that the settings for the HDMI Control function are properly made. (For details, refer to "Setting the HDMI Control" in the Operating instructions.)

Check that the following conditions are met:

- "Input Setting" on the HDMI Control Setting menu must be set to the same input as that to which the equipment that supports the HDMI Control function is connected.
- When Power Off Control, Power-On Ready, or Hold Sound Status are to be used, their settings must be On.

C

• Confirmation of operations

Check that the HDMI Control function works properly.

- (1) Connect a device that supports the HDMI Control function.
- (2) Perform the procedures that are required after changing connections, which are described in "Making the HDMI Control connections" in the Operating instructions.
 - 1 Turn on the plasma television and all the connected devices.
 - 2 Confirm that the setting in "Input Setting" for "HDMI Control Setting" is properly entered according to the connected devices. Also confirm the HDMI Control related settings in the connected devices.
 - 3 Switch to the HDMI input terminals to which the devices are connected to check if audio and video images are properly output and displayed.
 - 4 Try turning off the plasma television, then turn the power back on to the plasma television.
- (3) Perform "Power On Test" or "Power Off Test" on the HDMI Control Setting menu. (For details, refer to "Power On/Off Test" in the Operating instructions.)

E

If the following occurs even if the operation check is performed properly, a failure, such as breakage of the HDMI cable, problems on the side of the connected device, and problems with the MAIN Assy, may be suspected:

- "Power On Test" or "Power Off Test" cannot be selected (the items are grayed)
- The connected device cannot be turned on/off.

In some cases, an operation check using another HDMI input connector may be required in order to narrow down the cause.

F

5.5.2 FUNCTION OF DECREASING THE BRIGHTNESS LEVEL

■ High-temperature protection function 1

If the panel temperature (TEMP1) reaches 80 °C, the limit for the maximum count of plasma discharge will be gradually decreased to lower the temperature of the panel.

- This function is activated based on the TEMP1 temperature.
- The limit for the maximum count of plasma discharge will be decreased 8 per 5 seconds.
- The lowest limit for the maximum count of plasma discharge is about 700.
- The maximum count of plasma discharge will begin to increase gradually if the panel temperature falls to the specified temperature.

■ High-temperature protection function 2

If the panel temperature (TEMP1) reaches 55 °C, the plasma-discharge count that is determined based on the input APL will be decreased. In actual operation, the ABL adjustment value will be offset.

- This function is activated based on the TEMP1 temperature.
- The ABL adjustment value will be decreased by one step per 30 seconds.
- The ABL adjustment value will begin to increase gradually if the panel temperature falls to the specified temperature.

■ Panel protection function 1 (protection against still picture)

If a still picture is displayed for 3 minutes or more, the limit for the maximum count of plasma discharge will be gradually decreased to minimize the effects of phosphor burn.

- This function is activated after detection if the displayed picture is still (the picture will be considered to be still if only the mouse cursor is moved).
- The limit for the maximum count of plasma discharge will be decreased 8 per 5 seconds.
- The lowest limit for the maximum count of plasma discharge is about 700 (it takes about 15 minutes to reach the lowest limit, although the required time varies depending on the displayed picture).
- The maximum count of plasma discharge will begin to increase gradually if the displayed picture is changed to animated picture.

Note: How to decrease the brightness level in this function is the same as in high-temperature protection function 1.

■ Panel protection function 2 (SCAN IC protection)


If a particular load is applied to the SCAN IC, the limit for the maximum count of plasma discharge will be gradually decreased.

Note: How to decrease the brightness level in this function is the same as in high-temperature protection function 1.

■ Panel protection function 3 (protection against panel cracking)

A bright window, as shown in the figure on the right, on the screen increases the heat of the panel. If such a pattern is recognized on the screen, the limit for the maximum count of plasma discharge will be gradually decreased.


Note: How to decrease the brightness level in this function is the same as in high-temperature protection function 1.



Detection example: SCAN IC protection



Detection example: Protection against panel cracking



5.6 OUTLINE OF THE OPERATION

5.6.1 PANEL DRIVE-POWER ON / OFF FUNCTION

Function:

It is an operational mode where the digital signal processing performs circuit operation but the power is not supplied to the panel driving system (Vsus, VAddress) in order to avoid a power down (PD).

Application:

1. When it is necessary to check whether the signal output is correctly reaching the drive system in a repairing activity etc.
2. In the case of a PD, to determine whether the problem is with the panel drive-power supply or with the other system power supply.


Method:

1. Short-circuit between the specified location of the POWER SUPPLY Unit and GND (Multi base section recommended), using a jumper with alligator clips (refer to the photos below).
2. Execute [DRV S00] by RS-232C command. ([DRV S01] for release)


Supplemental explanation:

- When the panel drive-power is in OFF state, there will be no PD, except PS_PD, as the PD signal has been muted.
- If the clip is removed in the OFF state of the panel drive-power, PD will take place at the instance of clip removal. Therefore, be sure to remove the clip after turning the power OFF.
- Under RS-232C command control, [DRV S01] (release) is possible during power ON. However, there is a possibility of damaging the set. Therefore, make this operation only after turning the power OFF.
- Command [DRV S00/S01] is effective even during standby.
- When the main power switch is set to OFF, no command is accepted.
- When the AC power cord is unplugged, the panel drive-power OFF state established by the [DRV S00] command is canceled. (The panel drive-power OFF state remains in effect even if the main power switch is set to OFF after that command is sent.)

When the panel drive-power is ON




When the panel drive-power is OFF




5.6.2 SPECIFICATION OF THE FAN CONTROL

Block diagram

The internal fan cools down the MTB and Power blocks.
The external fans cool down the whole unit.



Operation specifications




Notes:

- The operating temperature of the fan is higher than the ambient temperature, because the sensor temperature is read by the microcomputer.
- If the critical values for signals are displayed in the address circuit, the fan may be activated or be rotated at higher speed in response to values lower than the set temperature values shown above.
- When the temperature rises, the sensor voltage of TEMP2 decreases.
- When the voltage of the DAC output for external FAN decreases, rotation speed of FAN rises.

5.6.3 PROCESSING IN ABNORMALITY

Protection of the Power Amplifier

● Circuit configuration



● Specifications for port monitoring

Port Name	SD/PD Indication	Active	Monitoring conditions	Operation
A_NG_B	AUDIO	Shutdown occurs when the signal is "L." 30 mS * 3 times	RST4 = "H" (always) (Monitoring starts 2 sec after the above conditions are established.)	The main CPU operations described below will be performed when either "A_NG_B = L" or "OTW = L" is detected (established) under the monitoring conditions.
OTW	AUDIO	Shutdown occurs when the signal is "L." 130 mS * 3 times		

● Operation specifications of the main CPU

- (1) When a shutdown decision is made by the main CPU
- After a warning indication is displayed for 5 sec, a shutdown is generated (the blue LED flashes 5 times).
 - A warning indication is displayed for all input-signal types.
 - Example of a warning indication: "The speaker terminals are short-circuited. After reconnection, turn the unit on again."
(For 50-inch models) (For 42-inch models, an indication declaring a forced power-off is displayed.)


- (2) Display conditions
- When the panel is on: A warning indication is displayed immediately.
- When the panel is off: A warning indication is not displayed immediately but is displayed when the panel is turned on.
- Note:** A warning indication is displayed each time the panel is turned on if the conditions for a shutdown persist.

● Conditions for resetting the circuits

The circuits will be reset upon Standby ON/OFF.

Power supply and DC-DC converter

● Circuit configuration




● Specifications for port monitoring

Port Name	SD/PD Indication	Active	Monitoring conditions	Operation
RST2	ASIC power (M-DCDC)	Shutdown occurs when the signal is "L." for 5 sec after PSW1 is ON. or for 2 sec while the unit is ON.	<ul style="list-style-type: none"> Panel ON (RST4 = H and PSW1 = L) While awaiting restoration of RST2 (RST2 = L) 	<p>The SD timer starts when "RST2 = L" is detected under monitoring conditions. If "RST3 = H," "M_SW_DET_B = H," or "RST4 = L" is detected, or if a power-down or shutdown in the module microcomputer system is not generated, the unit waits for 30 mS. Then, if the SD timer continues to count for 2 sec or more, a shutdown is determined, and a shutdown process starts. A specific LED flash pattern (blue LED, 13 times) starts. The next PON operation is valid, and the flag is cleared upon the next power-on.</p> <p>If RST2 is H, a restoration process starts according to the latest power-on/off status.</p>
RST3	AC power	AC_OFF when the signal is "H."	<ul style="list-style-type: none"> Active STB (including SD/PD statuses) Functional STB Panel ON (Areas other than North America) While the main power switch is set to OFF (M_SW_DET_B = H) (North America) While the main power switch is set to OFF (M_SW_DET_B = H) While awaiting restoration of AC power (RST3 = H) While awaiting restoration of RST2 (RST2 = L) While awaiting restoration of RST4 (RST4 = L) 	<p>If "RST3 = H" (AC_OFF) is detected under the monitoring conditions, a power-off process starts. Monitoring of the RST3 port is continued, while monitoring of other ports is interrupted. Communication is controlled only by the IF microcomputer. The port outputs are set as specified. If the signal at the RST3 port continues to be H after 30 mS of waiting, monitoring is continued. If RST3 is L, a restoration process starts according to the latest power-on/off status.</p>
RST4	MAIN power (RELAY)	Shutdown occurs if the signal is "L." for 5 sec after RELAY is ON. or for 2 sec while the unit is ON or in Functional STB.	<ul style="list-style-type: none"> Functional STB Panel ON (Areas other than North America) While the main power switch is set to OFF (M_SW_DET_B = H) While awaiting restoration of RST2 (RST2 = L) While awaiting restoration of RST4 (RST4 = L) 	<p>The SD timer starts when "RST4 = L" (power-off of devices in the functional STB system) is detected under monitoring conditions. The RST4 initialization process starts, and input monitoring, communication setting, and output-terminal setting are performed. The RST4-SD timer starts. If either "RST3 = H" or "M_SW_DET_B = H" is detected, or if a power-down or shutdown in the module microcomputer system is not generated, the unit waits for 30 mS. Then, if the SD timer continues to count for 2 sec or more, a shutdown is determined, and a shutdown process starts. A specific LED flash pattern (blue LED, 13 times) starts. The next PON operation is valid, and the flag is cleared upon the next power-on. If RST4 is H, a restoration process starts according to the latest power-on/off status.</p>

Fan and temperature sensor

● Circuit configuration



● Specifications for port monitoring


Port Name	SD/PD Indication	Active	Monitoring conditions	Operation
FAN_NG1	FAN1	Shutdown occurs when the signal is "H." 1 S * 3 times	RST4 = H and FAN_ON1 = H (Monitoring starts 3 sec after the above conditions are established.)	If FAN_NG1 (for details on detection logic, see "File of fan-control specifications") is detected (established) under the monitoring conditions, a shutdown process starts. A specific LED flash pattern (blue LED, 10 times) starts. The next PON operation is valid, and the flag is cleared upon the next power-on.
FAN_NG2	FAN	Shutdown occurs when the signal is "H." 1 S * 3 times	RST4 = H and FAN_ON2 = H (Monitoring starts 3 sec after the above conditions are established.)	If FAN_NG2 (for details on detection logic, see "File of fan-control specifications") is detected (established) under the monitoring conditions, a shutdown process starts. A specific LED flash pattern (blue LED, 10 times) starts. The next PON operation is valid, and the flag is cleared upon the next power-on.
TEMP2	High temperature at MTB	Shutdown occurs if any values equal to or greater than minimum to require a shutdown are detected. 1 S * 3 times	RST4 = H (Monitoring starts 1 sec after the above conditions are established.)	If any values equal to or greater than minimum to require a shutdown are detected (established) under the monitoring conditions, a warning indication will be displayed for 30 sec, after which a shutdown process starts. A specific LED flash pattern (blue LED, 11 times) starts. The next PON operation is valid, and the flag is cleared upon the next power-on.
TMP_NG	High temperature in the drive circuits	Shutdown occurs if any values equal to or greater than minimum to require a shutdown are detected. 200 mS * 5 times (average)	Digital video RST2 = H	If any values equal to or greater than minimum to require a shutdown is detected (established) under the monitoring conditions, those changes in status will be transmitted to the main microcomputer via the UART. Upon receiving the data, a warning indication will be displayed for 30 sec, after which a shutdown process starts. The main microcomputer orders a specific LED flash pattern (blue LED, 4 times). The next PON operation is valid, and the flag is cleared upon the next power-on.
	Low temperature in the drive circuits			If any values equal to or greater than minimum to require a shutdown is detected (established) under the monitoring conditions, those changes in status will be transmitted to the main microcomputer via the UART. Upon receiving the data, the main microcomputer orders a specific LED flash pattern (blue LED, 4 times). The next PON operation is valid, and the flag is cleared upon the next power-on.

● Outline and Notes

For video data transmission inside this Plasma Display, digital signals are used. Therefore, this unit adopts the HDCP (High-bandwidth Digital Content Protection) system for copyright protection. This unit is also provided with a detection switch (TRAP switch) that will prohibit the unit from being turned on again "if the rear case of the unit is accidentally opened," in order to prevent the panel technology from being leaked out.

The TRAP switch is disabled while the unit is turned off.

When performing internal diagnosis of the PDP, fix the switch to the OFF position using adhesive tape before turning on the unit. After servicing, be sure to remove the adhesive tape.



WHEN THE TRAP SWITCH IS ACTIVATED

When the TRAP switch is activated, the red and blue LEDs will light.

In order to deactivate the TRAP switch, close the upper plate of the unit or fix the TRAP switch to the OFF position in the manner described above.

Then, follow procedures (1) or (2) below:

(1) Deactivating with the remote control unit

- Enter Factory mode.
- Proceed to the INITIALIZE layer of Factory mode. Hold the DISPLAY key pressed for more than 5 seconds.

(2) Deactivating with the RS-232C command

- Send the CTM (cancel) command.


1 2 3 4

6. SERVICE FACTORY MODE

6.1 OUTLINE OF THE SERVICE FACTORY MODE

A Operations during Service Factory mode are described here.

6.1.1 SERVICE FACTORY MODE TRANSITION CHART



D

6.1.2 HOW TO ENTER/EXIT SERVICE FACTORY MODE

E

■ How to enter Service Factory Mode

By using a PDP service remote control)

- PDP service remote control : Press [FACTORY] key.

By issuing RS-232C commands)

- During normal Standby mode : Issue [PON] then [FAY].
- During normal operation mode : Issue [FAY].

■ How to exit Service Factory Mode

By using a PDP service remote control)

- PDP service remote control : press [FACTORY] key.
- Supplied remote control unit : press [HOME MENU] key.

By issuing RS-232C commands)

- Issue [FAN].

■ How to enter Service Factory Mode by Using the supplied Remote Control Unit

- Same as previous model. Please refer to the technical document (Service Know-how).

6.1.3 FUNCTIONS WHEN ENTERING THE SERVICE FACTORY MODE

■ Functions whose setting are set to OFF

The settings for the following functions are set to OFF when Service Factory mode is entered (including when the “FAY” command is received) :

Function	Remarks
2-Screen Operation	Input function set on the main side is selected.
FREEZE	
Auto size, Side Mask	It is not performed during Factory mode.
ORBITER, Mask control	Central value operation (ORBITER)
Sleep Timer	Cancel the operation.
Room light sensor	Turn off the detecting operation (Setting data will be retained.)
Blue LED dimmer	Turn off the operation (Setting data will be retained.)
Detection of the TRAP switch	The detection operation is stopped.
TRAP history	To a possible turning on though the memory is maintained.
Display of TV guide	Finish the TV-GUIDE function.
Setting of Parental Control	When this is turned off, the block of the screen is released.
Power Control	Turn off the operation (However, the setting maintains it.)
Image Position	Central value operation

Note: Enter the factory after cancelling ACI because the ACI operation setting OFF and not done.

■ User data

User data will be treated as follows :

- User data on picture-quality and audio-quality adjustments are not reflected, and factory-preset data are output (user data will be retained in memory). When the unit enters Service Factory mode, the current audio-quality adjustment data will be still be retained in memory.
- User-setting data will be applied to the various settings (items on the menus), signal formats, and the items that are associated with path change (HDMI settings, etc.).
- Data on screen (i.e., screen position; meaning clock dividers, and not including data on screen size). Are reset to the default values (data stored in memory will be retained).
Screen size will be retained.

1234

6.1.4 REMOTE CONTROL CODE IN SERVICE FACTORY MODE

Remote Control Keys	Basic Functions	Remarks
MUTING	Switching the main items.	Shifting to the next main item (top).
↓ (DOWN)	Switching the subtitled items.	Shifting downward to the next subtitled item.
↑ (UP)	Switching the subtitled items.	Shifting upward to the next upper layer.
← (LEFT)	Decreasing the adjustment value.	Decreasing the adjustment value.
→ (RIGHT)	Increasing the adjustment value.	Increasing the adjustment value.
ENTER/SET	Switching the layers.	Shifting downward or upward to the next lower or upper layer.
INPUT	Selecting INPUT.	Shifting the INPUT to the next function.
INPUTxx	Selecting INPUT.	Switching the INPUT to xx. (xx=1 to 7 etc)
CH+/P+	Increasing the channel number.	
CH-/P-	Decreasing the channel number.	
Numeric Keys	Function: TV	Function: TV (previously selected channel number is selected)
POWER	Power OFF.	Turning the power off.
FACTORY	Factory OFF (Factory mode)	In Factory mode, turning Factory mode off.
	Factory ON (Non-Factory mode).	In Non-Factory mode, turn Factory mode on.
HOME MENU	Menu ON.	In Factory mode, turn Factory mode off.
VOLUME+	Volume UP.	Increasing 10 the adjustment value. (PANEL FACTORY)
VOLUME-	Volume DOWN.	Decreasing 10 the adjustment value. (PANEL FACTORY)
DRIVE OFF (Note1)	Drive Mode OFF.	Turning Drive mode off.
INTEGRATOR	INTEGRATOR MENU ON.	Enter INTEGRATOR MODE.

(Note 1) When ten seconds have passed since the [DRIVE OFF] key was pressed at the standby, it becomes invalid.
Please press [POWER] key from the [DRIVE OFF] key pressing within ten seconds when you do power supply ON while driven OFF.




PDP service
remote control

PDP-5010FD

6.1.5 PDP SERVICE REMOTE CONTROL

- The keys labeled with the same names on the service remote control unit have the same functions as those of the supplied remote control unit. (See "2.3 PANEL FACILITIES.")
- For the keys not provided on the supplied remote control unit, see the explanations below:




6.1.6 FACTORY HIERARCHICAL TABLE

Large Item	Middle Item		Variable / Adjustment Range	Remarks	
		Small Item			
6.2.1 INFORMATION					
	6.2.1.1	VERSION (1)			
	6.2.1.2	VERSION (2)			
	6.2.1.3	VERSION (3)			
	6.2.1.4	MAIN NG	CLEAR <=>	NO <=> YES	
	6.2.1.5	TEMPERATURE			
	6.2.1.6	HOUR METER	MTB HOUR METER CLEAR	NO <=> YES	
	6.2.1.7	HDMI SIGNAL INFO 1			
	6.2.1.8	HDMI SIGNAL INFO 2			
	6.2.1.9	VDEC SIGNAL INFO 1			
	6.2.1.10	VDEC SIGNAL INFO 2			
	6.2.1.11	DTV TUNING STATUS 1			
	6.2.1.12	DTV TUNING STATUS 2			
	6.2.1.13	DTV TUNING STATUS 3			
	6.2.1.14	DTV TV-GUIDE BER		for the technical analysis	
	6.2.1.15	DEBUG INFO		for the technical analysis	
6.2.2 PANEL FACTORY (+)					
	6.2.2.1	PANEL INFORMATION			
	6.2.2.2	PANEL WORKS			
	6.2.2.3	POWER DOWN			
	6.2.2.4	SHUT DOWN			
	6.2.2.5	PANEL-1 ADJ (+)	VOL SUS <=>	000 to 255	Equivalent to VSU (Setting value: Factory adjustment value)
			VOL OFFSET <=>	000 to 255	Equivalent to VOF (Setting value: Factory adjustment value)
			VOL RST P <=>	000 to 255	Equivalent to VRP (Setting value: Factory adjustment value)
			VOL XPOFS1 <=>	000 to 255	Equivalent to VX1 (Setting value: Factory adjustment value)
			VOL XPOFS2 <=>	000 to 255	Equivalent to VX2 (Setting value: Factory adjustment value)
			VOL YNOFS1 <=>	000 to 255	Equivalent to VY1 (Setting value: Factory adjustment value)
			VOL YNOFS3 <=>	000 to 255	Equivalent to VY3 (Setting value: Factory adjustment value)
			VOL YNOFS4 <=>	000 to 255	Equivalent to VY4 (Setting value: Factory adjustment value)
			RESET1ST_KSB <=>	112 to 144	Equivalent to R1K (Setting value: 128 fixed)
			RESET2ND_KSB <=>	112 to 144	Equivalent to R2K (Setting value: 128 fixed)
			YSTL_1SF_KSB <=>	112 to 144	Equivalent to Y1K (Setting value: 128 fixed)
			YSTL_1SF_HZ <=>	112 to 144	Equivalent to Y1Z (Setting value: 128 fixed)
			XSUS_1ST_B <=>	112 to 144	Equivalent to X1B (Setting value: 128 fixed)
			YSUS_2ND_B <=>	112 to 144	Equivalent to Y2B (Setting value: 128 fixed)
			XSUS_3RD_B <=>	112 to 144	Equivalent to X3B (Setting value: 128 fixed)
			YSUS_B <=>	112 to 144	Equivalent to YSB (Setting value: 128 fixed)
			XSUS_B <=>	112 to 144	Equivalent to XSB (Setting value: 128 fixed)
			YSTL_KSB <=>	112 to 144	Equivalent to YTK (Setting value: 128 fixed)
			YSTL_HZ <=>	112 to 144	Equivalent to YTZ (Setting value: 128 fixed)
			YSTL_2SF_KSB <=>	112 to 144	Equivalent to Y2K (Setting value: 128 fixed)
	YSTL_2SF_HZ <=>	112 to 144	Equivalent to Y2Z (Setting value: 128 fixed)		
	YSTL_FMR_KSB <=>	112 to 144	Equivalent to YNK (Setting value: 128 fixed)		
	YSTL_FMR_HZ <=>	112 to 144	Equivalent to YNZ (Setting value: 128 fixed)		
	SUS FREQ. <=>	MODE 1 to MODE 8	Equivalent to SFR (Setting value: MODE1)		
	6.2.2.6	PANEL-2 ADJ (+)	R-HIGH <=>	000 to 511	Equivalent to PRH (Setting value: Factory adjustment value)
			G-HIGH <=>	000 to 511	Equivalent to PGH (Setting value: Factory adjustment value)
			B-HIGH <=>	000 to 511	Equivalent to PBH (Setting value: Factory adjustment value)
			R-LOW <=>	000 to 999	Equivalent to PRL (Setting value: 512 fixed)
			G-LOW <=>	000 to 999	Equivalent to PGL (Setting value: 512 fixed)
B-LOW <=>			000 to 999	Equivalent to PBL (Setting value: 512 fixed)	
ABL <=>			000 to 255	Equivalent to ABL (Setting value: Factory adjustment value)	
6.2.2.7	PANEL FUNCTION (+)	R-LEVEL <=>	LV-0 to LV-7	Equivalent to RRL (Setting value: Lv-1)	
		G-LEVEL <=>	LV-0 to LV-7	Equivalent to RGL (Setting value: Lv-1)	
		B-LEVEL <=>	LV-0 to LV-7	Equivalent to RBL (Setting value: Lv-0)	
		ADDRESS L1 <=>	PH0 to PH9	Equivalent to AP0S*-. (Setting value: PH1)	
		ADDRESS L2 <=>	PH0 to PH9	Equivalent to AP0S*-. (Setting value: PH0)	
		ADDRESS L3 <=>	PH0 to PH9	Equivalent to AP1S*-. (Setting value: PH2)	
		ADDRESS L4 <=>	PH0 to PH9	Equivalent to AP1S*-. (Setting value: PH1)	
		ADDRESS U1 <=>	PH0 to PH9	Equivalent to AP2S*-. (Setting value: PH1)	
		ADDRESS U2 <=>	PH0 to PH9	Equivalent to AP2S*-. (Setting value: PH0)	
		ADDRESS U3 <=>	PH0 to PH9	Equivalent to AP3S*-. (Setting value: PH2)	
		ADDRESS U4 <=>	PH0 to PH9	Equivalent to AP3S*-. (Setting value: PH1)	
		STK MODE <=>	OFF <=> MODE1 to MODE8 <=>	SKM S00 to S07	



*: Setting value

Large Item			Variable / Adjustment Range	Remarks
	Middle Item	Small Item		
6.2.2 PANEL FACTORY (+)				
	6.2.2.8 ETC. (+)	BACKUP DATA <=>	NO OPRT <=> TRANSFER or ERR	Equivalent to BCP
		DIGITAL EEPROM <=>	NO OPRT <=> DELETE/REPAIR	Equivalent to FAJ/UAJ
		PD INFO. <=>	NO OPRT <=> CLEAR	Equivalent to CPD
		SD INFO. <=>	NO OPRT <=> CLEAR	Equivalent to CSD
		HR-MTR INFO. <=>	NO OPRT <=> CLEAR	Equivalent to CHM
		PM/B1-B5 <=>	NO OPRT <=> CLEAR	Equivalent to CPM
		P COUNT INFO. <=>	NO OPRT <=> CLEAR	Equivalent to CPC
		MAX TEMP. <=>	NO OPRT <=> CLEAR	Equivalent to CMT
	6.2.2.9 RASTER MASK SETUP (+)	MASK OFF	<=> 48V <=> 50V <=> 60V <=> 72V <=> 75V <=> 60P <=>	Equivalent to MKS+S00
		RST MASK 01 <=>		Equivalent to MKS+S51
	
		RST MASK 25 <=>		Equivalent to MKS+S75
	6.2.2.10 PATTERN MASK SETUP (+)	MASK OFF	<=> 48V <=> 50V <=> 60V <=> 72V <=> 75V <=> 60P <=>	Equivalent to MKS+S00
		PTN MASK 01 <=>		Equivalent to MKS+S01
	
		PTN MASK 49 <=>		Equivalent to MKS+S49
	6.2.2.11 COMBI MASK SETUP (+)	MASK OFF	<=> 48V <=> 50V <=> 60V <=> 72V <=> 75V <=> 60P <=>	Equivalent to MKC+S00
		CMB MASK 01 <=>		Equivalent to MKC+S01
	
		CMB MASK 17 <=>		Equivalent to MKC+S17
6.2.3 OPTION				
	6.2.3.1 EDID WRITE MODE <=>		DISABLE <=> ENABLE	Exclusively used for production line
	6.2.3.2 ANTENNA MODE <=>		CABLE <=> AIR	
	6.2.3.3 AFT <=>		DISABLE <=> ENABLE	
	6.2.3.4 SYNC DET (+)			for the technical analysis
	6.2.3.5 CC (+)			for the technical analysis
6.2.4 INITIALIZE				
	6.2.4.1 SIDE MASK LEVEL (+)	SIDE MASK LEVEL <=>		
	6.2.4.2 FINAL SETUP	DATA RESET <=>	NO <=> YES	
	6.2.4.3 HMG/HG SERVICE MODE	MODE SHIFT <=>	NO <=> YES	
	6.2.4.4 Wide XGA AUTO <=>		DISABLE <=> ENABLE	Exclusively used for technical analysis (details omitted)

6.1.7 INDICATIONS IN SERVICE FACTORY MODE



Main-item indications



① Input function

Input Functions		OSD
VIDEO 1 to 7		VD 1 to 7
Terrestrial Wave A		ARA
Terrestrial Wave B		ARB
Cable A		CBA
Cable B		CBB
Home Gallery (Regular model only)		HG
Home Media Gallery (ELITE model only)		HMG
PC		PC

② SIG mode and Screen size

Note: See SIG-Mode Tables. (See next page.)

③ Color system and Signal type

Color System and Signal Type		OSD
NTSC	Composite input	NTV
	S-connector input	NTS
Y/CB/CR		CBR
Y/PB/PR		PBR
RGB		RGB
Digital Video signal		DIG

④ Option (Destination, Panel Generation, etc.)

Options	OSD
Regular model	ATB
ELITE model	AHB

② SIG Mode and Screen size (by User is displayed)

1st and 2nd characters : Resolution of the input signal

3rd and 4th characters : Refresh rate of the input signal

5th character : Selection of the screen size

■ Input signal mode table for video signals (resolutions and V frequencies)

1st to 4th Character		Signal Type	Fv (Hz)	Fh (kHz)
10	60	SDTV*525i	60.000	15.750
20	60	SDTV*525p	60.000	31.500
30	60	HDTV*1125i	60.000	33.750
40	60	HDTV*750p	60.000	45.000
50	24	HDTV*1125p	24.000	27.000
50	60	HDTV*1125p	60.000	67.500

Fv: Vertical Frequency, Fh: Horizontal Frequency

■ Input signal mode table for PC signals (resolutions and V frequencies)

1st to 4th Character		Signal Type	Fv (Hz)	Fh (kHz)
C1	70	720 x 400	70.087	31.469
C2	60	640 x 480	59.940	31.469
C4	60	800 x 600	60.317	37.879
C6	60	1280 x 720	60.000	44.800
C7	60	1024 x 768	60.004	48.363
C9	60	1360 x 768	60.015	47.712
D6	60	1280 x 1024	60.000	64.000

Fv: Vertical Frequency, Fh: Horizontal Frequency

■ Current selection of the screen size

5th Character	GUI Notation	VIDEO	PC	Remarks
0	DOT BY DOT	● (*)	—	
1	4:3	●	●	
2	FULL	●	●	
3	ZOOM	●	—	
4	CINEMA	●	—	
5	WIDE	●	—	

●: supported, —: unsupported

Note (*): It is effective only with models having the Full HD panel.

6.2.1.2 VERSION (2)

	1	5	10	15	20	25	30	35	40
1									
5									
10									
15									
16									

Meaning	Item Name	Display Example
DTV Hardware Version	HARDWARE	XXXXXXXXX
DTV Hardware Serial	SERIAL	01234567
DTV Runtime Version	RUNTIME	HHHHHHHHH
CFE Version	CFE	HHHHHHHHH
KERNEL Version	KERNEL	HHHHHHHHH
ROOTS Version	ROOTS	HHHHHHHHH
FLAGS	FLAGS	H/W (Y)
		DVR (Y) FONTS(Y)
		DFAST(Y) PLOG (Y)

6.2.1.3 VERSION (3)

	1	5	10	15	20	25	30	35	40
1									
5									
10									
15									
16									

Meaning	Item Name	Display Example
HMG/HG module Version	HMG/HG	01234567
User Password	PASSWORD	1234

6.2.1.4 MAIN NG

A

B

C

D

E

F

	1	5	10	15	20	25	30	35	40																														
1			INFORMATION										VD1-30601-NTV-AHB																										
			MAIN NG																																				
			MAIN					SUB					00151H21M																										
5																																							
			1	MA-IIC					FE1					00031H50M																									
			2	MA-IIC					AV-SW					00013H03M																									
			3	MA-3L					IF					00002H52M																									
			4	MAIN					-----					00001H58M																									
10			5	TEMP2					-----					00000H07M																									
			6																																				
			7																																				
			8																																				
15																																							
16																																							

MTB side's Shutdown NG information

OSD: MAIN	OSD: SUB	Cause of Shutdown
AUDIO	----	Short-circuit of the speaker terminal or failure of audio amplifier.
MODULE	----	Failure of communication to Module microcomputer.
MA-3L		3-wire Serial Communication of Main microcomputer.
	IF	Communication failure of IF microcomputer
	MULTI	Multi Processor communication failure
MA-IIC		IIC Communication failure of Main microcomputer
	FE1	Analog Tuner 1
	FE2	Analog Tuner 2
	MSPMAP	MSP/MAP
	AV-SW	AV Switch
	RGB-SW	RGB Switch
	VDEC	VDEC
	SDRAM	VDEC - SDRAM
	ADC	AD/PLL
	HDMI	HDMI
	US-MSP	MSP
MAIN		Communication failure of Main microcomputer
FAN	FAN1	Fan stopped
	FAN2	Fan stopped (Only with models having the Full HD panel)
TEMP2		Abnormally high temperature at MTB.
DTUNER		Failure of Digital Tuner
	PS/RST	Failure to DTV Starting
	RETRY	DTV communication error
	DE-BCM	Abnormally in BCM7038
	DE-FE	Tuner 1 or 2
	DE-CAS	Card I/F IC
	DE-VBI	VBI Slicer
	DE-EPI	EEPROM
	TV-G	TV-Guide Error
	HOME-G	Failure at Home Gallery
	DTVMID	Middleware
	DTVAPP	Application
RST-MA	M-DCDC	Abnormally in RST2 of MAIN Assy. (power decrease of DC-DC converter)
	RELAY	Abnormally in RST4 of MAIN Assy. (power decrease of Relay power)
HMG		Failure at Home Media Gallery
	HMG	Home Media Gallery startup error
MA-EEP		IIC communication line between EEPROM and MAIN.

	1	5	10	15	20	25	30	35	40	
1										
5										
10										
15										
16										

Operation:

Even if [←] key or [→] key is pressed, {CLEAR <=> :YES} ⇔ {CLEAR <=> :NO} is repeated.
 If the [ENTER/SET] key is kept on pressing for 5 second when the status of this menu is <YES>, clear process will begin.

6.2.1.5 TEMPERATURE

A present temperature and the FAN rotation are displayed.
If either [←] key or [→] key is pressed, the display data is refreshed.

	1	5	10	15	20	25	30	35	40
1									
5									
10									
15									
16									

• Display/Meaning

TEMP1 : The temperature of the sensor on the panel side is displayed by the Fahrenheit (F).

TEMP2 : The temperature conversion display is done with 10 bit the A/D input value of IF uCOM 90 pin (AN4). It is displayed by both the Fahrenheit (F) and 8 bit A/D value.

(Remark: When temperature (F) of the sensor becomes more than a specified temperature, the shutdown start of processing.)

FAN1 : The value of the FAN rotating state is displayed.

STOP: stopped, LOW: slow speed, HIGH: high speed.

FAN2 : The value of the rotation state of FAN is displayed.

During a rotation of FAN, 8bit D/A value output from 2 pin (DA0) of IF uCOM is displayed.

It is displayed with OFF during a stop (only for the FHD model).

B-SENSOR : The value that indicated the degree of brightness input into an Room light sensor is displayed.

AD value when the output of the Room light sensor was input into 89 pin (AN5) of IF uCOM is displayed.

6.2.1.6 HOUR METER

	1	5	10	15	20	25	30	35	40
1									
5									
10									
15									
16									

• Display/Meaning

Meaning	Item Name	Display Example	Corresponding RS-232C Command
HOUR METER (PANEL)	PANEL	00151H 21M	QS3
HOUR METER (MTB)	MTB	00151H 21M	QS3
POWER ON COUNTER	P-COUNT	00000095 TIMES	QS3
SYSTEM SERIAL	SERIAL		QS3

Note: The PANEL-side's HOUR METER/P-COUNT acquires information from the PANEL-side.

• MTB HOUR METER

In HOUR METER screen on Factory Menu, press the [ENTER] key, and then it moves to the screen to clear MTB HOUR METER. (MTB HOUR METER is cleared only.)

	1	5	10	15	20	25	30	35	40
1									
5									
10									
15									
16									

Operation:


Even if [←] key or [→] key is pressed, {CLEAR <=> :YES} ⇔ {CLEAR <=> :NO} is repeated.

If the [ENTER/SET] key is kept on pressing for 5 second when the status of this menu is <YES>, clear process will begin.

MTB HOUR METER is cleared only. PANEL HOUR METER is not cleared.

6.2.1.7 HDMI SIGNAL INFO 1

A



B

Displays the input signal information of HDMI terminal

Item	Meaning
PWR5V	+5 V power detection (18 pin of HDMI terminal)
VSYNC	VSYNC detection
CKDT	Clock detection
SCDT	SYNC detection
DCRPT	HDCP decryption status
AUTHEN	HDCP authentication status
MODE	HDMI mode status
BIST	----
NVAL	N value
CTSVAL	CTS value
AKSV	Shadow AKSV value
BKSV	Shadow BKSV value
IT CNT	IT content (AVI info)
EXTCOL	Extension calorimetry (AVI info)
RGV QR	RGB range (AVI info)
PIXDEP	Number of pixel/bit

C

D

E

F

A



C

□

*2: If may not match to the state of source devices when the color is abnormal.

F

F

6.2.1.9 VDEC SIGNAL INFO 1

A

	1	5	10	15	20	25	30	35	40												
1		INFORMATION										VD1-30601-NTV-AHB									
		VDEC SIGNAL INFO 1																			
5		MVDEC -000:00										SVDEC -400:00									
		-001:00										-401:00									
		-094:00										-494:00									
		-095:00										-495:00									
		-096:00										-496:00									
10		-098:00										-- --:--									
		-1B5:00										-5B5:00									
		-1B6:00										-5B6:00									
		-1B7:00										-5B7:00									
15																					
16																					

B

Displays signal status that is input to VDEC.

Device	Sub Address (Main screen)	Sub Address (Sub screen)	Meaning
VDEC	000h	400h	Line system distinction result
	001h	401h	VTR distinction result
	094h	494h	Slot number
	095h	495h	Color system distinction result
	096h	496h	ACC coefficient
	098h	---	3D YC flag
	1B5h	5B5h	MV detection 1
	1B6h	5B6h	MV detection 2
	1B7h	5B7h	MV detection 3

6.2.1.10 VDEC SIGNAL INFO 2

		1		5		10		15		20		25		30		35		40
D	1																	

Displays signal status that is input to VDEC.

Device	Sub Address (Main screen)	Sub Address (Sub screen)	Meaning
VDEC	205h	605h	CC detection 1
	208h	608h	CC detection 2
	20Bh	60Bh	CC-CRI detection
	20Ch	60Ch	XDS content advisor 0
	20Dh	60Dh	XDS content advisor 1

A

1

9

1

□

E

1

1

■

A ■ **Operation Items**

This is the menu screen for the adjustment of the panel. Data acquisition and value adjustment can be performed for the following items:

No.	Indication	Description of functions
6.2.2.1	PANEL INFORMATION	Data, such as the version of the microcomputer of the panel, product serial number, and statuses of memories for adjustment values for the main unit and for backup, are displayed.
6.2.2.2	PANEL WORKS	Operation data, such as accumulated pulse-meter count, accumulated hour-meter count, accumulated power-on count, and the temperature detected by the sensor, are displayed.
6.2.2.3	POWER DOWN	The power-down history is displayed, with the hour-meter values that indicate the hour values when power-downs occurred.
6.2.2.4	SHUT DOWN	The shutdown history is displayed, with the hour-meter values that indicate the hour values when shutdowns occurred.
6.2.2.5	PANEL-1 ADJ (+)	Settings of the driving pulse timing and driving voltage can be performed.
6.2.2.6	PANEL-2 ADJ (+)	White balance and ABL (power consumption) for the panel can be set.
6.2.2.7	PANEL FUNCTION (+)	Perform panel-degradation correction-level setting, phase adjustment of the address, and the streaking-correction setting.
6.2.2.8	ETC. (+)	Copying of backup data and clearance of various data can be performed.
6.2.2.9	RASTER MASK SETUP (+)	The mask indication (RASTER) can be set and indicated.
6.2.2.10	PATTERN MASK SETUP (+)	The mask indication (PATTERN) can be set and indicated.
6.2.2.11	COMBI MASK SETUP (+)	The mask indication (COMBI) can be set and indicated.

■ Details of indications in each layer

- In the following examples, GUI images for a 50-inch and 60-inch models are indicated.

6.2.2.1 PANEL INFORMATION

- Data, such as the version of the microcomputer of the panel, product serial number, and statuses of memories for adjustment values for the main unit and for backup, are displayed. No other layers are nested below this layer, and there are no adjustment items.

	1	5	10	15	20	25	30	32
1			PANEL FACT.		VD1-10605-NTV-ATB			
	1		PANEL INFORMATION					
	2		MODULE	= 02 F		05 F		
5	3		-PRG	= 02 F				
	4		-DAT	= 02 F				
	5		SEQ-PRS	= 04 Y		04 F		
	6		-PRQ	= 04				
	7		-PIC	= 03 Y				
10	8		-SEQ	620Y				
	9							
	A		SERIAL					
	B		DIG.EEP	ADJUSTED				
	C		BACKUP	ADJUSTED				
15	D							
16	E							

■ Key operation

- <DOWN> : Shifting to PANEL WORKS
- <UP> : Shifting to COMBI MASK SETUP (+)
- <L/R> : Updating displayed information

■ Display items:

- MODULE : The version of data written in the Module microcomputer (IC3601) is indicated.
- PRG : The program version of the Module microcomputer is indicated.
- DAT : The data version of the Module microcomputer is indicated.
- SEQ-PRG : The version of data written in the Sequence LSI (IC3301) is indicated.
- PRG : The program version of the Sequence LSI is indicated.
- PIC : The Picture-data version of the Sequence LSI is indicated.
- SEQ : The sequence-data version of the Sequence LSI is indicated.
- SERIAL : The serial number of the module is indicated.
- DIG.EEP : The adjusted status of the EEPROM that is mounted on the DIGITAL Assy is indicated.
- BACKUP : The adjusted status of the EEPROM for backup that is mounted on the SENSOR Assy is indicated.

6.2.2.2 PANEL WORKS

- Data on operations, such as the accumulated pulse-meter counts, hour-meter count, power-on count, and temperature detected by the sensor, are sent back. No other layers are nested below this layer, and there are no adjustment items.

	1	5	10	15	20	25	30	32
1			PANEL FACT.		VD1-10605-NTV-ATB			
	1		PANEL WORKS					
	2							
5	3		PM-B1	00001057M				
	4		PM-B2	00001062M				
	5		PM-B3	00001185M				
	6		PM-B4	00000688M				
	7		PM-B5	00000926M				
10	8							
	9		HR-MTR	000028H 02M				
	A		P-COUNT	0000082 TIMES				
	B		TEMP1	+33.8 / +75.1				
	C							
15	D							
16	E							

■ Key operation

- <DOWN> : Shifting to POWER DOWN
- <UP> : Shifting to PANEL INFORMATION
- <L/R> : Updating displayed information

← Temperature unit is " °C (Centigrade) ".

■ Contents of the Display item

- PM-B1 to B5: The accumulated pulse-meter counts for the 5 blocks on the screen are indicated. (the lowest-order digit represents millions of pulses.)
- HR-MTR: The hour-meter value (accumulated power-on hours) is indicated.
- P-COUNT: The accumulated power-on count is indicated.
- TEMP1: The current panel temperature and the historical maximum temperature recorded in memory are indicated. The range of temperature indication is from -50.0 to +99.9. (The temperature unit is " °C (Centigrade) ".)

6.2.2.3 POWER DOWN

- The power-down history is displayed. The last most 8 power-down histories are displayed with the hour-meter values that indicate the hours when power-downs occurred. No other layers are nested below this layer, and there are no adjustment items.

		1	5	10	15	20	25	30	32
1		PANEL	FACT.		VD1-10605-NTV-ATB				
	1	POWER	DOWN						
2		1ST		2ND		000328H	04M		
3									
4	1	X-DRV				000177H	16M		
5	2	Y-SUS	SCAN			000041H	44M		
6	3	SCAN				000041H	32M		
7	4	POWER	SCAN			000041H	29M		
8	5	ADRS				000013H	42M		
9	6	SCAN5V	X-DCDC			000012H	11M		
A	7	Y-DCDC				000000H	51M		
B	8								
C									
D									
E									

Key operation

- <DOWN> : Shifting to SHUT DOWN
- <UP> : Shifting to PANEL WORKS
- <L/R> : Updating displayed information

<Causes of power-down and corresponding OSD indications>

Cause of power-down	OSD Indication	Cause of power-down	OSD Indication
POWER SUPPLY Unit	P-PWR	ADDRESS Assy	ADRS
SCAN Assy	SCAN	X DRIVE Assy	XDRV
5 V power for SCAN Assy	SCAN5V	DC/DC converter for X drive	X-DCDC
Y DRIVE Assy	Y-DRV	X-drive SUS circuit	X-SUS
DC/DC converter for Y drive	Y-DCDC	Digital DC/DC converter	D-DCDC
Y-drive SUS circuit	Y-SUS	Unknown	UNKNOWN

- * When power-down is confirmed, the factor is displayed as "1st", "2nd", according to the accuracy order.
- * The power-down history is not recorded when the power-down occurred at the same place and same time.

6.2.2.4 SHUT DOWN

- The shutdown history is displayed. The last most 8 shutdown histories are displayed with the hour-meter values that indicate the hours when shutdowns occurred. No other layers are nested below this layer, and there are no adjustment items.

		1	5	10	15	20	25	30	32
1		PANEL	FACT.		VD1-10605-NTV-ATB				
	1	SHUT	DOWN						
2		MAIN		SUB		000328H	04M		
3									
4	1	TMP-NG	TEMP-H			000177H	16M		
5	2	SQ-LSI	BUSY			000041H	44M		
6	3	MD-IIC	DAC1			000041H	32M		
7	4	SQ-LSI	VER-HS			000041H	29M		
8	5	MD-IIC	BACKUP			000013H	42M		
9	6	SQ-LSI	BUSY			000012H	11M		
A	7								
B	8								
C									
D									
E									

Key operation

- <DOWN> : Shifting to PANEL-1 ADJ (+)
- <UP> : Shifting to POWER DOWN
- <L/R> : Updating displayed information

- * When there is detail information when shutdown occurred, the possible defective part is displayed as Sub information.

<Cause of shut-down and corresponding OSD Indication >

Cause of shut-down (MAIN)		Cause of shut-down (SUB)	
Item	OSD Indication	Item	OSD Indication
Drive Processing IC	SQ_LSI	Communication Error	RTRY
		Drive Stop	SQ-NON
		Communication Busy	BUSY
		Version mismatching (H/S) (M/S)	VER-HS, VER-MS
MDU-IIC	MD-IIC	MAIN EEPROM Communication Error	EEPROM
		BACKUP EEPROM Communication Error	BACKUP
		DAC1 Communication Error	DAC1
		DAC2 Communication Error	DAC2
Abnormally in RST2 power supply	RST2	-	-
Panel temperature	TMP-NG	High temperature of the panel	TEMP-H
		Low temperature of the panel	TEMP-L

6.2.2.5 PANEL-1 ADJ (+)

- Timing and voltage for the driving pulse are set. At third line of the screen, the WB (White Balance) table and frequency table indicating operation status are displayed, and at fifteenth line of the screen, the item for the upper nested layer (PANEL-1 ADJ [+]) is displayed. Pressing the ENTER/SET key shifts the screen to the next nested layer below for item selection.

		1	5	10	15	20	25	30	32
1		PANEL	FACT.		VD1-10605-NTV-ATB				
	1								[TBL1/60VS]
	2								
5	3								
	4								
	5								
	6								
	7								
10	8								
	9								
	A								
	B								
	C								
15	D	PANEL-1	ADJ	(+)					
16	E								

■ Key operation

- <DOWN> : Shifting to PANEL-2 ADJ (+)
- <UP> : Shifting to POWER DOWN
- <SET> : Shifting to the next nested layer

- When the screen is shifted to the next nested layer below, the item of the layer above is indicated at third line of the screen, and the item of the layer below is indicated at fifteenth line.
- The configuration of the menu screen is the same for any adjustment item that has lower layers.
- To confirm that the change in the SUS FREQ. setting has resulted in diminishing of AM radio interference in this layer, after changing the setting, turn the unit off then back on.

		1	5	10	15	20	25	30	32
1		PANEL	FACT.		VD1-10605-NTV-ATB				
	1	PANEL-1	ADJ						[TBL1/60VS]
	2								
5	3								
	4								
	5								
	6								
	7								
10	8								
	9								
	A								
	B								
	C								
15	D	VOL	OFFSET	<=>					: 134
16	E								

■ Key operation

- <DOWN> : Shifting to the next item
- <UP> : Shifting to the previous item
- <RIGHT> : Adding by one to the adjustment/setting value
- <LEFT> : Subtracting by one from the adjustment/setting value
- <VOL+> : Adding by 10 to the adjustment/setting value
- <VOL-> : Subtracting by 10 from the adjustment/setting value
- <SET> : Determining the adjustment/setting value and shifting to the upper layer

A

6.2.2.6 PANEL-2 ADJ (+)

- White balance can be adjusted by adjusting R, G, and B gain. Pressing the ENTER/SET key shifts the screen to the next nested layer below for item selection.

		1	5	10	15	20	25	30	32
1		PANEL	FACT.		VD1-10605-NTV-ATB				
	1								[TBL1 / 60VS]
	2								
5	3								
	4								
	5								
	6								
B	7								
10	8								
	9								
	A								
	B								
	C								
15	D	PANEL-2	ADJ	(+)					
16	E								

Key operation

- <DOWN> : Shifting to PANEL FUNCTION (+)
- <UP> : Shifting to PANEL-1 ADJ (+)
- <SET> : Shifting to the next nested layer

C

		1	5	10	15	20	25	30	32
1		PANEL	FACT.		VD1-10605-NTV-ATB				
	1	PANEL-2	ADJ						[TBL1 / 60VS]
	2								
5	3								
	4								
	5								
	6								
	7								
10	8								
	9								
	A								
	B								
D	C								
15	D	R-HIGH	<=>						: 2 5 4
16	E								

Key operation

- <DOWN> : Shifting to the next item
- <UP> : Shifting to the previous item
- <RIGHT> : Adding by one to the adjustment/setting value
- <LEFT> : Subtracting by one from the adjustment/setting value
- <VOL+> : Adding by 10 to the adjustment/setting value
- <VOL-> : Subtracting by 10 from the adjustment/setting value
- <SET> : Determining the adjustment/setting value and shifting to the upper layer

The ABL/WB adjustment values are grouped into up to four tables, depending on the drive sequences. The adjustment value for the actually driven table is displayed. The number of the adjustment table and the drive sequence currently selected are displayed on the right side of the third line as the On-Screen display.

Drive sequence and adjustment table

Sequence Name	Video50	Video60	Video72	Video75	PC60
Adjustment Value Table	TBL2	TBL1	TBL1	TBL3	TBL4

6.2.2.7 PANEL FUNCTION (+)

- A setting for panel degradation correction can be made. Pressing the ENTER/SET key shifts the screen to the next nested layer below for item selection.

		1	5	10	15	20	25	30	32
1		PANEL	FACT.		VD1-10605-NTV-ATB				
	1								[TBL1/60VS]
	2								
5	3								
	4								
	5								
	6								
	7								
10	8								
	9								
	A								
	B								
	C								
15	D	PANEL	FUNCTION	(+)					
16	E								

Key operation

- <DOWN> : Shifting to ETC.(+)
- <UP> : Shifting to PANEL-2 ADJ (+)
- <SET> : Shifting to the next nested layer

		1	5	10	15	20	25	30	32
1		PANEL	FACT.		VD1-10605-NTV-ATB				
	1	PANEL	FUNCTION						[TBL1/60VS]
	2								
5	3								
	4								
	5								
	6								
	7								
10	8								
	9								
	A								
	B								
	C								
15	D	R-LEVEL	<=>						:LV-3
16	E								

Key operation

- <DOWN> : Shifting to the next item
- <UP> : Shifting to the previous item
- <RIGHT> : Adding by one to the adjustment/setting value
- <LEFT> : Subtracting by one from the adjustment/setting value
- <SET> : Determining the adjustment/setting value and shifting to the upper layer

6.2.2.9 RASTER MASK SETUP (+)

- This menu set the RASTER MASK and the drive sequence at RASTER MASK state. Pressing the ENTER/SET key shifts the screen to the next nested layer below for item selection.

		1	5	10	15	20	25	30	32																				
1		PANEL FACT. VD1-10605-NTV-ATB																											
	1	[TBL1/60VS]																											
	2																												
5	3																												
	4																												
	5																												
	6																												
	7																												
10	8																												
	9																												
	A																												
	B																												
	C																												
15	D	RASTER MASK SETUP (+)																											
16	E																												

■ Key operation

- <DOWN> : Shifting to PATTERN MASK SETUP (+)
- <UP> : Shifting to ETC. (+)
- <SET> : Shifting to the next nested layer

		1	5	10	15	20	25	30	32																							
1			P	A	N	E	L	F	A	C	T	.		V	D	1	-	1	0	6	0	5	-	N	T	V	-	A	T	B		
		1	R	A	S	T	E	R		M	A	S	K		S	E	T	U	P		[T	B	L	1	/	6	0	V	S]	
		2																														
5		3																														
		4																														
		5																														
		6																														
		7																														
10		8																														
		9																														
		A																														
		B																														
		C																														
15		D	R	S	T		M	A	S	K		0	1																			
16		E																														

■ Key operation

- <DOWN> : Shifting to the next MASK
- <UP> : Shifting to the previous MASK
- <RIGHT> : Changing MASK sequence (+)
- <LEFT> : Changing MASK sequence (-)
- <SET> : Determining the adjustment/setting value and shifting to the upper layer

- The MASK indication sequence can be changed among 48V, 50V, 60V, 72V, 75V and 60P using the Right or Left key. The selected sequence and the ABL/WB table are retained until the mask is turned off.

A 6.2.2.10 PATTERN MASK SETUP (+)

- This menu set the PATTERN MASK and the drive sequence at PATTERN MASK state. Pressing the ENTER/SET key shifts the screen to the next nested layer below for item selection.

	1	5	10	15	20	25	30	32
1			PANEL FACT.		VD1-10605-NTV-ATB			
	1							[TBL1 / 60VS]
	2							
5	3							
	4							
	5							
	6							
B	7							
10	8							
	9							
	A							
	B							
	C							
15	D		PATTERN MASK SETUP (+)					
16	E							

■ Key operation

- <DOWN> : Shifting to COMBI MASK SETUP (+)
- <UP> : Shifting to RASTER MASK SETUP (+)
- <SET> : Shifting to the next nested layer

	1	5	10	15	20	25	30	32
1			PANEL FACT.		VD1-10605-NTV-ATB			
	1		PATTERN MASK SETUP					[TBL1 / 60VS]
	2							
5	3							
	4							
	5							
	6							
	7							
10	8							
	9							
	A							
	B							
	C							
15	D		PTN MASK 01					: 60V
16	E							

■ Key operation

- <DOWN> : Shifting to the next MASK
- <UP> : Shifting to the previous MASK
- <RIGHT> : Changing MASK sequence (+)
- <LEFT> : Changing MASK sequence (-)
- <SET> : Determining the adjustment/setting value and shifting to the upper layer

- The MASK indication sequence can be changed among 48V, 50V, 60V, 72V, 75V and 60P using the Right or Left key. The selected sequence and the ABL/WB table are retained until the mask is turned off.

6.2.2.11 COMBI MASK SETUP (+)

- This menu set the COMBI MASK and the drive sequence at COMBI MASK state. Pressing the ENTER/SET key shifts the screen to the next nested layer below for item selection.

		1	5	10	15	20	25	30	32
1		PANEL	FACT.		VD1-10605-NTV-ATB				
	1								[TBL1/60VS]
	2								
5	3								
	4								
	5								
	6								
	7								
10	8								
	9								
	A								
	B								
	C								
15	D	COMBI	MASK	SETUP	(+)				
16	E								

■ Key operation

- <DOWN> : Shifting to PANEL INFORMATION
- <UP> : Shifting to PATTERN MASK SETUP (+)
- <SET> : Shifting to the next nested layer

		1	5	10	15	20	25	30	32
1		PANEL	FACT.		VD1-10605-NTV-ATB				
	1	COMBI	MASK	SETUP					[TBL1/60VS]
	2								
5	3								
	4								
	5								
	6								
	7								
10	8								
	9								
	A								
	B								
	C								
15	D	CMB	MASK	01					: 60V
16	E								

■ Key operation

- <DOWN> : Shifting to the next MASK
- <UP> : Shifting to the previous MASK
- <RIGHT> : Changing MASK sequence (+)
- <LEFT> : Changing MASK sequence (-)
- <SET> : Determining the adjustment/setting value and shifting to the upper layer

- The MASK indication sequence can be changed among 48V, 50V, 60V, 72V, 75V and 60P using the Right or Left key. The selected sequence and the ABL/WB table are retained until the mask is turned off.

6.2.3 OPTION

Operation item

A

No.	Function	Content	RS-232C
6.2.3.1	EDID WRITE MODE <=>	DISABLE <=> ENABLE	----
6.2.3.2	ANTENNA MODE <=>	CABLE <=> AIR	----
6.2.3.3	AFT <=>	OFF <=> ON (Controls AFT action)	----
6.2.3.4	SYNC DET (+)	Exclusively used for technical analysis	----
6.2.3.5	CC (+)	Exclusively used for technical analysis	----

6.2.3.1 EDID WRITE MODE <=>

B

Exclusively used for production line.

6.2.3.2 ANTENNA MODE <=>

Exclusively used for production line.

6.2.3.3 AFT <=>

Exclusively used for production line.

C

6.2.3.4 SYNC DET (+)

Exclusively used for technical analysis (details omitted).

6.2.3.5 CC (+)

Exclusively used for technical analysis (details omitted).

D

E

F

6.2.4 INITIALIZE

Operation item

No.	Function	Content	RS-232C
6.2.4.1	SIDE MASK LEVEL (+)	Configure the color of the side mask.	SML
6.2.4.2	FINAL SETUP (+)	Initialize flash memorys on virgin product status	FST
6.2.4.3	HMG/HG SERVICE MODE	Enter HMG/HG SERVICE MODE	----
6.2.4.4	Wide XGA AUTO <=>	Exclusively used for technical analysis.	----

Note: When there is an altered history due to an open TRAP SW, if the "DISPLAY" key is held for at least 5 seconds on the above menu, the altered history will be cleared and the unit will be back to normal.

6.2.4.1 SIDE MASK LEVEL (+)

1	5	10	15	20	25	30	35	40
1	INITIALIZE	VD1-30601-NTV-AHB						
5								
10								
15	SIDE MASK LEVEL (+)							
16								

To configure sidemask level (To adjust the values, input signal is required).

Display	Content	RS-232C
SIDE MASK LEVEL <=>	Adjust Side Mask level (Adjustable range: 000 to 255)	SML

6.2.4.2 FINAL SETUP (+)

1	5	10	15	20	25	30	35	40
1	INITIALIZE	VD1-30601-NTV-AHB						
5	FINAL SETUP							
10								
15	DATA RESET <=>	: NO						
16								

- To reset each memory values to factory default values. Factory command is "FST".
- When the configuration is set to <NO> and the [ENTER/SET] key is pressed, no action is taken and the menu returns to previous screen.
- When the configuration is set to <YES> and the [ENTER/SET] key is pressed for 5 seconds, the reset action executes.

Be sure to disconnect and connect the AC cable after FINAL SETUP.
When replacing the MAIN Assy, the FINAL SETUP is required.

(3) Each item explanation (Example)

```

① ① PTP Support : Disabled
② ② T: Bus=03 Lev=01 Prnt=01 Port=00 Cnt=01 Dev#= 2 Spd=480 MxCh= 0
③ ③ D: Ver= 2.00 Cls=00(>ifc ) Sub=00 Prot=00 MxPS=64 #Cfgs= 1
④ ④ P: Vendor=0dda ProdID=2026 Rev= 1.4f
⑤ ⑤ S: Manufacturer=ICSI
⑥ ⑥ S: Product=USB2.0 Card Reader
⑦ ⑦ S: SerialNumber=0000001
⑧ ⑧ C:* #Ifs= 1 Cfg#= 1 Atr=80 MxPwr=500mA
⑨ ⑨ I: If#= 0 Alt= 0 #EPs= 2 Cls=08(stor.) Sub=06 Prot=50 Driver=usb-storage
⑩ ⑩ E: Ad=82(I) Atr=02(Bulk) MxPS= 512 Ivl=0ms
⑪ ⑪ E: Ad=01(O) Atr=02(Bulk) MxPS= 512 Ivl=0ms

```

① PTP Support

Disable	PTP Non-Support	String
Enable	PTP Support	String

② T (Topology info)

Bus	Bus Number	Decimal
Lev	Level in topology for this bus	Decimal
Prnt	Parent Device Number	Decimal
Port	Connector/Port on Parent for this device	Decimal

Cnt	Count of devices at this level	Decimal
Dev#	Device Number	Decimal
Spd	Device Speed in Mbps	Decimal
MxCh	Max Children	Decimal

④ D (Device descriptor info)

Ver	Device USB version	Hexadecimal
Cls	Device Class	Hexadecimal
Sub	Device Sub Class	Hexadecimal
Prot	Device Protocol	Hexadecimal
MxPS	Max Packet Size of Default Endpoint	Decimal
#Cfgs	Number Configurations	Decimal

④ P (Product ID info)

Vendor	Vendor ID code	Hexadecimal
ProdID	Product ID code	Hexadecimal
Rev	Product revision number	Hexadecimal

⑤ S (String descriptor info - 1)

Manufacturer	String
--------------	--------

⑥ S (String descriptor info - 2)

Product	String
---------	--------

⑦ S (String descriptor info - 3)

SerialNumber	String
--------------	--------

⑧ C (Configuration descriptor info)

#Ifs	Number of Interfaces	Decimal
#Cfg	Configuration Number	Decimal
Atr	Attributes	Hexadecimal
MxPwr	MaxPower in mA	Decimal

⑨ I (Interface descriptor info)

If#	Interface Number	Decimal
Alt	Alternate Setting Number	Decimal
#Eps	Number of Endpoints	Decimal
Cls	Interface Class	Hexadecimal(String)
Sub	Interface Sub Class	Hexadecimal
Prot	Interface Protocol	Hexadecimal
Driver	Driver name	String

⑩ E (Endpoint descriptor info)

⑪ E (Endpoint descriptor info)

Ad	Endpoint Address (I=In, O=Out)	Hexadecimal(String)
Atr	Attributes	Hexadecimal(String)
MxPS	Endpoint Max Packet Size	Decimal
Ivl	Interval (max) between transfers	Decimal

2. End method

It is the same as the case that Home Gallery displays.

6.2.4.4 Wide XGA AUTO <=>

Exclusively used for technical analysis (details omitted).

1234


7. DISASSEMBLY

7.1 FLOWCHART OF REMOVAL ORDER FOR THE MAIN PARTS AND BOARDS

Note: Even if the unit shown in the photos and illustrations in this manual may differ from your product, the procedures described here are common.

Flowchart of removal order for the main parts and boards


It is efficient to proceed with removal of the main parts and boards in the order shown in the chart below:



Disassembly

Speaker System

- ① Disconnect the speaker cables.
- ② Remove the three screws.
- ③ Remove the speaker system.
- ④ Remove the three brackets by removing the six screws.



A

Disassembly

1 Rear Case (508F)

● Function button panel




- ① Remove the two screws.
- ② Remove the function button panel.

● Side input cover

- ③ Remove the two screws.
- ④ Remove the side input cover.


● Power button case (508F)

- ⑤ Remove the two screws.
- ⑥ Remove the power button case.



● Rear case (508F)


- ① Remove the 20 screws. (AMZ30P060FTB)
- ② Remove the 10 screws. (TBZ40P080FTB)
- ③ Remove the two screws. (ABA1332)
- ④ Remove the one screw. (ABA1341)
- ⑤ Remove the rear case (508F).



■ Tightening sequence for the screws when assembling

When assembling the rear case (508F), tighten the screws in the following sequence:

- ① Tighten the two screws.
- ② Tighten three screws.
- ③ Tighten the two screws.
- ④ Tighten the eight screws.
- ⑤ Tighten other screws.



2 Access to PCB Assys

● SIDE IO Assy

- ① Remove the four screws.
- ② Remove the two screws.
- ③ Remove the four screws.
- ④ Remove the side input panel (8U).

● 50F X DRIVE Assy


- ① Remove the two screws.
- ② Remove the side input shield with PCB.
- ③ Diagnose the 50F X DRIVE Assy.

● 50F Y DRIVE Assy

- ① Remove the two screws.
- ② Remove the function button shield with PCB.
- ③ Diagnose the 50F Y DRIVE Assy.


• For 50F X DRIVE Assy

Side input shield




• For SIDE IO Assy

SIDE IO Assy




• For 50F Y DRIVE Assy

Function button shield SIDE KEY Assy



Caution:

As the two capacitors on the 50F Y DRIVE Assy are located very close to sub frame L Assy 507, if the former Assy is tilted toward the latter Assy when disassembling, they may come into contact with the latter Assy. Therefore, before removing the 50F Y DRIVE Assy, be sure to tilt the capacitors, as shown in the photo (away from sub frame L Assy 507).




Sub frame L Assy 507

Capacitor

50F Y DRIVE Assy

FHD FAN CONNECT Assy




50F Y DRIVE Assy

50F X DRIVE Assy

FHD POWER SW Assy



Note:

When removing the POWER SUPPLY Unit, be sure to remove not only the POWER SUPPLY Unit but entire PCB base.




POWER SUPPLY Unit
PCB base


■ Styling of jumper wires around the FAN motor



NG



OK






A

● MAIN Assy

- ① Disconnect cables, connectors, as required.
- ② Remove the two screws.
- ③ Remove the two screws.
- ④ Remove the POD cover.
- ⑤ Remove the POD stay A with PCB.

■ How to remove the bridge connector connecting between the MAIN and TANSHI Assys

- (1) Grip the two short edges of the connector with longnose pliers.
- (2) Insert a finger between the longnose pliers and the board to protect the board and the mounted parts on the board from accidental damage by the pliers then, using your finger as a fulcrum and the pliers as a lever, pry the connector upward to remove it.



B

C





3 Terminal Panel B (50U)

- ① Remove the four screws.
- ② Remove the two screws.
- ③ Remove the 10 screws.
- ④ Remove the four screws.
- ⑤ Remove the terminal panel B (50U).

Note:

The wiring shown in the photo is different from the actual wiring, because the product in the photo is a prototype.
Upon servicing, be sure to restore the original wiring of the unit after repair work.




D

E

■ Tightening sequence for the screws when assembling



When assembling the terminal panel B (50U), tighten the screws in the following sequence:

- ① Tighten the screw.
- ② Tighten the screw.
- ③ Tighten other screws.




4 Front Case Assy (508FU)

- ① Remove the four rivets.
- ② Pull the lower part of the Front case Assy (508FU) toward you and out.
- ③ Remove the Front case Assy (508FU), by pulling it upward.





5 Access to 50F DIGITAL Assy

- ① Disconnect the cable.
- ② Remove the two screws.
- ③ Remove the four screws.




- ④ Lift the Multi base section to the direction of the arrow.



6 Exchange of SCAN IC


● Front chassis HT (508F) Assy

- ① Remove the four screws.
- ② Remove the two screws.
- ③ Remove the front chassis HT (508F) Assy.




● Front chassis HB Assy (50)

- ① Disconnect the two jumper wires.
- ② Remove the one screw.
- ③ Remove the FHD RLS Assy.
- ④ Remove the two screws.
- ⑤ Remove the two screws.
- ⑥ Remove the two screws.
- ⑦ Remove the front chassis HB Assy (50).



● Panel holder V1 (50), V2 (50)

- ① Remove the two screws.
- ② Unhook the six hooks.
- ③ Remove the panel holders V1 (50) and V2 (50).





A

● Front chassis VL (508F)

- ① Loosen the jumper wire.
- ② Remove the three screws.
- ③ Remove the front chassis VL (508F).

↓


Exchange




Notes for Three pieces connector 40P*

Three pieces connector 40P is a precision part. Pay attention to the handling.

Connecting Method



Disconnecting Method



SERVICE PRECAUTIONS

Be careful in handling this product, because scratches on cabinet coating are easily noticeable.
When working on this unit, be sure to place the cabinet on a piece of soft cloth for protection.

(1) Grille Assy

The Grille Assy is secured to the baffle plate with two-sided tape and bosses. When removing the Grille Assy, it is necessary to wear cotton gloves.

● Disassembly

1. Insert the tip of your gloved finger into the gap between the Grille Assy in front and the corner of the baffle plate so that the Grille Assy is slightly lifted.



2. Insert the gloved finger to the extent of the second joint into the gap between the cabinet and the Grille Assy.




3. Alternately and gradually lift the left and right sides of the Grille Assy by about 5 cm, sliding gloved fingers along the cabinet. When lifting the Grille Assy, be sure to lift the left and right sides alternately, but not both sides simultaneously.



Note: Be careful not to bend the Grille Assy too far. Otherwise, it may be damaged.

OK: Good example **NG:** Bad example



● Reassembly

Remove the old two-sided tape attached to the rear side of the Grille Assy and the front side of the baffle, and adhere new two-sided tape. Press the bosses into the baffle plate and press the entire grill into position.
(Press the bosses from the woofer frame.)

(2) Woofer (Disassembly)

The woofer is secured to the baffle plate with four screws from the inside. To remove the woofer, first remove the baffle plate.

● Reassembly

When reassembling the woofer, place it so that its ⊕ terminal is suitable for the inside. Tighten the screws to the baffle.

(3) Tweeter (Disassembly)


The tweeter is secured to the baffle plate with two screws from the inside. To remove the tweeter, first remove the baffle plate.

● Reassembly

When reassembling the tweeter, ⊕ terminal is in the topside.


Network Assy (Caution)

When removing the Network Assy, pull it out a little at a time from alternate sides, because it is seated tightly.



Baffle Assy (Caution)

When reassembling the cabinet and the baffle plate, secure the screws in the order shown in the figure below:



12

1

2

3

4

8. EACH SETTING AND ADJUSTMENT



- A
1. At shipment, the unit is adjusted to its best conditions. Normally, it is not necessary to readjust even if an assembly is replaced. If the adjustment is shifted or if it becomes necessary to readjust because of part replacement, etc., perform the adjustment as described below.
 2. Any value changed in Service/Factory mode will be stored in memory as soon as it is changed. Before readjustment, take note of the original values for reference in case you need to restore the original settings.
 3. Use a stable AC power supply.

B

8.1 ADJUSTMENT REQUIRED WHEN THE UNIT IS REPAIRED OR REPLACED

C

■ When any of the following assemblies is replaced

POWER SUPPLY Unit	➡	Refer to “8.3 HOW TO CLEAR HISTORY DATA” and “8.6 PRECAUTION ON REPLACEMENT OF THE POWER SUPPLY UNIT”.
DIGITAL Assy	➡	Writing of backup data is required. Refer to the “8.2 BACKUP OF THE EEPROM (DIGITAL ASSY)”.
X DRIVE Assy	➡	No adjustment required
Y DRIVE Assy	➡	No adjustment required
Service Panel Assy	➡	Refer to “8.3 HOW TO CLEAR HISTORY DATA” and “8.4 ADJUSTMENTS WHEN THE SERVICE PANEL ASSY IS REPLACED”.
MAIN Assy (*)	➡	No adjustment required
PANEL SENSOR Assy	➡	Writing of backup data is required. Refer to the “8.2 BACKUP OF THE EEPROM (DIGITAL ASSY)”.
Other assemblies	➡	No adjustment required

E

Note: Checking the Cable Card ID

- The PDP has a slot for a cable card that is used for managing your information by the cable TV company. The following procedure allows you to check your Cable Card ID and the Host ID.
1. Press HOME MENU.
 2. Select “Tuner Setup”. (⬆/⬇ then ENTER)
 3. Select “Channel Setup”. (⬅/➡ then ENTER)
 4. Select “POD ID”. (⬆/⬇)
 - The Host ID and Cable Card ID appear.
 5. Press HOME MENU to exit the menu.

F

(*) : When replacing the MAIN Assy, be sure to perform the FINAL SETUP.

Notes on replacing parts

For the parts described in the list below, replacement is required for the whole Assy, not only the defective part. If any part listed below is identified as defective and needs replacement, replace the whole Assy, and make necessary adjustments after replacement.

Reason: The whole Assy must be replaced, because adjustments and data rewriting for the Assy at the level of production line are required.

PCB Assy No.	Assy Name	Parts that Require Whole-Assy Replacement		
		Ref No.	Function Name	Part No.
AWV2457	MAIN Assy	IC4601	AV switch	R2S11006FT
		IC4701	RGB switch	R2S11001FT
		IC4703	EEPROM	BR24L01AFJ-W
		IC4801	MAIN VDEC	CM0048BF
		IC5001	A/D Converter	AD9985KSTZ-110
		IC5102	EEPROM	BR24L02FV-W
		IC5103	EEPROM	BR24L02FV-W
		IC5104	EEPROM	BR24L02FV-W
		IC5203	EEPROM	BR24L02FV-W
		IC6401	SYSTEM IC	BCM7038KPB1G-B2
		IC6602	DDR SDRAM	K4H561638H-UCB3
		IC6603	DDR SDRAM	K4H561638H-UCB3
		IC6604	DDR SDRAM	K4H561638H-UCB3
		IC6605	DDR SDRAM	K4H561638H-UCB3
		IC6902	Flash ROM	AGC1057
		IC8204	Flash ROM	AGC1049
		IC8301	Flash UCOM	AGC1037
		IC8602	Flash ROM	AGC1039
AWV2510	50F X DRIVE Assy	• Parts of X D-D CON BLOCK		
AWV2511	50F Y DRIVE Assy	• Parts of Y MAIN D-D CON BLOCK 1 • Parts of Y MAIN D-D CON BLOCK 2		

POWER SUPPLY Unit



The assembly must be replaced as a unit, and no part replacement is allowed.

MAIN Assy



No adjustment is required after replacement of parts other than those mentioned above.

DIGITAL Assy



No adjustment is required after replacement of parts other than those mentioned above.

X DRIVE Assy



No adjustment is required after replacement of parts other than those shown in "8.5 ADJUSTMENTS WHEN THE DRIVE ASSYS ARE REPLACED."

Y DRIVE Assy



No adjustment is required after replacement of parts other than those shown in "8.5 ADJUSTMENTS WHEN THE DRIVE ASSYS ARE REPLACED."

ADDRESS Assy



No adjustment required

PANEL SENSOR Assy



No adjustment is required after replacement of parts other than those mentioned above.

TANSHI Assy



No adjustment required

1 2 3 4

8.2 BACKUP OF THE EEPROM (DIGITAL ASSY)

A

■ Outline

Adjustment data are stored in the EEPROM (4K) on the DIGITAL Assy in the production process. Those adjustment data are also automatically stored in the EEPROM (for backup) on the PANEL SENSOR Assy.
If the DIGITAL Assy is replaced, those adjustment data for backup can be copied from the EEPROM on the PANEL SENSOR Assy to a new DIGITAL Assy.

■ Backed up data

- B
- Drive voltage adjustment value
 - Hour-meter count
 - Pulse-meter count
 - Panel white balance adjustment value
 - Serial No.
 - Drive waveform adjustment value
 - P-ON counter value
 - PD/SD histories

■ How to copy backup data


1. When the DIGITAL Assy is replaced with one for service (usual service)

Adjustment data can be restored by copying the data backed up in the PANEL SENSOR Assy to the EEPROM on a new DIGITAL Assy.
The EEPROM on the new DIGITAL Assy has no adjustment data, and the EEPROM for backup in the PANEL SENSOR Assy has adjustment data. After replacing the DIGITAL Assy, enter PANEL FACT. mode, display the PANEL INFORMATION page, then check if "NO DATA!" is set for "DIG. EEP" and "ADJUSTED" is set for "BACKUP". Then, proceed in the following steps:

C

(1) Copying, using the Factory menu

- ① Plug in the AC cord, press the Power switch on the unit to set it to ON, then enter Standby mode.
② Turn on the power, using the remote control unit, then enter Panel Factory mode.
Copy the backup data, as shown in the figure below.



- ③ Turn the power off.
- After the DIGITAL Assy is replaced with one for service, be sure to check if "NO DATA!" is set for "DIG. EEP" on the PANEL INFORMATION page of the PANEL FACT. mode.
 - If copying of the backup data fails in the above procedure, the red LED lights, and the blue LED flashes, as a warning that no backup data were copied.
 - If both the DIGITAL and PANEL SENSOR Assys are to be replaced, first replace the PANEL SENSOR Assy, turn the unit on and back off again, then replace the DIGITAL Assy.

E

(2) Copying, using the RS-232C commands


- ① Turn on the unit, using the remote control unit or by issuing the PON command. Then issue the FAY command.
② Issue the BCP command to transfer the data stored in the EEPROM for backup.
③ Turn the power off.

2. When a secondhand DIGITAL Assy that had been mounted in another product is to be reused

As adjustment data for another product are already stored in the secondhand DIGITAL Assy, first delete those data then copy the backup data stored in the EEPROM on the PANEL SENSOR Assy.

(1) Copying, using the Factory menu

- ① Plug in the AC cord, press the Power switch on the unit to set it to ON, then enter Standby mode.
- ② Turn on the power, using the remote control unit, then enter Panel Factory mode.
Copy the backup data, as shown in the figure below.



- ③ Turn the power off.

Note:

If the secondhand DIGITAL Assy is mounted in the product then the unit is turned on then back off again, the data in the EEPROM on the DIGITAL Assy are copied over the EEPROM in the PANEL SENSOR Assy. Thus the backup data can never be restored. During the first power-on after the DIGITAL Assy is replaced, be sure to enter Factory mode to copy the backup data. Or, before removing the secondhand DIGITAL Assy from the original product, delete the adjustment data on it, using the Factory mode (DIGITAL EEPROM: DELETE), mount it to the product to be repaired, then copy the data from the backup EEPROM.

(2) Copying, using the RS-232C commands


- ① Turn on the unit, using the remote control unit or by issuing the PON command. Then issue the FAY command.
- ② Issue the UAJ command to delete data stored in the EEPROM on the DIGITAL Assy.
- ③ Issue the BCP command to transfer the data stored in the EEPROM for backup.
- ④ Turn the power off.

3. In a case where normal backup data are not stored in the backup EEPROM because the EEPROM on the DIGITAL Assy is defective, etc., and where manually adjusted values are to be applied to the product

Note: In this section, it is assumed that settings for various items have been completed, using Factory menu or RS-232C commands.

(1) Method using the Factory menu

- ① Set various setting/adjustment values.
- ② Proceed in the following steps.



- ③ Turn the power off.

Note:

When a DIGITAL Assy with an EEPROM in which adjustment data are stored is mounted, this step is not required after manual adjustment. ("DIGITAL EEPROM: REPAIR" is not indicated.)

(2) Method using the RS-232C commands

Issue the FAJ command.

■ Clearance of various logs after the Assys are replaced

Besides adjustment data, data on accumulated power-on time and logs on defective parts of the product are backed up. Some of those data must be cleared after the Assys are replaced for service.

(1) Clearance of logs, using the RS-232C commands


Item	Content	When the Panel is replaced	When the POWER SUPPLY Unit is replaced	When the Other parts is replaced	RS-232C Commands
Hour-meter	Accumulated power-on time	Must be cleared	No need to be cleared	No need to be cleared	CHM
Pulse-meter	Accumulated number of pulses emitted	Must be cleared (mandatory)	No need to be cleared	No need to be cleared	CPM
Shutdown history	Cause of an SD and hour-meter count	Must be cleared	No need to be cleared	No need to be cleared	CSD
Power-down history	Cause of an PD and hour-meter count	Must be cleared	No need to be cleared	No need to be cleared	CPD
Power-on counter	Relay-on count	No need to be cleared	Must be cleared (mandatory)	No need to be cleared	CPC
MAX TEMP	Historical max. temperature	Must be cleared	Must be cleared	Must be cleared	CMT

Notes:

- As the pulse-meter count is used for each correction function, it must be cleared when an Assy relevant to correction functions is replaced.
- When clearing logs, using the RS-232C commands, first enter Factory mode (by issuing FAY or PFY), then issue the corresponding command.

(2) Clearance of logs, using the Factory menu

- Plug in the AC cord, press the Power switch on the unit to set it to ON, then enter Standby mode.
- Turn on the power, using the remote control unit, then enter Panel Factory mode.
Delete various logs, as shown in the figure below.



- Turn the power off.

1 2 3 4

8.4 ADJUSTMENT WHEN THE SERVICE PANEL ASSY IS REPLACED


A After the panel is replaced with one for service, voltage margin adjustment is required.

■

[Preparation]

Basically, voltage margin adjustment is performed using the Panel Factory menu.
After the panel is replaced and the unit is turned on, clear the pulse meter first.
For details on how to clear the pulse meter, see "8.3 HOW TO CLEAR HISTORY DATA".

- B
- *1: As various corrections are made referring to the pulse-meter count to calculate how long the panel has been used, if adjustment of the panel for service is performed without clearing the pulse-meter count, proper adjustments will not be performed.
 - *2: The drive sequence for 60-Hz video is used for adjustment. When adjustment is made using the Panel Factory menu, the current drive sequence is displayed on the screen, as shown in the figure below. Make sure that 60VS is always indicated during adjustment.



D

[Supplement]










■ In the "PANEL-1ADJ" layer, the Panel White Balance value is reset to default, Panel Gamma is set to Straight, Noise is set to OFF, LUT mode is set to ON and Reset active control is set to OFF.
In this case, "- - - /****" (**** represents the current drive sequence) is displayed on the third line of the On-Screen display during Panel Factory mode.

If adjustment is performed using RS-232C commands, the following commands must be transmitted for preparation:

- E
- [PAV S00] : To set panel drive mode to Factory
 - [VFQ S03] : To set Drive Sequence to Video 60-Hz
 - [WBI S01] : To temporarily reset the Panel WB adjustment value to default (WBI S00 cancels this setting.)
 - [PGR S00] : To set the gamma R value to that for Factory mode
 - [PGG S00] : To set the gamma G value to that for Factory mode
 - [PGB S00] : To set the gamma B value to that for Factory mode
 - [DIZ S03] : Dither ON, L dither ON, noise OFF.
 - [\$1800000001] : LUT mode ON
 - [\$1000003F00] : Reset active control OFF.

*: If the unit is shut down during the above adjustment flow, resend the above commands from the beginning.

Overview




Note on voltage calculation

When calculating the setting voltage, round off to get rid of the fractional part.

Range of margin measuring

Read the voltage within the hysteresis (stricter value).



Definition of limits for the voltage margins (abnormal lit/dead cells)

Abnormal lit cells:

- Five or fewer abnormal cells on the whole screen
- Two or fewer abnormal cells within a radius of 1 cm

Abnormal dead cells

- Fifteen or fewer abnormal cells on the whole screen
- Two or fewer abnormal cells within a radius of 1 cm

*: Abnormal cells visually recognizable at a distance of 1 meter from the panel must be counted.

*: Cells displayed abnormally for less than one second are not counted as abnormal cells.

Definition of tones for the measuring signals

FHD signal (1920*1080)/Video 60-Hz sequence
/Dither: ON, L dither: ON, noise: OFF

White	RST MASK 01 (R 1023 /G 1023 /B 1023)
Red	RST MASK 02 (R 1023 /G 0 /B 0)
Green	RST MASK 03 (R 0 /G 1023 /B 0)
Pink	RST MASK 10 (R 1023 /G 626 /B 1023)
Light blue	RST MASK 12 (R 626 /G 1023 /B 1023)
Red 1023+	RST MASK 15 (R 1023 /G 120 /B 120)
Green 1023+	RST MASK 16 (R 120 /G 1023 /B 120)
Cyan 3SF	RST MASK 22 (R 0 /G 169 /B 169)

Preparation before adjustment

[Replacement with the panel for service is completed.]

Procedures for resetting corrections for change over time

Turn the unit on. / [PON]

Enter Factory mode. / [FAY]

Set PM/B1-B5 to CLEAR (to clear the pulse meter). / [CPM]

Set HR-MTR to CLEAR (to clear the hour meter). / [CHM]

Turn the unit off. / [POF]

Procedures for stabilizing the panel before adjustment

Turn the unit on. / [PON]

Enter Factory mode. / [FAY]

Enter the initial values for the panel for service.

VOL SUS (127 fixed) / [VSU 127]

VOL OFFSET (VOF adjustment voltage) reduction / [VOF ***]

VOL RST P (VRP adjustment voltage) reduction / [VRP ***]

VOL XPOFS1 (087 fixed) / [VX1 087]

VOL XPOFS2 (140 fixed) / [VX2 140]

VOL YNOFS3 (VY3 adjustment voltage) reduction+10 / [VY3 ***]

VOL YNOFS4 (VY4 adjustment voltage) reduction / [VY4 ***]

VOL YNOFS1 (VY3 adjustment voltage) reduction-21 / [VY1 ***]

Display RST MASK 01 (white). / [MKS S51]

Select Video 60-Hz sequence. / [VFQ S03]

Perform aging for 5 minutes.

Indication example of the adjustment label of service panel

AWV9999- VOF=35V
VRP=170V VY3=184+α V VY4=200
Hour Meter_____H
 Data 07/05/24 Chassis CXX99999
 Time 18:27 Pnl FTEST123456

Note: α V sets adjustment value to 10.

* To store the [VFQ S03] command in memory, transmit it after displaying the mask.

[To the Main flowchart (1)]

Note: If you perform the adjustment by RS-232C commands, the following commands must be added before going to the main flowchart (1):

[PAV S00] : To set panel drive mode to Factory

[VFQ S03] : To set Drive Sequence to Video 60-Hz

[WBI S01] : To temporarily reset the Panel WB adjustment value to default (WBI S00 cancels this setting.)

[PGR S00] : To set the gamma R value to that for Factory mode

[PGG S00] : To set the gamma G value to that for Factory mode


[PGB S00] : To set the gamma B value to that for Factory mode

[DIZ S03] : Dither ON, L dither ON, noise OFF.

[\$1800000001] : LUT mode ON

[\$1000003F00] : Reset active control OFF.

■ Main flowchart (1)...Checking VOL OFFSET



A

■ Main flowchart (2)...Checking VOL YNOFS3/4/1

[From the Main flowchart (1)]

■

Display RST MASK 16 (Green 1023+). / [MKS S66]

Set VOL YNOFS3 to the tentative setting value minus 23. / [VY3 ***]

Set VOL YNOFS4 to the tentative setting value minus 23. / [VY4 ***]

B

Set VOL YNOFS1 to the tentative setting value minus 23. / [VY1 ***]

■

Is there erroneous discharge (abnormal dead cell)?
(Check on the PANEL 1-ADJ menu.)

Yes

To the Recovery flowchart (2-1)

No

Display RST MASK 15 (Red 1023+). / [MKS S65]

C

Is there erroneous discharge (abnormal dead cell)?
(Check on the PANEL 1-ADJ menu.)

Yes

To the Recovery flowchart (2-2)

No

■

Display RST MASK 22 (Cyan 3SF). / [MKS S72]

Set VOL YNOFS3 to the tentative setting value plus 23. / [VY3 ***]

D

Set VOL YNOFS4 to the tentative setting value plus 23. / [VY4 ***]

Set VOL YNOFS1 to the tentative setting value plus 23. / [VY1 ***]

■

Is there erroneous discharge (abnormal lit cell)?
(Check on the PANEL 1-ADJ menu.)

Yes

To the Recovery flowchart (2-3)

No

Return the VOL YNOFS3 to the tentative setting value. / [VY3 ***]

E

Return the VOL YNOFS4 to the tentative setting value. / [VY4 ***]

Return the VOL YNOFS1 to the tentative setting value. / [VY1 ***]

■

Determine the tentative setting value for VOL YNOFS3 as the final value.
Determine the tentative setting value for VOL YNOFS4 as the final value.
Determine the tentative setting value for VOL YNOFS1 as the final value.

F

+

From the Recovery flowchart (2-1) and (2-3)

[Adjustment completed]

Note:


Make sure that the following values become the final setting values.

VOL SUS *1	VOL XPOSF2 *1
VOL OFFSET	VOL YNOFS1
VOL RST P *1	VOL YNOFS3
VOL XPOFS1 *1	VOL YNOFS4

*1: The tentative setting value becomes the final value.


■ Recovery flowchart (1-1)...Changing the VOL OFFSET setting voltage

[From the Main flowchart (1)]




■ Recovery flowchart (1-2)...Changing the VOL OFFSET setting voltage

[From the Main flowchart (1) / Recovery flowchart (1-1)]



A




B

C

Recovery flowchart (1-3)...Changing the VOL OFFSET setting voltage

[From the Main flowchart (1)]




D

E

F

Recovery flowchart (1-4)...Changing the VOL OFFSET setting voltage

[From the Main flowchart (1) / Recovery flowchart (1-3)]



A

Recovery flowchart (2-1)...Changing the VOL YNOFS3/4/1 setting voltage

[From the Main flowchart (2)]


B


C

D

E


F





Recovery flowchart (2-2)...Changing the VOL YNOFS3/4 setting voltage

[From the Main flowchart (2) / Recovery flowchart (2-1)]



A

Recovery flowchart (2-3)...Changing the VOL YNOFS3/4/1 setting voltage

[From the Main flowchart (2)]


B

C

D

E

F



[To the Main flowchart (2)]

Setting Voltages

VOF		VRP		VY1		VY3		VY4	
Vysnofs (V)		Vyprst (V)		Vyknofs1,2 (V)		Vyknofs3 (V)		Vyknofs4 (V)	
14	000	146	002	161	001	151	001	151	001
15	005	147	003	162	003	152	003	152	003
16	011	148	005	163	005	153	005	153	005
17	016	149	007	164	008	154	008	154	008
18	021	150	009	165	010	155	010	155	010
19	027	151	011	166	012	156	012	156	012
20	032	152	013	167	014	157	014	157	014
21	037	153	014	168	016	158	016	158	016
22	043	154	016	169	018	159	018	159	018
23	048	155	018	170	020	160	020	160	020
24	053	156	020	171	022	161	022	161	022
25	059	157	022	172	025	162	025	162	025
26	064	158	024	173	027	163	027	163	027
27	069	159	025	174	029	164	029	164	029
28	075	160	027	175	031	165	031	165	031
29	080	161	029	176	033	166	033	166	033
30	085	162	031	177	035	167	035	167	035
31	091	163	033	178	037	168	037	168	037
32	096	164	035	179	040	169	040	169	040
33	101	165	036	180	042	170	042	170	042
34	107	166	038	181	044	171	044	171	044
35	112	167	040	182	046	172	046	172	046
36	117	168	042	183	048	173	048	173	048
37	123	169	044	184	050	174	050	174	050
38	128	170	046	185	052	175	052	175	052
39	133	171	047	186	054	176	054	176	054
40	139	172	049	187	057	177	057	177	057
41	144	173	051	188	059	178	059	178	059
42	149	174	053	189	061	179	061	179	061
43	155	175	055	190	063	180	063	180	063
44	160	176	057	191	065	181	065	181	065
45	165	177	058	192	067	182	067	182	067
46	171	178	060	193	069	183	069	183	069
47	176	179	062	194	072	184	072	184	072
48	181	180	064	195	074	185	074	185	074
49	187	181	066	196	076	186	076	186	076
50	192	182	068	197	078	187	078	187	078
51	197	183	069	198	080	188	080	188	080
52	203	184	071	199	082	189	082	189	082
53	208	185	073	200	084	190	084	190	084
54	213	186	075	201	086	191	086	191	086
55	219	187	077	202	089	192	089	192	089
56	224	188	079	203	091	193	091	193	091
57	229	189	080	204	093	194	093	194	093
58	235	190	082	205	095	195	095	195	095
59	240	191	084	206	097	196	097	196	097
60	245	192	086	207	099	197	099	197	099
61	251	193	088	208	101	198	101	198	101
62	255	194	090	209	104	199	104	199	104
		196	093	210	106	200	106	200	106
		197	095	211	108	201	108	201	108
		198	097	212	110	202	110	202	110
		199	099	213	112	203	112	203	112
		200	100	214	114	204	114	204	114
		201	102	215	116	205	116	205	116
		202	104	216	118	206	118	206	118
		203	106	217	121	207	121	207	121
		204	108	218	123	208	123	208	123
		205	110	219	125	209	125	209	125
		206	111	220	127	210	127	210	127
		207	113	221	129	211	129	211	129
		208	115	222	131	212	131	212	131
		209	117	223	133	213	133	213	133

A

Setting Voltages

VRP		VY1		VY3		VY4	
Vyprst (V)		Vyknofts1,2 (V)		Vyknofts3 (V)		Vyknofts4 (V)	
210	119	224	136	214	136	214	136
211	121	225	138	215	138	215	138
212	122	226	140	216	140	216	140
213	124	227	142	217	142	217	142
214	126	228	144	218	144	218	144
215	128	229	146	219	146	219	146
216	130	230	148	220	148	220	148
217	132	231	150	221	150	221	150
218	133	232	153	222	153	222	153
219	135	233	155	223	155	223	155
220	137	234	157	224	157	224	157
221	139	235	159	225	159	225	159
222	141	236	161	226	161	226	161
223	143	237	163	227	163	227	163
224	144	238	165	228	165	228	165
225	146	239	168	229	168	229	168
226	148	240	170	230	170	230	170
227	150	241	172	231	172	231	172
228	152	242	174	232	174	232	174
229	154	243	176	233	176	233	176
230	155	244	178	234	178	234	178
231	157	245	180	235	180	235	180
232	159	246	183	236	182	236	182
233	161	247	185	237	185	237	185
234	163	248	187	238	187	238	187
235	165	249	189	239	189	239	189
236	166	250	191	240	191	240	191
237	168	251	193	241	193	241	193
238	170	252	195	242	195	242	195
239	172	253	197	243	198	243	198
240	174	254	200	244	200	244	200
241	176	255	202	245	202	245	202
242	177	256	204	246	204	246	204
243	179	257	206	247	206	247	206
244	181	258	208	248	208	248	208
245	183	259	210	249	210	249	210
246	185	260	212	250	212	250	212
247	187	261	214	251	214	251	214
248	188	262	217	252	217	252	217
249	190	263	219	253	219	253	219
250	192	264	221	254	221	254	221
251	194	265	223	255	223	255	223
252	196	266	225	256	225	256	225
253	198	267	227	257	227	257	227
254	199	268	229	258	229	258	229
255	201	269	232	259	232	259	232
256	203	270	234	260	234	260	234
257	205	271	236	261	236	261	236
258	207	272	238	262	238	262	238
259	209	273	240	263	240	263	240
260	210	274	242	264	242	264	242
261	212	275	244	265	244	265	244
262	214	276	246	266	246	266	246
263	216	277	249	267	249	267	249
264	218	278	251	268	251	268	251
265	220	279	253	269	253	269	253
266	221	280	255	270	255	270	255

VRP	
Vyprst (V)	
267	223
268	225
269	227
270	229
271	231
272	232
273	234
274	236
275	238
276	240
277	242
278	243
279	245
280	247
281	249
282	251
283	253
284	254

F

8.5 ADJUSTMENT WHEN THE DRIVE ASSYS ARE REPLACED


Waveform adjustments required when replacing the following parts of the X DRIVE and Y DRIVE Assys.

Assy Name	Ref No.	Part Name	Part Category	Remarks
X DRIVE Assy	IC1101	PS9117AP	Photo Coupler	
	IC1104	TND307TD	FET Driver	
	IC1204	PS9117AP	Photo Coupler	
	IC1209	TND307TD	FET Driver	
Y DRIVE Assy	IC2101	PS9117AP	Photo Coupler	
	IC2103	TND307TD	FET Driver	
	IC2104	TND307TD	FET Driver	
	IC2201	PS9117AP	Photo Coupler	
	IC2203	TND307TD	FET Driver	

TIME LAG ADJUSTMENT OF THE CONTROL SIGNAL (SUS-B)

- Measure the time lag for the SUS-U signal to the SUS-B signal.
- Check the time lag for the SUS-B Gate signal to the SUS-U Gate signal.
Adjust the variable control so that the time lag of Gate becomes "time lag of input signal + $\alpha \pm 5$ nsec."

Note: For details on measuring points of waveform, see the figure below.



Time lag of SUS-U Gate and SUS-B Gate : $\Delta Tsus - gub$

Adjust so that " $\Delta Tsus - gub = \Delta Tsus - iub + \alpha \pm 5$ nsec," using the variable controls shown in the table below:

Assy	VR	Value of α
X DRIVE Assy	VR1002	70 nsec
Y DRIVE Assy	VR2002	60 nsec

A


■ **DELAY ADJUSTMENT OF THE CONTROL SIGNAL (SUS-D)**

- ① Measure the pulse width of the SUS-D signal.
- ② Check the pulse width of the SUS-D input signal (gate terminal of Q2111).
Adjust the variable control so that the pulse width of the SUS-D input signal (gate terminal of Q2111) becomes the same pulse width ± 5 nsec as the SUS-D signal.


Note:

- Be sure to set the Drive to OFF for adjustment.
- For details on measuring points of waveform, see the figure below.

B



C



D

SUS-D pulse width: $T_{sus - Dg}$
Adjust so that " $T_{sus - Dg} = T_{sus - D} \pm 5$ nsec," using the variable control shown in the table below:


Assy	VR
Y DRIVE Assy	VR2001

E


F

SUS-B ADJUSTMENT

X DRIVE Assy




Y DRIVE Assy



SUS-D ADJUSTMENT

Y DRIVE Assy



1234

8.6 PRECAUTION ON REPLACEMENT OF THE POWER SUPPLY UNIT

A

■ Attachment of the housing wire


The housing wire (J126) is attached to the P11 terminal of the POWER SUPPLY unit. As the housing wire is not provided with the POWER SUPPLY unit for service, when replacing the POWER SUPPLY unit, remove the housing wire (J126) from the old one and attach it to the new one.

NEVER turn on the unit before replacement, as doing so may damage the PC boards or the product.

Note:


The wiring shown in the photo is different from the actual power supply unit, because the product in the photo is a prototype.

POWER SUPPLY unit




1 Disconnect the housing wire (J126) from the P11 terminal on the old POWER SUPPLY Unit.

2 Connect the housing wire (J126) to the P11 terminal on the new POWER SUPPLY Unit.



POWER SUPPLY unit (old)



POWER SUPPLY unit (new)

9. RS-232C

9.1 OUTLINE OF RS-232C COMMAND

9.1.1 PREPARED TOOLS

It is necessary to prepare the following one to use 232C command.

- PC
 - Application for control
 - 232C cable (straight)
- * The setting of the Com port cannot be communicated if it doesn't do correctly.
(Please follow a set explanation of PC in the Com port)

9.1.2 USING RS-232C COMMANDS

Individual ports are provided for RS-232C and SR+ connectors with this model. Therefore, unlike the case of previous models, which required switching of exclusive operation between these connectors on the Integrator menu, switching is no longer required.

9.2 LIST OF RS-232C COMMANDS

RS-232C commands can be used in Service Factory mode. Before using RS-232C commands, it is necessary to change the factory presetting. See "9.1 OUTLINE OF RS-232C COMMAND".
[Note ; If you want to see version information (ex. QS1, QSE, Factory, Menu), Please see 10 seconds after starting.]

RS-232C command list

Command Name	Function		Active U-com		Last Memory	Effective only in Factory mode	Remarks
			MDU	MTB			
A							
ABL	***	Adjusting the upper limit of the power	●		Mod	●	
AMT	S00	Audio mute OFF		●			
	S01	Audio mute ON		●			
AP0	S**	ADDRESS L1, L2 setting	●		Mod	●	
AP1	S**	ADDRESS L3, L4 setting	●		Mod	●	
AP2	S**	ADDRESS U1, U2 setting	●		Mod	●	
AP3	S**	ADDRESS U3, U4 setting	●		Mod	●	
APN	***	1V average pulse number setting	●		Mod	●	UP*/DN* is not effective
APW	S00	APL interlocked function: OFF	●			●	
	S01	APL interlocked function: ON	●			●	
	S02	APL interlocked WB: ON / APL interlocked γ : OFF	●			●	
	S03	APL interlocked WB: OFF / APL interlocked γ : ON	●			●	
B							
BCP		Copying the backup data in the EEPROM	●			●	
BHI	***	User white balance : BLUE highlight	●				UP*/DN* is not effective
BLW	***	User white balance : BLUE lowlight	●				UP*/DN* is not effective
BRT	***	User brightness	●				UP*/DN* is not effective
BSM	S00	After image/Burning safe mode: OFF	●				UP*/DN* is not effective
	S01	After image/Burning safe mode: ON	●				
C							
CBU		Clearing backup data of EEPROM	●			●	
CHM		Clearing data of the hour meter	●			●	
CHN	FWD	Changing tuner preset channel (1 step forward)		●			
	REV	Changing tuner preset channel (1 step reverse)		●			
CHR		Clearing data of the hour meter of MTB side		●		●	
CNT	***	User contrast	●				UP*/DN* is not effective
CMT		Clearing data of the maximum temperature	●			●	
CPC		Clearing power-on count data	●			●	
CPD		Clearing power-down history	●			●	
CPM		Clearing data of the pulse meter	●			●	
CSD		Clearing shutdown history	●			●	
CTM		Releasing the TRAP SW		●			
D							
DIZ	S00	Dither/L dither OFF & noise OFF	●			●	
	S01	Dither/L dither ON & noise ON	●			●	
	S02	Dither/L dither OFF & noise ON	●			●	
	S03	Dither/L dither ON & noise OFF	●			●	
DRV	S00	Panel drive-power OFF	●				
	S01	Panel drive-power ON	●				
DW*		To subtract *** to the adjustment value (*** = 000 to 999, designated by a function command)		●			

Command Name	Function		Active U-com		Last Memory	Effective only in Factory mode	Remarks
			MDU	MTB			
F							
FAJ		Determining the flag of the DIGITAL Assy adjustment in "adjustment is completed"	●			●	
FAN		Factory mode OFF	●	●		●	
FAY		Factory mode ON	●	●			
FST		Set each memory setting of MTB side to the shipment state.		●		●	
G							
GHI	***	User white balance : GREEN highlight	●				UP*/DN* is not effective
GLW	***	User white balance : GREEN low light	●				UP*/DN* is not effective
I							
INA	***	Switching the terrestrial analog signal (ANTENNA A) (***: channel number)		●	Main		
	***** ****	Switching the terrestrial digital signal (ANTENNA A) (*****: channel number)		●	Main		
		Switching to the ANTENNA A		●	Main		
INB	***	Switching the terrestrial analog signal (ANTENNA B) (***:channel number)		●	Main		
		Switching to the ANTENNA B		●	Main		
INH		Switching the HomeGallery (Home Media Gallery for the ELITE model)		●			
INP	S01	Input switch: INPUT 1		●	Main		
	S02	Input switch: INPUT 2		●	Main		
	S03	Input switch: INPUT 3		●	Main		
	S04	Input switch: INPUT 4		●	Main		
	S05	Input switch: INPUT 5		●	Main		
	S06	Input switch: INPUT 6		●	Main		
	S07	Input switch: INPUT 7		●	Main		
	S08	Input switch: INPUT 8 (PC)		●	Main		
M							
MIR	S00	Mirror mode: OFF (default)	●				
	S01	Mirror mode: Right and left inversion	●				
	S02	Mirror mode: Top and bottom inversion	●				
	S03	Mirror mode: Top and bottom and right and left inversion	●				
MKC	S00	Panel mask indication off	●		Mod		
	S01	H ramp (slant 1) M	●		Mod	●	
	S02	H ramp (slant 4) M	●		Mod	●	
	S03	Slanting ramp M	●		Mod	●	
	S04	30 for aging	●		Mod	●	
	S05	05 for aging	●		Mod	●	
	S06	Erasing afterimage 1	●		Mod	●	
	S07	Erasing afterimage 2	●		Mod	●	
	S08	White (change in luminance level)	●		Mod	●	
	S09	PEAK detection raster	●		Mod	●	
	S10	Address lack check	●		Mod	●	
	S11	Green vertical line scroll	●		Mod	●	
	S12	Green horizontal line scroll	●		Mod	●	
	S13	Vertical ramp vertical scroll (white)	●		Mod	●	
	S14	Vertical ramp vertical scroll (green)	●		Mod	●	
	S15	Horizontal ramp horizontal scroll (white)	●		Mod	●	
	S16	Horizontal ramp horizontal scroll (green)	●		Mod	●	
S17	Cross hatch + window	●		Mod	●		
MKS	S00	MASK OFF	●		Mod		
	S01	H ramp (slant 1)	●		Mod	●	
	S02	H ramp (slant 4)	●		Mod	●	

A

B

C

D

E

F

Command Name		Function	Active U-com		Last Memory	Effective only in Factory mode	Remarks
			MDU	MTB			
M							
MKS	S03	V ramp (slant 1)	●		Mod	●	
	S04	Slanting ramp	●		Mod	●	
	S05	Window (Hi= 870, Lo= 102)	●		Mod	●	
	S06	Window (Hi= 1023, Lo= 102)	●		Mod	●	
	S07	Window (Hi= 1023, Lo=000)	●		Mod	●	
	S08	Window (Hi= 1023) 4 %	●		Mod	●	
	S09	Window (Hi= 1023) 1.25 %	●		Mod	●	
	S10	Window (1/7 LINE)	●		Mod	●	
	S11	STRIPE (MGT/GRN)	●		Mod	●	
	S12	STRIPE (GRN/MGT)	●		Mod	●	
	S13	B & W, checker (1 line)	●		Mod	●	
	S14	B & W, checker (2 lines)	●		Mod	●	
	S15	B & W, checker (4 lines)	●		Mod	●	
	S16	B & W, checker (8 lines)	●		Mod	●	
	S17	COLOR BAR	●		Mod	●	
	S18	Slanting lines	●		Mod	●	
	S19	Red & black, checker (1 line)	●		Mod	●	
	S20	Red & black, checker (2 lines)	●		Mod	●	
	S21	Red & black, checker (4 lines)	●		Mod	●	
	S22	Red & black, checker (8 lines)	●		Mod	●	
	S23	Erasing afterimage (RGB: zigzag, V: reverse)	●		Mod	●	
	S24	SUS 2000 pulses (black raster)	●		Mod	●	
	S25	1 for perfect linear	●		Mod	●	
	S26	2 for perfect linear	●		Mod	●	
	S27	3 for perfect linear	●		Mod	●	
	S28	4 for perfect linear	●		Mod	●	
	S29	RGB checker 1	●		Mod	●	
	S30	RGB checker 2	●		Mod	●	
	S31	Window RED (RED=1023)	●		Mod	●	
	S32	Window GREEN (GREEN=1023)	●		Mod	●	
	S33	Window BLUE (BLUE=1023)	●		Mod	●	
	S34	Even line horizontal stripes	●		Mod	●	
	S35	Odd line horizontal stripes	●		Mod	●	
	S36	Afterimage check 1	●		Mod	●	
	S37	Afterimage check 2	●		Mod	●	
	S38	Afterimage check 3	●		Mod	●	
	S39	Afterimage check 4	●		Mod	●	
	S40	Red single-color slanting ramp	●		Mod	●	
	S41	GREEN single-color slanting ramp	●		Mod	●	
	S42	BLUE single-color slanting ramp	●		Mod	●	
	S43	For panel light check 1	●		Mod	●	
	S44	For panel light check 2	●		Mod	●	
	S45	5 for perfect linear	●		Mod	●	
	S46	6 for perfect linear	●		Mod	●	
	S47	7 for perfect linear	●		Mod	●	
	S48	8 for perfect linear	●		Mod	●	
	S49	Mask for ABL adjustment	●		Mod	●	
	S51	Raster - White	●		Mod	●	
	S52	Raster - Red	●		Mod	●	
	S53	Raster - Green	●		Mod	●	

Command Name		Function	Active U-com		Last Memory	Effective only in Factory mode	Remarks
			MDU	MTB			
MKS	S54	Raster - Blue	●		Mod	●	
	S55	Raster - Black	●		Mod	●	
	S56	Raster - Cyan	●		Mod	●	
	S57	Raster - Magenta	●		Mod	●	
	S58	Raster - Yellow	●		Mod	●	
	S59	Raster - Pink	●		Mod	●	
	S60	Raster - Cyan 291	●		Mod	●	
	S61	Raster - Yellow egg color	●		Mod	●	
	S62	Raster - Light blue	●		Mod	●	
	S63	Raster - Beige	●		Mod	●	
	S64	Raster - Gray 291	●		Mod	●	
	S65	Raster - Red 1023+	●		Mod	●	
	S66	Raster - Green 1023+	●		Mod	●	
	S67	Raster - Blue 1023+	●		Mod	●	
	S68	Raster - Red 626	●		Mod	●	
	S69	Raster - Green 626	●		Mod	●	
	S70	Raster - Blue 626	●		Mod	●	
	S71	Raster - Gray 2SF	●		Mod	●	
	S72	Raster - Cyan 3SF	●		Mod	●	
	S73	Raster - Magenta 3SF	●		Mod	●	
	S74	Raster - Yellow 3SF	●		Mod	●	
	S75	Raster - Gray 307	●		Mod	●	
MST	S00	Display one screen		●			
	S01	PsideP (Main size: normal)		●			
	S02	PinP (Right down)		●			
	S03	PinP (Right up)		●			
	S04	PinP (Left up)		●			
	S05	PinP (Left down)		●			
	S08	SWAP (Exchanging sub-screen)		●			
N							
NGP	S00	Negative positive inversion: OFF (default)	●				
	S01	Negative positive inversion: ON	●				
O							
OSD	S00	Turning OSD setting to off		●	Main		
	S01	Turning OSD setting to on		●	Main		
P							
PAV	S00	Panel drive mode (FACTORY)	●				
	S01	Panel drive mode (STANDARD)	●				
	S02	Panel drive mode (DYNAMIC)	●				
	S03	Panel drive mode (MOVIE)	●				
	S04	Panel drive mode (GAME)	●				
	S05	Panel drive mode (SPORTS)	●				
	S06	Panel drive mode (PURE)	●				
	S07	Panel drive mode (USER)	●				
	S08	Panel drive mode (ISF-DAY)	●				
	S09	Panel drive mode (ISF-NIGHT)	●				
	S10	Panel drive mode (OPTIMUM)	●				

A

B

C

D

E

F

Command Name		Function	Active U-com		Last Memory	Effective only in Factory mode	Remarks
			MDU	MTB			
P							
PBH	***	Panel white balance adjustment - Blue highlight	●		Mod	●	UP*/DN* is not effective
PBL	***	Panel white balance adjustment - Blue low light	●		Mod	●	UP*/DN* is not effective
PDM	S00	Passing PD signals to the POWER SUPPLY Unit => Power-down	●				
	S01	Not passing PD signals to the POWER SUPPLY Unit => No power-down	●				
PES	S00	For general-purpose commonness: Standard	●				
	S01	For general-purpose commonness: Energy saving 1	●				
	S02	For general-purpose commonness: Energy saving 2	●				
	S10	For general-purpose Japan standard: Standard	●				
	S11	For general-purpose Japan standard: Standard	●				
	S12	For general-purpose Japan standard: Standard	●				
	PFL	S00	Peripheral luminance correction: OFF	●			●
S01		Peripheral luminance correction: ON fixed	●			●	
S02		Peripheral luminance correction: APL interlocked ON (default)	●			●	
PFM	S00	It does not return the hierarchy character of the panel factory	●			●	
	S01	It returns the hierarchy character of the panel factory	●			●	
PFN		Factory mode: OFF	●			During PFY	
PFS		Setup at shipment	●			●	
PFY		Factory mode: ON	●				
PGB	S00	Blue-independent gamma setting: Straight	●				
	S01	Blue-independent gamma setting: Fixed on 1.6	●				
	S02	Blue-independent gamma setting: Fixed on 1.7	●				
	S03	Blue-independent gamma setting: Fixed on 1.8	●				
	S04	Blue-independent gamma setting: Fixed on 1.9	●				
	S05	Blue-independent gamma setting: Fixed on 2.0	●				
	S06	Blue-independent gamma setting: Fixed on 2.1	●				
	S07	Blue-independent gamma setting: Fixed on 2.2 (default)	●				
	S08	Blue-independent gamma setting: Fixed on 2.3	●				
	S09	Blue-independent gamma setting: Fixed on 2.4	●				
	S10-31	Blue-independent gamma setting: Customize	●				
	PGG	S00	Green-independent gamma setting: Straight	●			
S01		Green-independent gamma setting: Fixed on 1.6	●				
S02		Green-independent gamma setting: Fixed on 1.7	●				
S03		Green-independent gamma setting: Fixed on 1.8	●				
S04		Green-independent gamma setting: Fixed on 1.9	●				
S05		Green-independent gamma setting: Fixed on 2.0	●				
S06		Green-independent gamma setting: Fixed on 2.1	●				
S07		Green-independent gamma setting: Fixed on 2.2 (default)	●				
S08		Green-independent gamma setting: Fixed on 2.3	●				
S09		Green-independent gamma setting: Fixed on 2.4	●				
S10-31		Green-independent gamma setting: Customize	●				
PGH		***	Panel white balance adjustment - Green highlight	●		Mod	●
PGL	***	Panel white balance adjustment - Green low light	●		Mod	●	

Command Name	Function		Active U-com		Last Memory	Effective only in Factory mode	Remarks
			MDU	MTB			
P							
PGR	S00	Red-independent gamma setting: Straight	●				
	S01	Red-independent gamma setting: Fixed on 1.6	●				
	S02	Red-independent gamma setting: Fixed on 1.7	●				
	S03	Red-independent gamma setting: Fixed on 1.8	●				
	S04	Red-independent gamma setting: Fixed on 1.9	●				
	S05	Red-independent gamma setting: Fixed on 2.0	●				
	S06	Red-independent gamma setting: Fixed on 2.1	●				
	S07	Red-independent gamma setting: Fixed on 2.2 (default)	●				
	S08	Red-independent gamma setting: Fixed on 2.3	●				
	S09	Red-independent gamma setting: Fixed on 2.4	●				
	S10-31	Red-independent gamma setting: Customize	●				
PKD	S00	Peak luminance detection: OFF	●			●	
	S01	Peak luminance detection: ON	●			●	
PKL	S00	Panel brightness setting No brightness limitation : 100 % (default)	●				
	S01	Panel brightness setting Brightness limitation 1 : 87 %	●				
	S02	Panel brightness setting Brightness limitation 2 : 73 %	●				
	S03	Panel brightness setting Brightness limitation 3 : 60 %	●				
	S04	Panel brightness setting Brightness limitation 4 : 52 %	●				
	S05	Panel brightness setting Brightness limitation 5 : 40 %	●				
	S06	Panel brightness setting Brightness limitation 6 : 27 %	●				
	S07	Panel brightness setting Brightness limitation 7 : 13 %	●				
PMT	S00	Canceling panel muting	●				
	S01	Panel muting	●				
POF		Power OFF	●	●	Main		
PON		Power ON	●	●	Main		
PPT	S00	Panel protection: OFF	●			●	
	S01	Panel protection: ON	●			●	
PRH	***	Panel white balance adjustment - Red highlight	●		Mod	●	UP*/DN* is not effective
PRL	***	Panel white balance adjustment - Red low light	●		Mod	●	UP*/DN* is not effective
PUC	S00	Pure cinema: off		●	Main	●	
	S01	Pure cinema: Standard		●	Main	●	
	S02	Pure cinema: Advance		●	Main	●	
	S03	Pure cinema: Smooth		●	Main	●	
Q							
QAJ		Acquiring various adjustment values	●				
QMT		Acquiring temperature of MTB side and Fan speed		●			
QNG		Acquiring shutdown information of MTB side		●			
QPD		Acquiring logs of power-down points	●				
QPM		Acquiring data of the pulse meter	●				
QPW		Acquiring panel white balance adjustment values	●				
QS1		Acquiring unit data, such as the software version common to all models, regardless of destination	●	●			
QS2		Acquiring data on the status of the unit, such as temperature	●				
QS3		Each information output for panel	●				
QSE		Acquiring unit data, such as the software version common to all models, regardless of destination		●			
QSD		Acquiring data on shutdown	●				
QSI		Acquiring data related with signals	●				
QSP		Acquiring the software sub-version of the microcomputer at panel side	●				

A

B

C

D

E

F

Command Name		Function	Active U-com		Last Memory	Effective only in Factory mode	Remarks
			MDU	MTB			
R							
R1K	***	First reset (wedge width)	●		Mod	●	UP*/DN* is not effective
R2K	***	Second reset (wedge width)	●		Mod	●	UP*/DN* is not effective
RBL	S00	BLUE setting for panel degradation correction: Lv0 (no correction)	●		Mod	●	
	S01	BLUE setting for panel degradation correction: LV1	●		Mod	●	
	S02	BLUE setting for panel degradation correction: LV2	●		Mod	●	
	S03	BLUE setting for panel degradation correction: LV3	●		Mod	●	
	S04	BLUE setting for panel degradation correction: LV4	●		Mod	●	
	S05	BLUE setting for panel degradation correction: LV5	●		Mod	●	
	S06	BLUE setting for panel degradation correction: LV6	●		Mod	●	
	S07	BLUE setting for panel degradation correction: LV7	●		Mod	●	
RGL	S00	GREEN setting for panel degradation correction: Lv0 (no correction)	●		Mod	●	
	S01	GREEN setting for panel degradation correction: LV1	●		Mod	●	
	S02	GREEN setting for panel degradation correction: LV2	●		Mod	●	
	S03	GREEN setting for panel degradation correction: LV3	●		Mod	●	
	S04	GREEN setting for panel degradation correction: LV4	●		Mod	●	
	S05	GREEN setting for panel degradation correction: LV5	●		Mod	●	
	S06	GREEN setting for panel degradation correction: LV6	●		Mod	●	
	S07	GREEN setting for panel degradation correction: LV7	●		Mod	●	
RHI	***	User white balance - Red highlight	●				UP*/DN* is not effective
RLS	S00	Room light sensor operation : OFF	●				
	S01	Room light sensor operation : 1	●				
	S02	Room light sensor operation : 2	●				
	S03	Room light sensor operation : 3	●				
	S04	Room light sensor operation : 4	●				
	S05	Room light sensor operation : 5	●				
RLW	***	User white balance - Red low light	●				UP*/DN* is not effective
RRL	S00	RED setting for panel degradation correction: Lv0 (no correction)	●		Mod	●	
	S01	RED setting for panel degradation correction: LV1	●		Mod	●	
	S02	RED setting for panel degradation correction: LV2	●		Mod	●	
	S03	RED setting for panel degradation correction: LV3	●		Mod	●	
	S04	RED setting for panel degradation correction: LV4	●		Mod	●	
	S05	RED setting for panel degradation correction: LV5	●		Mod	●	
	S06	RED setting for panel degradation correction: LV6	●		Mod	●	
	S07	RED setting for panel degradation correction: LV7	●		Mod	●	
S							
SDM	S00	Shutdown enabled	●			●	
	S01	Shutdown prohibited	●			●	
SFR	S01	Measures against AM radio noise - SUS FREQUENCY MODE 1	●		Mod	●	
	S02	Measures against AM radio noise - SUS FREQUENCY MODE 2	●		Mod	●	
	S03	Measures against AM radio noise - SUS FREQUENCY MODE 3	●		Mod	●	
	S04	Measures against AM radio noise - SUS FREQUENCY MODE 4	●		Mod	●	
	S05	Measures against AM radio noise - SUS FREQUENCY MODE 5	●		Mod	●	
	S06	Measures against AM radio noise - SUS FREQUENCY MODE 6	●		Mod	●	
	S07	Measures against AM radio noise - SUS FREQUENCY MODE 7	●		Mod	●	
	S08	Measures against AM radio noise - SUS FREQUENCY MODE 8	●		Mod	●	

Command Name	Function		Active U-com		Last Memory	Effective only in Factory mode	Remarks
			MDU	MTB			
S							
SKM	S00	STREAKING correction mode OFF	●		Mod	●	
	S01	STREAKING correction mode 1	●		Mod	●	
	S02	STREAKING correction mode 2	●		Mod	●	
	S03	STREAKING correction mode 3	●		Mod	●	
	S04	STREAKING correction mode 4	●		Mod	●	
	S05	STREAKING correction mode 5	●		Mod	●	
	S06	STREAKING correction mode 6	●		Mod	●	
	S07	STREAKING correction mode 7	●		Mod	●	
	S08	STREAKING correction mode 8	●		Mod	●	
SMC	S01	Smooth clear drive OFF	●			●	
	S02	Smooth clear drive ON (default)	●			●	
SML	***	Adjustment of the side mask level		●	Main	●	
SMM	S00	Setting of the effective area during streaking correction: All screen detection (default)	●			●	
	S01	Setting of the effective area during streaking correction: 4:3 detection	●				
	S02	Setting of the effective area during streaking correction: 14:9 detection	●				
	S03	Setting of the effective area during streaking correction: D-BY-D detection VGA	●				
	S04	Setting of the effective area during streaking correction: D-BY-D detection SVGA	●				
SN0	***	Setting of the serial No. 0 (panel)	●		Mod	●	UP*/DN* is not effective
SN1	***	Setting of the serial No. 1 (panel)	●		Mod	●	UP*/DN* is not effective
SN2	***	Setting of the serial No. 2 (panel)	●		Mod	●	UP*/DN* is not effective
SN3	***	Setting of the serial No. 3 (panel)	●		Mod	●	UP*/DN* is not effective
SN4	***	Setting of the serial No. 4 (panel)	●		Mod	●	UP*/DN* is not effective
SQM	S01	Panel sequence mode: VIDEO sequence	●				
	S02	Panel sequence mode: PC sequence	●				
	S03	Panel sequence mode: FILM sequence	●				
SSM	S01	SSCG OFF	●			●	It is necessary to wait for one minute after drive OFF
	S02	SSCG ON	●			●	
SZM	S00	Setting the screen size to Dot by Dot		●	Main		
	S01	Setting the screen size to 4 :3		●	Main		
	S02	Setting the screen size to FULL		●	Main		
	S03	Setting the screen size to ZOOM		●	Main		
	S04	Setting the screen size to CINEMA		●	Main		
	S05	Setting the screen size to WIDE		●	Main		
T							
THS	S00	Theater port interlock operation OFF	●				
	S01	Theater port interlock operation ON	●				
U							
UAJ		Determining the flag for the DIGITAL Assy adjustment in "not adjusted"	●		Mod	●	
UP*		To add *** to the adjustment value (*** = 000 to 999, designated by a function command)		●			

A

B

C

D

E

F

Command Name	Function		Active U-com		Last Memory	Effective only in Factory mode	Remarks
			MDU	MTB			
V							
VFQ	S01	Setting the frequency in Mask mode to VD-48 Hz	●		Mod	●	
	S02	Setting the frequency in Mask mode to VD-50 Hz	●		Mod	●	
	S03	Setting the frequency in Mask mode to VD-60 Hz	●		Mod	●	
	S05	Setting the frequency in Mask mode to VD-72 Hz	●		Mod	●	
	S06	Setting the frequency in Mask mode to VD-75 Hz	●		Mod	●	
	S13	Setting the frequency in Mask mode to PC-60 Hz	●		Mod	●	
	S22	Setting the frequency in Mask mode to VD-50 Hz (nonstandard)	●		Mod	●	
	S23	Setting the frequency in Mask mode to VD-60 Hz (nonstandard)	●		Mod	●	
	S25	Setting the frequency in Mask mode to VD-72 Hz (nonstandard)	●		Mod	●	
	S26	Setting the frequency in Mask mode to VD-75 Hz (nonstandard)	●		Mod	●	
VOF	***	Adjustment of the reference value of Vysnfs voltage Vysnfs ADJUSTMENT	●		Mod	●	UP*/DN* is not effective
VOL	UP*, DW*, ***	To adjust the volume (to be used in combination with UP*/DW*)		●			
VRP	***	Adjustment of the reference value of Vyprst voltage Vyprst ADJUSTMENT	●		Mod	●	UP*/DN* is not effective
VSU	***	Adjustment of the reference value of Vsus voltage Vsus ADJUSTMENT	●		Mod	●	UP*/DN* is not effective
VX1	***	Adjustment of the reference value of Vxpofs1 voltage Vxpofs1 ADJUSTMENT	●		Mod	●	UP*/DN* is not effective
VX2	***	Adjustment of the reference value of Vxpofs2 voltage Vxpofs2 ADJUSTMENT	●		Mod	●	UP*/DN* is not effective
VY1	***	Adjustment of the reference value of Vyknofs1, 2 voltage Vyknofs1,2 ADJUSTMENT	●		Mod	●	UP*/DN* is not effective
VY3	***	Adjustment of the reference value of Vyknofs3 voltage Vyknofs3 ADJUSTMENT	●		Mod	●	UP*/DN* is not effective
VY4	***	Adjustment of the reference value of Vyknofs4 voltage Vyknofs4 ADJUSTMENT	●		Mod	●	UP*/DN* is not effective
W							
WBI	S00	Panel WB standard output mode: OFF	●			●	
	S01	Panel WB standard output mode: ON	●			●	
X							
X1B	***	3SF and later-first XSUS (resonance up width)	●		Mod	●	UP*/DN* is not effective
X3B	***	2SF-third XSUS (resonance up width)	●		Mod	●	UP*/DN* is not effective
XSB	***	2SF-repeat XSUS (resonance up width)	●		Mod	●	UP*/DN* is not effective
Y							
Y1K	***	1SF-YSUS-Tail (wedge width)	●		Mod	●	UP*/DN* is not effective
Y1Z	***	1SF-YSUS-Tail (resonance down width)	●		Mod	●	UP*/DN* is not effective
Y2B	***	2SF-second YSUS (resonance up width)	●		Mod	●	UP*/DN* is not effective
Y2K	***	2SF-YSUS-Tail (wedge width)	●		Mod	●	UP*/DN* is not effective
Y2Z	***	2SF-YSUS-Tail (resonance down width)	●		Mod	●	UP*/DN* is not effective
YNK	***	3SF and later (SSF 2 pulses)-YSUS Tail (wedge width)	●		Mod	●	UP*/DN* is not effective
YNZ	***	3SF and later (SSF 2 pulses)-YSUS Tail (resonance down width)	●		Mod	●	UP*/DN* is not effective
YTK	***	3SF and later-YSUS Tail (wedge width)	●		Mod	●	UP*/DN* is not effective
YTZ	***	3SF and later-YSUS Tail (resonance down width)	●		Mod	●	UP*/DN* is not effective
YSB	***	2SF-repeat YSUS (resonance up width)	●		Mod	●	UP*/DN* is not effective
Z							
ZME		Initializing the video EEPROM data		●		●	
ZPR		Initializing the setting data to which no adjustment command is provided PANEL EEPROM REFRESH	●		Mod	●	

9.3 DETAILS OF EACH COMMANDS

9.3.1 QS1 (PANEL STATUS)

Model information and version information are returned.

Command Format	Effective Operation Modes	Function	Remarks
[QS1]	Every Time	Output of status	Return data: 3 (ECO) + 84 (DATA) + 2 (CS) = 89 Byte

Data Arrangement		Data Length	Output Example
ECO		3 byte	QS1 (Fixed)
1	Resolution/Size	1 byte	F
2	Panel Generation	1 byte	8
3	Destination	1 byte	*
4	Grade	1 byte	*
5	Panel Product Form	1 byte	B
6	Boot version of Module microcomputer	3 byte	05F
7	Program version of Module microcomputer	8 byte	-02F
8	Boot version of SQ_LSI	3 byte	04F
9	Program version of SQ_LSI	8 byte	-01Y
10	Panel information	8 byte	G8_50F
11	Reserved (panel section)	8 byte	*****
14	, (comma)	1 byte	,
15	MTB generation	1 byte	8
16	MTB destination	1 byte	A
17	MTB grade	1 byte	H
18	MTB product form	1 byte	B
19	Program version of IF microcomputer	8 byte	010AE
20	Boot version of IF microcomputer	4 byte	01A
21	Program version of Main microcomputer	8 byte	-01A
22	Boot version of Main microcomputer	4 byte	01A
23	Program version of ASIC	8 byte	-01A
24	Boot version of ASIC	4 byte	01A
25	CS (Check Sum)	2 byte	FF

15: MTB Generation	
6	G6
7	G7
8	G8
9	G9
0	G10

16: MTB Destination	
A	North America
C	China
E	Europe
G	General
J	Japan
U	Australia

17: MTB Grade	
H	Elite/XDA/Step-upD
T	Step-upA/XG/XC/Regular (US)
B	Not used
S	RegularD
R	RegularA

18: MTB Product Form	
S	System model
B	One body model

1: Resolution/Size	
3	1024*768/42
4	1024*768/43
5	1280*768/50
6	1365*768/50
7	1365*768/60
E	1920*1080/42
F	1920*1080/50
G	1920*1080/60

2: Panel Generation	
6	G6
7	G7
8	G8
9	G9
0	G10

3: Destination	
*	Commonness
A	US (Reserved)
E	EU (Reserved)
J	Japan (Reserved)

4: Grade	
*	Commonness
Z	Evaluation

5: Panel Product Form	
S	System model
B	All-in-one design TV
M	Monitor
D	Standard module
E	Simple module

10: Panel Information		
1 to 3rd byte	G8_	Generation information G8 + _(under bar) fixed
4 to 5th byte	42	42 inch
	50	50 inch
	60	60 inch
6th byte	*	PSIZE information and SQ_LSI version mismatching (version mismatching at SD)
	F	FHD model
	X	XGA model
7th byte	*	Model information and SQ_LSI version mismatching (version mismatching at SD)
	—	Under bar
	6	2nd PLANT (XGA 50 inch only)
8th byte	4	1st PLANT (XGA 50 inch only)
	*	PLANT information and SQ_LSI version mismatching (version mismatching at SD)
	‘	Others

9.3.2 QS2 (PANEL OPERATION DATA)

The command QS2 is for acquiring data on the panel's operational information.

Command Format	Effective Operation Modes	Function	Remarks
[QS2]	All operations	To acquire data on operations of the panel	Return data: 3 (ECO) + 34 (DATA) + 2 (CS) = 39 Byte

Data Arrangement		Data Length	Output Example
ECO		3 byte	QS2 (fixed)
1	Power supply status	1 byte	0
2	Adjustment flag of the main unit	1 byte	0
3	Adjustment-data backup flag	1 byte	0
4	"1st PD" data	1 byte	0
5	"2nd PD" data	1 byte	0
6	Reserved	3 byte	**
7	Temperature data (TEMP 1)	3 byte	063
8	SD main data	1 byte	0
9	SD sub data	1 byte	0
10	Operation status induced by SD	1 byte	0
11	Reserved	3 byte	0
12	HOUR METER	8 byte	00000437
13	MASK indication	1 byte	0
14	Still picture detection	1 byte	7C
15	SCAN protection detection	1 byte	
16	Panel crack detection	1 byte	
17	Address emergency detection	1 byte	
18	Reserved	4 byte	
19	CS	2 byte	

8: SD main data	
0	No SD
1	SQ_LSI communication error
2	MDU-IIC communication error
3	Abnormally in RST2
4	TEMP

9-1: SD-Sub (SQ_LSI)	
0	No SD-Sub data
1	Communication error
2	Drive stop
3	BUSY
4	Version mismatching (H/S)
5	Version mismatching (M/S)

9-2: SD-Sub (MDU-IIC)	
0	No SD-Sub data
1	EEPROM
2	BACKUP
3	DAC1
4	DAC2

9-3: SD-Sub (TEMP)	
0	No SD-Sub data
1	TEMP1 high temperature
2	TEMP1 low temperature

10: Operation status induced by SD	
0	Normal
1	Relay-off completed
2	During warning indication

13: MASK indication	
0	MASK-OFF
1	MASK-ON

14 to 17: Detection of Each Protection function	
0	Normal operation
1	At detection of protection operation

1: Power supply status	
P	During power ON
0	Entering Passive mode failed during standby
1	Entering Passive mode succeeded during standby

2: Adjustment flag of the main unit	
0	Adjustment completed
1	Adjustment not completed

3: Adjustment-data backup flag	
0	With backup data
1	No backup data

4, 5: PD data	
0	No PD data
1	Not used
2	POWER
3	SCAN
4	SCN-5V
5	Y-DRV
6	Y-DCDC
7	Y-SUS
8	ADRS
9	X-DRV
A	X-DCDC
B	X-SUS
C	DIG-DCDC
D	Not used
E	Not used
F	UNKNOWN

The command QS3 is for acquiring data on operational information of the panel.

Command Format	Effective Operation Modes	Function	Remarks
[QS3]	All operations	To acquire data on operations of the panel	Return data: 3 (ECO) + 58 (DATA) + 2 (CS) = 63 Byte

Data Arrangement		Data Length	Output Example	Note (*1) : Centigrade scale
ECO		3 byte	QS3	
1	SERIAL	15 byte	-----	
2	HOUR METER	8 byte	00000000	
3	BACKUP HR METER	8 byte	00000000	
4	PON COUNTER	8 byte	00000000	
5	TEMP1 acquisition (Temperature value)	5 byte	+25.0 (*1)	
6	TEMP0 acquisition (Temperature value)	5 byte	+25.0 (*1)	
7	MaxTEMP acquisition (Temperature value)	5 byte	+75.0 (*1)	
8	Reserved	4 byte	****	
9	CS	2 byte	FB	

A The command QAJ is for acquiring the panel's factory-preset data.

Command Format	Effective Operation Modes	Function	Remarks
[QAJ]	All operations	To acquire data on the setting value of drive voltage	Return data: 3 (ECO) + 84 (DATA) + 2 (CS) = 89 Byte

Data Arrangement	Data Length	Output Example	31: Streaking correction
ECO	3 byte	QAJ	0 OFF
1 V-SUS adjustment value	3 byte	128	n n: 1 to 8 (Mode n)
2 Vysnofs adjustment value	3 byte	128	
3 Vyprst adjustment value	3 byte	128	
4 Vxpofs1 adjustment value	3 byte	128	
5 Vxpofs2 adjustment value	3 byte	128	
6 Vyknofs1,2 adjustment value	3 byte	128	
7 Vyknofs3 adjustment value	3 byte	128	
8 Vyknofs4 adjustment value	3 byte	128	
9 R1K adjustment value	3 byte	128	
10 R2K adjustment value	3 byte	128	
11 Y1K adjustment value	3 byte	128	
12 Y1Z adjustment value	3 byte	128	
13 X1B adjustment value	3 byte	128	
14 Y2B adjustment value	3 byte	128	
15 X3B adjustment value	3 byte	128	
16 YSB adjustment value	3 byte	128	
17 XSB adjustment value	3 byte	128	
18 YTK adjustment value	3 byte	128	
19 YTZ adjustment value	3 byte	128	
20 Y2K adjustment value	3 byte	128	
21 Y2Z adjustment value	3 byte	128	
22 YNK adjustment value	3 byte	128	
23 YNZ adjustment value	3 byte	128	
24 R-REVISE setting value	1 byte	0	
25 G-REVISE setting value	1 byte	0	
26 B-REVISE setting value	1 byte	0	
27 ADDRESS 1, 2 setting value	2 byte	01	
28 ADDRESS 3, 4 setting value	2 byte	13	
29 ADDRESS 5, 6 setting value	2 byte	32	
30 ADDRESS 7, 8 setting value	2 byte	30	
31 Streaking correction	1 byte	1	
32 AM radio countermeasure	1 byte	1	
33 Reserved	2 byte	**	
34 CS	2 byte	B7	

9.3.5 QPW (VIDEO ADJUSTMENT DATA OF THE PANEL)

The command QPW is for acquiring the factory-preset data about the video of the panel.

Command Format	Effective Operation Modes	Function	Remarks
[QPW]	All operations	To acquire data on the video setting value	Return data: 3 (ECO) + 40 (DATA) + 2 (CS) = 45 Byte

Data Arrangement	Data Length	Output Example	1: Drive sequence	3: Type of ABL/WB tables
ECO	3 byte	QPW (fixed)	48V Video 48 Hz	n n: 1 to 4
1 Drive sequence	3 byte	60V	50V Video 50 Hz	11, 12, 13: RGB Gamma setting
2 Standard/nonstandard	1 byte	S	60V Video 60 Hz	n 00 to 31
3 Type of ABL/WB tables	2 byte	T1	72V Video 72 Hz	15: Center luminance correction
4 ABL adjustment value	3 byte	128	75V Video 75 Hz	0 OFF
5 R-HIGH adjustment value	3 byte	256	60P PC 60 Hz	1 ON
6 G-HIGH adjustment value	3 byte	256	70P PC 70 Hz	2 ON (interlocked with APL)
7 B-HIGH adjustment value	3 byte	256	2: Standard/nonstandard	17: WB interlocked with APL
8 R-LOW adjustment value	3 byte	512	S Standard	0 OFF
9 G-LOW adjustment value	3 byte	512	N Nonstandard	1 ON
10 B-LOW adjustment value	3 byte	512	14: Streking correction	2 WB interlocked ON/γ OFF
11 R gamma setting	2 byte	07	0 OFF	3 WB interlocked OFF/γ ON
12 G gamma setting	2 byte	07	1 ON	18: Transition of brightness by protective operations
13 B gamma setting	2 byte	07		0 Upper limit state for brightness
14 Streking correction	1 byte	0		1 Brightness being reduced
15 Center luminance correction	1 byte	1		2 Lower limit state for brightness
16 Reserved	1 byte	*		3 Brightness being increased
17 WB interlocked with APL	1 byte	0		
18 Transition of protective operations	1 byte	0		
19 Reserved	2 byte	**		
20 CS	2 byte	39		

9.3.6 QPM (PULSE METER VALUE)

The command QPM is for acquiring the accumulated number of pulses of the panel.

Command Format	Effective Operation Modes	Function	Remarks
[QPM]	All operations	To acquire data on the accumulated number of pulses	Return data: 3 (ECO) + 40 (DATA) + 2 (CS) = 45 Byte

Data Arrangement	Data Length	Output Example
ECO	3 byte	QPM (fixed)
1 Pulse meter B 1	8 byte	00000000
2 Pulse meter B 2	8 byte	00000000
3 Pulse meter B 3	8 byte	00000000
4 Pulse meter B 4	8 byte	00000000
5 Pulse meter B 5	8 byte	00000000
6 CS	2 byte	6E

The command QPD is for acquiring data from the 8 latest power-down (PD) logs.

Command Format	Effective Operation Modes	Function	Remarks
[QPD]	All operations	To acquire data on the power-down logs	Return data: 3 (ECO) + 80 (DATA) + 2 (CS) = 85 Byte

Data Arrangement		Data Length	Output Example
ECO		3 byte	QPD (fixed)
1	Latest "1st PD" data	1 byte	A
2	Latest "2nd PD" data	1 byte	2
3	Data from the hour meter for the latest PD	8 byte	00010020
4	Second latest "1st PD" data	1 byte	E
5	Second latest "2nd PD" data	1 byte	9
6	Data from the hour meter for the second latest PD	8 byte	00008523
7	Third latest "1st PD" data	1 byte	4
8	Third latest "2nd PD" data	1 byte	3
9	Data from the hour meter for the third latest PD	8 byte	00004335
10	Fourth latest "1st PD" data	1 byte	2
11	Fourth latest "2nd PD" data	1 byte	0
12	Data from the hour meter for the fourth latest PD	8 byte	00000945
13	Fifth latest "1st PD" data	1 byte	4
14	Fifth latest "2nd PD" data	1 byte	0
15	Data from the hour meter for the fifth latest PD	8 byte	00000715
16	Sixth latest "1st PD" data	1 byte	A
17	Sixth latest "2nd PD" data	1 byte	2
18	Data from the hour meter for the sixth latest PD	8 byte	00000552
19	Seventh latest "1st PD" data	1 byte	A
20	Seventh latest "2nd PD" data	1 byte	0
21	Data from the hour meter for the seventh latest PD	8 byte	00000213
22	Eighth latest "1st PD" data	1 byte	D
23	Eighth latest "2nd PD" data	1 byte	0
24	Data from the hour meter for the eighth latest PD	8 byte	00000123
25	CS	2 byte	27

1, 2, 4, 5: PD data	
0	No PD
1	Not used
2	P-POWER
3	SCAN
4	SCN-5V
5	Y-DRIVE
6	Y-DCDC
7	Y-SUS
8	Address
9	X-DRIVE
A	X-DCDC
B	X-SUS
C	DIGITAL-DC/DC
D	Not used
E	Not used
F	UNKNOWN

9.3.8 QSD (SD LOGS)

The command QSD is for acquiring the data from the 8 latest shutdown (SD) logs.

Command Format	Effective Operation Modes	Function	Remarks
[QSD]	All operations	To acquire data on the shutdown logs	Return data: 3 (ECO) + 80 (DATA) + 2 (CS) = 85 Byte

Data Arrangement		Data Length	Output Example
ECO		3 byte	QSD (fixed)
1	Latest SD data	1 byte	1
2	Latest SD subcategory data	1 byte	0
3	Data from the hour meter for the latest SD	8 byte	00752013
4	Second latest SD data	1 byte	5
5	Second latest SD subcategory data	1 byte	0
6	Data from the hour meter for the second latest SD	8 byte	00456378
7	Third latest SD data	1 byte	2
8	Third latest SD subcategory data	1 byte	3
9	Data from the hour meter for the third latest SD	8 byte	00347845
10	Fourth latest SD data	1 byte	2
11	Fourth latest SD subcategory data	1 byte	4
12	Data from the hour meter for the fourth latest SD	8 byte	00175635
13	Fifth latest SD data	1 byte	1
14	Fifth latest SD subcategory data	1 byte	0
15	Data from the hour meter for the fifth latest SD	8 byte	00083450
16	Sixth latest SD data	1 byte	2
17	Sixth latest SD subcategory data	1 byte	2
18	Data from the hour meter for the sixth latest SD	8 byte	00045662
19	Seventh latest SD data	1 byte	0
20	Seventh latest SD subcategory data	1 byte	0
21	Data from the hour meter for the seventh latest SD	8 byte	00000000
22	Eighth latest SD data	1 byte	0
23	Eighth latest SD subcategory data	1 byte	0
24	Data from the hour meter for the eighth latest SD	8 byte	00000000
25	CS	2 Byte	7D

• SD data (Main)	
0	No SD (Main)
1	SQ_LSI communication error
2	MDU-IIC communication error
3	Abnormally in RST2
4	TEMP

• SD subcategory (SQ_LSI)	
0	No SD-Sub data
1	Communication error
2	Drive stop
3	BUSY
4	Version mismatching (H/S)
5	Version mismatching (M/S)

• SD subcategory (Main: MDU-IIC)	
0	No SD-Sub data
1	Main-EEPROM
2	Backup-EEPROM
3	DAC1
4	DAC2

• SD subcategory (Main: TEMP)	
0	No SD-Sub data
1	TEMP1 (high temperature)
2	TEMP1 (low temperature)

9.3.9 QSE (DESTINATION PECULIAR INFORMATION)

Induce it peculiar, individual information is acquired.

Command Format	Effective Operation Modes	Function	Remarks
[QSE]	Every time	Output of status	

Order	Part	Data Arrangement	Data Length	Output Example
0	—	Received Command name	3 byte	QSE
1		DTV Hardware Version	8 byte	07080200
2		DTV Hardware Serial	8 byte	16777215
3		DTV RUNTIME Version	8 byte	= 00K.22p
4		CFE Version	8 byte	07.00d
5		KERNEL Version	8 byte	2.4.2527
6		ROOTS Version	8 byte	04.13d
7		FLAGS Information 1	1 byte	Y
8		FLAGS Information 2	1 byte	*
9		FLAGS Information 3	1 byte	N
10		FLAGS Information 4	1 byte	Y
11		FLAGS Information 5	1 byte	N
12		FLAGS Information 6	1 byte	N
13		HMG/HG Model Version	10 byte	1.0.126
14		User Password	4 byte	1234
15	—	Check Sum	2 byte	13

9.3.10 QMT (TEMPERATURE / FAN ROTATION / ROOM LIGHT SENSOR)

Temperature information / FAN rotation state / Room light sensor information on the MTB side is returned.

Command Format	Effective Operation Modes	Function	Remarks
[QMT]	Every time	Output of status	A/D value of MTB-side's temperature/FAN rotating status

Order	Part	Data Arrangement	Data Length	Output Example
0	—	Received Command name	3 byte	QMT
1	MTB	A/D value of MTB-side Temperature	3 byte	267
2		MTB-side FAN rotating speed (0: STOP, 1: LOW, 2: HIGH)	1 byte	1
3		A/D value of room light sensor	3 byte	009
4		Level of room light sensor (Value: 1 to 5)	1 byte	5

9.3.11 QNG (SHUTDOWN INFORMATION OF MTB)

MTB side's shutdown information is acquired.

Command Format	Effective Operation Modes	Function	Remarks
[QNG]	Every time	Output of status	

Order	Part	Data Arrangement	Data Length	Output Example
0	—	Received Command name	3 byte	QNG
1	MTB	1st latest NG No.	1 byte	0
2		Subcategory No. for the 1st latest NG.	1 byte	0
3		MTB hour meter for the 1st latest NG.	7 byte	0000000
4		Reserved	3 byte	fixed on 000
5		2nd latest NG No.	1 byte	0
6		Subcategory No. for the 2nd latest NG.	1 byte	0
7		MTB hour meter for the 2nd latest NG.	7 byte	0000000
8		Reserved	3 byte	fixed on 000
9		3rd latest NG No.	1 byte	0
10		Subcategory No. for the 3rd latest NG.	1 byte	0
11		MTB hour meter for the 3rd latest NG.	7 byte	0000000
12		Reserved	3 byte	fixed on 000
:		:	:	
29		8th latest NG No.	1 byte	0
30		Subcategory No. for the 8th latest NG.	1 byte	0
31		MTB hour meter for the 8th latest NG.	7 byte	0000000
32		Reserved	3 byte	fixed on 000
33	—	Check Sum	2 byte	00

< SD Information No. >

Frequency *	Part	Part	Remarks (Operation)
5	MTB part	Shutdown signal from audio amp. / short-circuit of speaker terminal	Shutdown after 30 seconds warning
6		Failure of communication with Module microcomputer	Immediately Shutdown
7		3-wire serial communication of Main microcomputer	Go to No. 7 Subcategory Information
8		IIC communication failure of MTB side	Go to No. 8 Subcategory Information
9		Communication failure of Main microcomputer	Immediately Shutdown
10(A)		Failure of FAN	Go to No. 10 Subcategory Information
11(B)		Abnormally in high temperature	Shutdown after 30 seconds warning
12(C)		Failure of Digital Tuner	Go to No. 12 Subcategory Information
13(D)		Failure of Power Supply at MTB side	Go to No. 13 Subcategory Information
14(E)		Startup failure of Home Media Gallery	-
15(F)		Failure of Main EEPROM	Immediately Shutdown

*: Indicates the frequency of Blue LED flashing when the shutdown is occurred.

A

< No. 7 Subcategory Information on "Failure in 3-wire serial communication of Main microcomputer" >

Value	Shutdown Factor	Remarks (Operation)
1	Communication error of IF microcomputer	Shutdown
2	Communication error of sequence processor	Shutdown

B

< No. 8 Subcategory Information on "Failure in IIC communication of MTB side" >

Value	Shutdown Factor	Remarks (Operation)
1	Tuner 1	Shutdown
2	MSP/MAP	Shutdown
3	AV Switch	Shutdown
4	RGB Switch	Shutdown
5	VDEC	Shutdown
6	VDEC-SDRAM	Shutdown
7	AD/PLL	Shutdown
8	HDMI	Shutdown
A	Tuner 2	Shutdown
B	US-MSP	Shutdown

C

< No. 10 Subcategory Information on "Abnormally in FAN" >

Value	Shutdown Factor	Remarks (Operation)
1	FAN 1	Shutdown
2	FAN 2 (FHD only)	Shutdown

< No. 12 Subcategory Information on "Failure in Digital Tuner" >

Value	Shutdown Factor	Remarks (Operation)
1	DTV starting failure	Turn off the screen, then reset the device.
2	DTV communication error	
4	Abnormally in BCM7038	
7	Tuner 1 or 2	
8	Card I/F IC	
9	VBI Slicer	
C	EEPROM	
E	TV Guide	
G	Home Gallery	
H	Middleware	
I	Application	

< No. 13 Subcategory Information on "Failure in Power supply at MTB side" >

Value	Shutdown Factor	Remarks (Operation)
1	RST 2	Shutdown
2	RST 4	Shutdown

D

E

F

9.3.12 QSI (INPUT SIGNAL DATA)

The command QSI is for acquiring all data on input video signals.

Command Format	Effective Operation Modes	Function	Remarks
[QSI]	All operations	To acquire all data on input video signals	Return data: 3 (ECO) + 66 (DATA) + 2 (CS) = 71 Byte

Data Arrangement		Data Length	Output Example
ECO		3 Byte	QSI (fixed)
1	Type of drive sequence	3 Byte	60V
2	Standard/nonstandard	1 Byte	S
3	Type of ABL/WB tables	2 Byte	T1
4	Total value of PCN	4 Byte	0256
5	Total value of PRH	4 Byte	0256
6	Total value of PGH	4 Byte	0256
7	Total value of PBH	4 Byte	0256
8	Total value of PBR	4 Byte	0512
9	Total value of PRL	4 Byte	0512
10	Total value of PGL	4 Byte	0512
11	Total value of PBL	4 Byte	0512
12	Total value of ABL	3 Byte	128
13	V frequency distinction	4 Byte	6002
14	Reserved	1 Byte	*
15	Reserved	4 Byte	****
16	APL acquiring data	4 Byte	1023
17	Number of SUS pulses	4 Byte	0457
18	Result of detection of still picture	1 Byte	1
19	Result of detection of cracking in the panel	1 Byte	1
20	Result of detection for scanning protection	1 Byte	1
21	Result of detection for external protection	1 Byte	1
22	Transition of protection operation	1 Byte	1
23	Reserved	4 Byte	****
24	CS	2 Byte	27

1: Type of Drive sequence	
50V	Video 50 Hz
60V	Video 60 Hz
72V	Video 72 Hz
75V	Video 75 Hz
60P	PC 60 Hz
70P	PC 70 Hz

2: Standard/nonstandard	
S	Standard
N	Nonstandard

3: Type of ABL/WB tables	
Tn	n: 1 to 4

13: V frequency distinction
Reading value *100

16: APL acquiring data
Output with 10 bit 0 to 1023

17: Number of SUS pulses
0174 to 2752

18 to 21: Each protection function	
0	Setting: OFF
1	Setting: ON (during wait)
2	Setting: ON (during operation)

22: Transition of protection operations	
0	Upper limit state for brightness
1	Brightness being reduced
2	Lower limit state for brightness
3	Brightness being increased

9.3.13 DRV (PANEL DRIVE-POWER ON / OFF)

Drive ON/OFF: ON/OFF control of panel drive-power system

Command Format	Effective Operation Modes	Function	Remarks
[DRV+S00]	Every time	DRIVE OFF	
[DRV+S01]	Every time	DRIVE ON (default)	

Once the DRIVE OFF command is accepted, DRIVE OFF cannot be canceled by pressing the DRIVE OFF key again or by turning the unit off then back on with the STANDBY OFF/ON key.

To cancel DRIVE OFF, restart the unit by unplugging then again plugging in the power cord.

9.3.14 FAY / FAN (ADJ. COMMANDS PERMISSION / PROHIBITION)

The commands FAY/FAN are for prohibiting/permitting panel/MTB-adjustment commands.

Command Format	Operation		Remarks
	Effective Operation Modes	Control	
[FAY]	Normal operation mode while the power is on	Adjustment command is valid.	For details, refer to the section “6.1.3 FUNCTIONS WHEN ENTERING THE SERVICE FACTORY MODE”.
[FAN]	During FAY	Adjustment command is invalid.	

9.3.15 FAJ / UAJ / CBU / BCP (BACKUP FUNCTION FOR ADJUSTMENT VALUE)

When the DIGITAL Assy is to be replaced, adjustment values can be copied from the backup EEPROM to the EEPROM of the Assy for service.

Command Format	Operation		Remarks
	Effective Operation Modes	Control	
[FAJ]	During FAY	To make the flag setting that indicating that adjustment of the panel unit has been completed	This takes at least 350 mS.
[UAJ]		To make the flag setting that indicating that adjustment of the main unit has not been completed	
[CBU]		To make the flag setting that indicating that backup data have not been copied	The backup ROM is initialized.
[BCP]		To copy Digital backup data to EEPROM	

■

5

■

6

■

7

■

8

■

A

■

B

■

C

■

D

■

E

■

F

■

5

■

6

■

7

■

8


■

PDP-5010FD

△

(In the case of no amount instructions, apply as you think it appropriate.)

4



(1) PACKING SECTION PARTS LIST

Mark No.	Description	Part No.	Mark No.	Description	Part No.
1	Power Cord (2 m)	ADG1215	15	After Image Caution	See Contrast table (2)
2	Remote Control Unit	AXD1550	16	Pad (508F-REG B-L)	AHA2632
3	Battery Cover	AZN2680	17	Pad (508F-REG B-R)	AHA2633
NSP 4	Alkaline Dry Cell Battery (LR6, AA)	VEM1023	18	Pad (508F-REG T-L)	AHA2634
5	Binder Assy	AEC1908	19	Pad (508F-REG T-R)	AHA2635
6	Cleaning Cloth	AED1285	20	Pad (508F-REG ACC)	AHA2675
7	Operating Instructions (English, French, Spanish)	See Contrast table (2)	21	Under Carton	See Contrast table (2)
8	Caution Card	See Contrast table (2)	22	Upper Carton (5010FD)	See Contrast table (2)
9	Cleaning Caution (U)	See Contrast table (2)	23	Packing Sheet L	See Contrast table (2)
10	Accessory Caution	See Contrast table (2)	24	Band Assy	AXY1192
NSP 11	Warranty Card	See Contrast table (2)	25	Speaket System	SMW1985
NSP 12	Card (Register)	See Contrast table (2)	26	HDMI Caution	See Contrast table (2)
13	Polyethylene Bag	See Contrast table (2)	27	•••••	
14	Power Button Caution	See Contrast table (2)	28	Parental Caution	See Contrast table (2)

(2) CONTRAST TABLE

PDP-5010FD/KUCXC and KUC are constructed the same except for the following:

Mark	No.	Symbol and Description	PDP-5010FD /KUCXC	PDP-5010FD /KUC
NSP	7	Operating Instructions (English, French, Spanish)	ARE1472	ARE1487
	8	Caution Card	ARM1239	ARM1232
	9	Cleaning Caution (U)	ARM1303	ARM1283
	10	Accessory Caution	ARM1304	ARM1362
	11	Warranty Card	ARY1196	ARY1138
NSP	12	Card (Register)	ARY1156	VRV1132
NSP	13	Polyethylene Bag	AHG1394	Not used
	13	Vinyl Bag	Not used	AHG1340
	14	Power Button Caution	ARM1360	ARM1363
	15	After Image Caution	ARM1351	ARM1361
	21	Under Carton (508)	AHD3588	Not used
	21	Under Carton (5010FD)	Not used	AHD3571
	22	Upper Carton (5010FD)	AHD3624	AHD3623
	23	Packing Sheet L	AHG1389	Not used
	23	Packing Sheet	Not used	AHG1405
	26	HDMI Caution	ARM1373	ARM1374
	28	Parental Caution	ARM1371	ARM1372

10.2 REAR SECTION

A


B

C

D

E

F



Refer to
"10.3 FRONT SECTION".

(1) REAR SECTION PARTS LIST

Mark No.	Description	Part No.	Mark No.	Description	Part No.
1	SIDE IO Assy	AWW1274	21	Label C (U)	AAX3501
2	SIDE KEY Assy	AWW1275	22	Label B50 (U)	AAX3540
3	USB Cable (J301)	ADF1034	23	Terminal Panel B (50U)	ANC2452
4	Side Input Panel (8U)	ANC2457	24	Power Button Case (508F)	AAK2908
5	Function Button Base	See Contrast table (2)	25	Function Button Panel	AMB2906
6	Side Input Shield	See Contrast table (2)	26	Side Input Cover	AMB2911
7	Function Button Shield	See Contrast table (2)	27	Function Button	AAC1562
8	Coil Spring	ABH1125	28	Power Button (508F)	AAD4152
9	Spacer	AEC1288	29	Function Button Sheet (8U)	AAK2919
10	PCB Spacer	AEC1570	30	Input Cover Label 8U	AAX3509
11	Reuse Wire Saddle	AEC1945	31	Rear Case (508F)	ANE1662
12	Locking Card Spacer	AEC2019	32	Cushion	AEB1489
13	Reuse Wire Saddle	AEC2118	33	•••••	
14	USB Spacer A	AED1317	34	Screw (3 x 40P)	ABA1332
15	Inner Grip Assy	See Contrast table (2)	35	Screw	ABA1341
⚠ 16	Gasket (J-TYPE)	ANK1956	36	Screw	AMZ30P060FTB
NSP 17	Name Label	See Contrast table (2)	37	Screw	AMZ30P080FTC
NSP 18	Serial Seal	See Contrast table (2)	38	Screw	APZ30P080FTB
19	Caution Label	See Contrast table (2)	39	Screw	BPZ30P080FTB
20	Label A (U)	AAX3478	40	Screw	TBZ40P080FTB
			41	Screw	BBZ30P060FTB
			42	Screw	BPZ30P100FTB

(2) CONTRAST TABLE

PDP-5010FD/KUCXC and KUC are constructed the same except for the following:

Mark	No.	Symbol and Description	PDP-5010FD /KUCXC	PDP-5010FD /KUC
NSP	5	Function Button Base	ANG3066	ANG2923
	6	Side Input Shield	ANK1938	ANK1834
	7	Function Button Shield	ANK1939	ANK1835
	15	Inner Grip Assy	AMR3693	AMR3434
	17	Name Label (508REG)	AAL2934	Not used
NSP	17	Name Label (508REG-J)	Not used	AAL2997
NSP	18	Serial Seal	AAX3182	Not used
	18	Serial Sheet	Not used	AAX3143
	19	Caution Label U	AAX3534	Not used
	19	Caution Label E	Not used	AAX3533

10.3 FRONT SECTION

A


B

C

D

E

F



FRONT SECTION PARTS LIST

<u>Mark</u>	<u>No.</u>	<u>Description</u>	<u>Part No.</u>
	1	FHD IR Assy	AWW1289
	2	50FHD LED Assy	AWW1291
	3	FHD RLS Assy	AWW1292
	4	6P/6P/3P Housing Wire (J117)	ADX3562
	5	Blind Cushion (508F)	AEB1479
	6	Nylon Rivet	AEC1671
	7	Rivet	AEC1877
	8	1..Front Case Assy (508FU)	AMB3001
NSP	9	2..Panel Cushion H (50)	AED1257
NSP	10	2..Panel Cushion V (50)	AED1258
	11	•••••	
	12	FC Gate Sheet	AMR3746
	13	Screw	ABZ30P080FTC

10.4 CHASSIS SECTION (1/2)

A

B

C

D


E

F

Refer to
"10.7 MULTI BASE SECTION".



Cleaning liquid : GEM1004
Cleaning paper : GED-008



Refer to
"10.5 CHASSIS SECTION (2/2)".

PDP-5010FD

(1) CHASSIS SECTION (1/2) PARTS LIST

Mark No.	Description	Part No.	Mark No.	Description	Part No.
1	FHD POWER SW Assy	AWW1293	16	Sub Frame Plate	ANG3046
2	Ferrite Core (L1)	ATX1044	17	Floating Rubber 80	AEB1427
3	Housing Wire (J103)	ADX3552	18	Ferrite Core Holder	AEC1818
⚠ 4	Fan Motor 80 x 25L	AXM1058	19	Reuse Wire Saddle	AEC1945
⚠ 5	DC Fan Motor 80 x 25L	AXM1064	20	Ferrite Clamp	AEC1986
6	Front Chassis VL (508F)	AMA1027	21	Reuse Wire Saddle	AEC2118
7	Front Chassis VR (508F)	AMA1028	22	Fan Holder	AMR3704
8	Sub Frame L Assy 507	See Contrast table (2)	23	Gasket ADH-FCH	ANK1850
9	Sub Frame R Assy 507	See Contrast table (2)	24	•••••	
10	Front Chassis HT (508F) Assy	ANA2092	25	•••••	
11	Front Chassis HB Assy (50)	ANA2094	26	Screw	See Contrast table (2)
12	Panel Holder V1 (50)	ANG2770	27	Screw	ABZ30P080FTC
13	Panel Holder V2 (50)	ANG2771	28	Screw	AMZ30P060FTB
14	Fan Holder	ANG2833	29	Screw	APZ30P080FTB
15	Multi Base Holder	ANG2937	30	Screw	PPZ50P100FTB
			31	Screw	TBZ40P080FTB
			32	Screw	ABA1364

(2) CONTRAST TABLE

PDP-5010FD/KUCXC and KUC are constructed the same except for the following:

Mark	No.	Symbol and Description	PDP-5010FD /KUCXC	PDP-5010FD /KUC
	8	Sub Frame L Assy 507	ANA2080	ANA1945
	9	Sub Frame R Assy 507	ANA2081	ANA1946
	26	Screw	ABA1313	ABA1351

10.5 CHASSIS SECTION (2/2)

A


B

C

D

E

F



(1) CHASSIS SECTION (2/2) PARTS LIST

Mark No.	Description	Part No.	Mark No.	Description	Part No.
1	50F X DRIVE Assy	AWV2510	26	6P&6P Housing Wire (J109)	ADX3557
2	50F Y DRIVE Assy	AWV2511	27	6P&6P Housing Wire (J111)	ADX3558
3	PANEL SENSOR Assy	AWW1309	28	6P&6P Housing Wire (J112)	ADX3559
4	50F DIGITAL Assy	AWW1316	29	3P&3P&3P Housing Wire (J123)	ADX3565
5	FHD FAN CONNECT Assy	AWW1290	30	Conductive Plate Y	ANG3050
△ 6	POWER SUPPLY Unit	AXY1168	31	Nylon Rivet	AEC1671
7	Ferrite Core (F1 - F8)	ATX1048	32	Wire Saddle	AEC1745
8	Three Pieces Connector 40P	AKM1384	33	Flat Clamp	AEC1879
9	Flexible Cable (J201)	ADD1498	34	Ferrite Clamp	AEC1986
10	Flexible Cable (J202)	ADD1499	35	Side Type Mini Clamp	AEC2003
11	Flexible Cable (J203)	ADD1500	36	PCB Spacer (Reuse)	AEC2087
12	Flexible Cable (J204)	ADD1501	37	Reuse Wire Saddle	AEC2118
13	Flexible Cable (J205)	ADD1502	38	Reuse HL 28	AEC2119
14	Flexible Cable (J206)	ADD1503	39	PCB Spacer (Reuse)	AEC2122
15	Flexible Cable (J207)	ADD1504	40	Drive Silicone	AEH1139
16	Flexible Cable (J208)	ADD1505	41	Drive Sheet A	AMR3697
17	Flexible Cable (J209)	ADD1506	42	Drive Sheet B	AMR3698
18	Flexible Cable (J210)	ADD1507	43	•••••	
19	Flexible Cable (J211)	ADD1508	44	•••••	
20	5P Housing Wire (J105)	ADX3359	45	Screw	See Contrast table (2)
21	Housing Wire (J126)	ADX3545	46	Screw	ABA1364
22	9P&7P Housing Wire (J101)	ADX3550			
23	8P&8P Housing Wire (J102)	ADX3551			
24	14P Housing Wire (J104)	ADX3553			
25	6P&6P Housing Wire (J108)	ADX3556			

(2) CONTRAST TABLE

PDP-5010FD/KUCXC and KUC are constructed the same except for the following:

Mark	No.	Symbol and Description	PDP-5010FD /KUCXC	PDP-5010FD /KUC
	45	Screw	ABA1313	ABA1351

10.6 PANEL CHASSIS SECTION

A


B

C

D

E

F



(1) PANEL CHASSIS SECTION PARTS LIST


<u>Mark No.</u>	<u>Description</u>	<u>Part No.</u>
NSP 1	Panel Chassis (F) Assy	AWU1234
NSP 2	50F ADDRESS L Assy	AWW1310
NSP 3	50F ADDRESS S Assy	AWW1311
NSP 4	50F SCAN A Assy	AWW1312
NSP 5	50F SCAN B Assy	AWW1313
NSP 6	50F SCAN C Assy	AWW1314
NSP 7	50F SCAN D Assy	AWW1315
NSP 8	Plasma Panel (50F) Assy	AWU1235
9	PCB Spacer (Reuse)	AEC2087
10	PCB Spacer (Reuse)	AEC2122
11	Heat Radiation Sheet	AEH1134
12	Conductive Plate Holder	AMR3446
13	Address Plate (50F) A	ANG3048
14	Address Plate (50F) B	ANG3071
15	Conductive Plate X (F)	ANG2906
16	Screw	ABA1351
17	Screw	ABA1364
18	Three Pieces Connector 40P	AKM1384
19	Gasket AD	ANK1948
20	Screw	See Contrast table (2)

(2) CONTRAST TABLE

PDP-5010FD/KUCXC and KUC are constructed the same except for the following:

Mark	No.	Symbol and Description	PDP-5010FD /KUCXC	PDP-5010FD /KUC
	20	Screw	ABA1313	ABA1351

10.7 MULTI BASE SECTION




MULTI BASE SECTION PARTS LIST


Mark	No.	Description	Part No.
⚠	1	MAIN Assy	AWV2457
	2	TANSHI Assy	AWW1334
	3	POD Assy	AWW1295
⚠	4	Power Switch (S1 : TRAP)	ASG1089
⚠	5	AC Inlet (CN1)	AKP1322
	6	Flexible Cable (J212)	ADD1441
	7	Flexible Cable (J213)	ADD1491
	8	Flexible Cable (J214, J215)	ADD1519
	9	12P&15P Housing Wire (J106)	ADX3554
	10	5P Housing Wire (J107)	ADX3555
	11	11/6/4P Housing Wire (J114)	ADX3560
	12	•••••	
	13	11P Housing Wire (J118)	ADX3563
	14	8P/4P Housing Wire (J119)	ADX3531
	15	7P Housing Wire (J125)	ADX3566
	16	3P Housing Wire (J127)	ADX3546
	17	•••••	
	18	Locking Card Spacer	AEC1429
	19	Wire Saddle	AEC1745
	20	Reuse Wire Saddle	AEC1945
	21	Silicone Sheet Audio	AEH1143
	22	POD Cover	AMR3542
	23	Multi Base Assy (U)	ANA2102
	24	Terminal Panel A (U)	ANC2440
	25	POD Stay A	ANG2933
	26	•••••	
	27	Gasket UD	ANK1883
	28	Hex. Head Screw	BBA1051
	29	Washer Faced Nut	BBN1005
	30	Screw	BMZ30P060FTB
	31	Screw	PMB30P080FNI
	32	6P Housing Wire (J115)	ADX3561
	33	4P Housing Wire (J122)	ADX3564

10.8 PDP SERVICE ASSY 508F (AWU1272)

● Exterior Section



● Packing Section



PDP SERVICE ASSY 508F PARTS LIST

<u>Mark No.</u>	<u>Description</u>	<u>Part No.</u>	<u>Mark No.</u>	<u>Description</u>	<u>Part No.</u>
NSP 1	Panel Chassis (F) Assy	AWU1234	26	Screw	APZ30P080FTB
2	Front Chassis VL (508F)	AMA1027	27	Screw	TBZ40P080FTB
3	Front Chassis VR (508F)	AMA1028	28	•••••	
4	Sub Frame L Assy 507	ANA1945	29	•••••	
5	Sub Frame R Assy 507	ANA1946	30	•••••	
6	Front Chassis HT (508F) Assy	ANA2092	31	Caution Label	AAX3031
7	Front Chassis HB Assy (50)	ANA2094	32	Vinyl Bag S	AHG1338
8	Conductive Plate X (F)	ANG2906	33	•••••	
9	Sub Frame Plate	ANG3046	34	Service Pad	AEC2105
10	Address Plate (50F) A	ANG3048	35	Pad (508F T-L)	AHA2683
11	Address Plate (50F) B	ANG3071	36	Pad (508F T-R)	AHA2684
12	Rivet	AEC1877	37	Pad (508F B-L)	AHA2685
13	Ferrite Clamp	AEC1986	38	Pad (508F B-R)	AHA2686
14	Side Type Mini Clamp	AEC2003	39	Under Carton (508F)	AHD3622
15	PCB Spacer (Reuse)	AEC2122	40	Upper Carton (508F service)	AHD3637
16	Gasket ADH-FCH	ANK1850	41	Protect Sheet	AHG1331
17	Gasket AD	ANK1948			
NSP 18	Front Case (508F)	AMB3000			
19	Rear Case (508F)	ANE1662			
NSP 20	Drive Voltage Label	ARW1097			
21	Screw (3 x 40P)	ABA1332			
22	Screw	ABA1351			
23	Screw	ABA1364			
24	Screw	ABZ30P080FTC			
25	Screw	AMZ30P060FTB			

10.9 TABLE TOP STAND





TABLE TOP STAND PARTS LIST

Mark No.	Description	Part No.
1	Base Cover Assy	AXY1176
2	Stand Pipe L Assy	AXY1182
3	Stand Pipe R Assy	AXY1183
4	Screw	ABA1357
5	Screw (M8 x 23)	ABA1371
6	Screw (M8 x 40)	ABA1373

10.10 SPEAKER SYSTEM (PACKING)



SPEAKER SYSTEM (PACKING) PARTS LIST

Mark No.	Description	Part No.	Mark No.	Description	Part No.
NSP 1	1..Accessory Set	SME3775	17	•••••	
2	2..Speaker Wire	SDS1202	18	Protector (Side)	SHA2577
3	2..Polyethylene Bag S1	SHL1439	19	Protector (C-T)	SHA2578
NSP 4	2..Screw Set	SME3696	20	Protector (C-M)	SHA2579
5	3..Screw	BMZ50P100FTB	21	Protector (C-B)	SHA2580
6	3..Polyethylene Bag S0	SHL1438	22	Protection Sheet S3	SHC1846
7	1..Bracket Assy (S)	SXG1127	23	Protection Sheet S1	SHC1847
8	2..Gasket	SED1136	24	Packing Case	SHG2780
9	2..Gasket	SED1138	25	Packing Bag S2	SHL1450
10	2..Gasket	SED1166	26	Polyethylen Bag S0	SHL1451
NSP 11	2..Bracket LR	SNA1481	NSP 27	CS Assy	SMW1987
12	1..Bracket Assy (C)	SXG1128	NSP 28	Serial Label	SRW1112
13	2..Gasket	SED1140			
14	2..Gasket	SED1141			
15	2..Gasket	SED1167			
NSP 16	2..Bracket C	SNA1482			

10.11 CS ASSY

A


B

C

D

E

F



CS ASSY PARTS LIST

<u>Mark No.</u>	<u>Description</u>	<u>Part No.</u>	<u>Mark No.</u>	<u>Description</u>	<u>Part No.</u>
1	Speaker	H132DC65-51D	44	Screw	BPZ30P080FTC
2	Speaker	FK26AP32-55H	45	Screw	BPZ35P080FTC
NSP 3	Baffle	SNK2980	46	Screw	BPZ35P120FTB
NSP 4	Cabinet Assy C	SXG1122	47	Screw	BPZ35P120FTC
NSP 5	Cabinet Assy L	SXG1123	48	Screw	BPZ35P140FTB
NSP 6	Cabinet Assy R	SXG1124	49	Screw	BPZ40P350FTC
7	Grille	SMG1886			
8	1..Network Assy	SWN1787			
	2..Capacitor 1.5	SCE1034			
	2..Choke Coil 0.68	STH1266			
NSP 9	Gasket	SEB1299			
NSP 10	Gasket	SEB1300			
11	Packing	SEB1302			
NSP 12	Blinder	SEB1304			
NSP 13	Gasket	SEB1315			
NSP 14	Gasket	SEB1316			
NSP 15	Gasket	SEC2074			
16	Gasket	SEC2076			
NSP 17	Gasket	SEC2078			
18	Gasket	SEC2083			
NSP 19	Gasket	SEC2092			
NSP 20	Gasket	SEC2093			
NSP 21	Gasket	SEC2113			
NSP 22	Gasket	SEC2114			
NSP 23	Gasket	SEC2150			
NSP 24	Gasket	SEC2142			
NSP 25	Felt	SED1127			
NSP 26	Felt	SED1130			
27	Tape	SEH1089			
28	Tape	SEH1099			
29	Tape	SEH1117			
30	Input Terminal	SKX1098			
NSP 31	MDF Bar	SLX1165			
NSP 32	Paper Tube 26	SMR1403			
NSP 33	Acoustic Absorbent	SMT1331			
NSP 34	Acoustic Absorbent	SMT1333			
NSP 35	Acoustic Absorbent	SMT1335			
NSP 36	Acoustic Absorbent	SMT1328			
NSP 37	Acoustic Absorbent	SMT1357			
NSP 38	Acoustic Absorbent	SMT1358			
NSP 39	Acoustic Absorbent	SMT1359			
NSP 40	Model Label	SAN3955			
NSP 41	Caution Label	SRR1024			
NSP 42	Serial Label	SRW1111			
43				